

Contents

1	Technical Data	5
2	Declarations of Manufacturer.....	7
2.1	Declaration regarding assemblies and components	7
2.2	EC Declaration of Conformity (RL 94/9/EC, Annex X.B).....	8
3	Preface.....	9
3.1	General information	9
3.2	Proper use	10
4	Safety	11
4.1	Notes and symbols	11
4.2	As delivered condition	12
4.3	Storage / Packing / Preservation	12
4.3.1	Storage of turbo coupling	12
4.3.2	Storage of flexible elements	13
4.4	Lifting	14
4.5	General information with regard to dangerous situations	17
4.5.1	Fire extinguishing means, Fire fighting	19
4.6	Important information with regard to operation	20
4.7	Transportation	22
4.8	Staff qualification	23
4.9	Product observation.....	23
5	Voith Turbo Couplings with Constant Fill	24
5.1	Function	24
5.2	Type designation	25
5.3	Design examples	27
5.3.1	Connecting coupling on the input side	27
5.3.2	Connecting coupling on the output side	28
6	Tightening Torques	29
6.1	Set screws and fixing bolts	29
6.2	Fusible plugs, filler plugs, sight glasses, blind- and nozzle screws	30
6.3	Fastening screws.....	30
7	Installation of Basic Coupling Type T	31
7.1	Tools	31
7.2	Preparation	32
7.3	Mounting.....	34
7.4	Mounting devices.....	36
8	Installation of Basic Coupling Type TN.....	37
8.1	Mounting.....	38
9	Alignment.....	40
9.1	Flexible connecting couplings	40
9.1.1	Connecting couplings on input side (Outer wheel drive).....	40
9.1.2	Connecting couplings on output side (Outer wheel drive)	41
9.2	Laid lengths and type allocations turbo coupling / flexible connecting coupling.....	42
9.3	Alignment tolerances	42
9.4	Alignment.....	43
10	Operating Fluids	45
10.1	Requirements to be fulfilled by the operating fluid mineral oil.....	45
10.1.1	Usable operating fluids	46
10.1.2	Proposed operating fluids	46
10.2	Proposed operating fluids for special requirements	47
10.3	Requirements to be fulfilled by the operating fluid water	48

10.3.1	Usable operating fluids.....	48
10.3.2	Operating fluid water used for turbo couplings with centrifugal valves (types TW...F...)	48
11	Fill, Filling Check and Draining.....	50
11.1	Coupling fill.....	51
11.1.1	How to fill couplings installed in horizontal position	51
11.1.2	How to fill couplings installed in vertical position	52
11.2	Filling check	52
11.2.1	Level check for couplings installed in horizontal position	52
11.2.2	Level check for couplings installed in vertical position.....	53
11.3	Draining the coupling	54
11.3.1	Draining of couplings without delay chamber installed in horizontal position..	54
11.3.2	Draining of couplings with delay chamber installed in horizontal position.....	54
11.3.3	How to drain couplings installed in vertical position.....	55
12	Commissioning	56
13	Maintenance, Repair	58
13.1	Outside cleaning	61
13.2	Flexible connecting coupling.....	62
13.2.1	Control of flexible elements wear	62
13.2.2	Maintenance intervals	63
13.3	Bearings	63
13.3.1	Bearing lubrication when using mineral oil as operating fluid.....	63
13.3.2	Bearing lubrication when using water as operating fluid	63
13.3.3	Replacement of bearings / regreasing	63
13.4	Fusible plugs	64
13.4.1	Fusible plugs in couplings not suitable for usage in potentially explosive atmospheres	65
13.4.2	Fusible plugs in couplings suitable for usage in potentially explosive atmospheres	66
14	Assembly Control-, Commissioning and Maintenance Report.....	67
14.1	Assembly control report	68
14.2	Commissioning report	70
14.3	Maintenance report for general maintenance	71
14.3.1	Maintenance report for flexible connecting coupling.....	72
15	Coupling Disassembly.....	73
15.1	Preparation.....	73
15.2	Removal	74
15.3	Mechanical removal devices	75
15.4	Hydraulic removal devices	76
16	Malfunctions – Remedial Action.....	77
17	Queries, Orders placed for Service Engineers and Spare Parts.....	80
18	Temperature Monitoring.....	81
18.1	MTS mechanical thermal switch unit for pre-warning	81
18.2	BTS non-contacting thermal switch unit.....	82
18.2.1	BTS non-contacting thermal switch unit for pre-warning	82
18.2.2	BTS-Ex non-contacting thermal switch unit for limiting the maximum surface temperature	83
18.3	BTM non-contacting thermal measuring unit for pre-warning.....	84
19	Spare Parts Information	86
19.1	Spare parts for type 154 T	87
19.2	Spare parts for types 206 - 274 T	87
19.3	Spare parts for types T and TN.....	88

19.3.1	Spare parts for types 366 - 1150 T.....	89
19.3.2	Spare parts for types 366 - 650 TN.....	89
19.4	Spare parts for types 274 TV/TVV	91
19.5	Spare parts for types TV/TVV and TVN/TVVN	92
19.5.1	Spare parts for types 366 - 1150 TV/TVV	93
19.5.2	Spare parts for types 366 - 650 TVN/TVVN	93
19.6	Spare parts for types TVVS and TVVSN.....	94
19.6.1	Spare parts for types 422 - 1150 TVVS	95
19.6.2	Spare parts for types 422 - 650 TVVSN.....	95
19.7	Spare parts for type 154 DT	96
19.8	Spare parts for types 206 DT and 274 DT/DTV	97
19.9	Spare parts for types 1150 DT/DTV	98
20	Spare parts information Connecting couplings.....	100
20.1	Connecting couplings on the input side	100
20.1.1	Flexible cam coupling type ENK.....	100
20.1.2	Flexible element coupling type EEK.....	100
20.1.3	Flexible packet coupling type EPK	101
20.2	Connecting coupling on the output side	101
20.2.1	Coupling Nor-Mex G.....	101
21	Representatives Voith Turbo GmbH & Co. KG.....	103
22	Index	106

1 Technical Data

Necessary information for use in potentially explosive atmospheres:



CE - Marking:		
Ambient temperature, if deviating from -25 °C T _a +40 °C		°C
max. surface temperature (T ₃ = 200 °C, T ₄ = 135 °C, or deviating)		°C
Temperature monitoring	<input type="checkbox"/> MTS ¹⁾ for pre-warning <input type="checkbox"/> BTS ²⁾ for pre-warning <input type="checkbox"/> BTS-Ex ²⁾ for limitation of max. surface temperature for Voith Turbo couplings acc. to EC Directive 94/9/EG Maximum permissible temperature of turbo coupling on motor start:	°C
Nominal response temperature of temperature monitoring		°C
Max. permissible fill rate ³⁾		dm ³ (litre)
Fusible plug (SSS)	<input type="checkbox"/> SSS <input type="checkbox"/> SSS-X	
Overload (see chap. 4.6), causing response of thermal fuse (fusible plug(s) and/or BTS-Ex) requires switch-off of power supply after		s (sec)
Additional monitoring of output speed is required to switch off power supply prior to response of fusible plugs.	<input type="checkbox"/> yes <input type="checkbox"/> no	
After motor switch-on, monitoring of output speed has to become effective after		s (sec)
Diameter input ⁴⁾		mm
Diameter output ⁴⁾		mm
Replacement of roller bearings		h

Table 1

- ¹⁾ MTS: Mechanical thermal switch unit (see chapter 18.1).
²⁾ BTS: Non-contacting thermal switch unit (see chapter 18.2).
³⁾ Applies for missing fill rate on cover sheet.
⁴⁾ Diameter and fit of hub or shaft to be joined by means of shaft-hub connection.



Additional data required for use on potentially explosive areas:

2 Declarations of Manufacturer

2.1 Declaration regarding assemblies and components

Since 29 December 2009 a new Machinery Directive 2006/42/EC has to be applied bindingly in the member state of the European Community.

Voith turbo couplings of Product Group 'Start-up Components' as defined by the new Machinery Directive 2006/42/EC and the explanations of the guidelines published in December 2009 to implement the machinery directive, are neither "*Machinery*" nor "*incomplete machinery*" but assemblies or components.

As our products are no incomplete machinery, we do not issue a declaration of incorporation as per Machinery Directive 2006/42/EC.

Also, an EC Declaration of Conformity must not be issued, neither the CE marking be made, unless specified by other EC directives or regulations.

Voith as certified company ensures that the basic safety and health requirements for their products are always be met by internal quality management systems and by applying harmonized standards.

The technical documentation for Voith products is so comprehensive that they may be installed reliably into machinery or incomplete machinery and a safe operation of the complete machinery with regard to the Voith products is also possible later on when observing this documentation.

Issued in
On

Crailsheim, Germany
March 18th 2010

Name of
the undersigned

Mr. B. Morlock,
General Manager - Start-up Components

Signature



2.2 EC Declaration of Conformity (RL 94/9/EC, Annex X.B)

in confirmation of compliance of the machinery with Directive 94/9/EC

The manufacturer **Voith Turbo GmbH & Co. KG,**
Voithstraße 1, D-74564 Crailsheim

hereby declares that the machinery described below:

Description T...
Turbo Couplings with constant fill

Serial No. see shipping documents

complies with the provisions of the following harmonized standards in the version valid at signature date:

EN ISO 12100-1 / -2	Safety of machinery - basic concepts and general principles for design Part 1: Terminology, methodology Part 2: Technical principles
EN 1127-1 / -2	Explosive atmospheres, explosion prevention and protection, basic concepts and methodology
EN 13463-1	Non-electrical equipment for use in potentially explosive atmospheres, Part 1: Basic method and requirements
EN 13463-5	Non-electrical equipment for use in potentially explosive atmospheres, Part 5: Protection by constructional safety "c"
EN 13463-8	Non electrical equipment for use in potentially explosive atmospheres, Part 8: Protection by liquid immersion "k"
EN 1710	Equipment and components intended for use in potentially explosive atmospheres in underground mines

as well as with the following European and national standards and technical specifications in the version valid at signature date:

TRBS 2153	Avoidance of ignition hazards resulting from electrostatic charging
-----------	---

Each modification by the customer on the parts supplied, invalidates the declaration.

Issued in	Crailsheim, Germany
On	March 18 th 2010
Name of the undersigned	Mr. B. Morlock, General Manager - Start-up Components

Signature



3 Preface

3.1 General information

This manual will support you in using the turbo coupling in a safe, proper and economical way.

If you observe the information contained in this manual, you will

- increase the reliability and lifetime of coupling and installation,
- avoid risks,
- reduce repairs and downtimes.

This manual must

- **always be available at the machine site,**
- **be read and used by every person who works on the coupling.**

The coupling is manufactured to the state of art and approved safety regulations. Nevertheless, the user's or third parties' life may be endangered or the machine or other material assets impaired in case of improper handling or use.

Spare parts:

Spare parts must comply with the requirements determined by Voith.

This is guaranteed when original spare parts are being used.

Installation and/or use of non-original spare parts may negatively change the mechanical properties of the **Voith Turbo coupling** and thus have an adverse impact on the safety.

Voith is not liable for damages resulting from use of non-original spare parts.

Use only appropriate workshop equipment for repair. Professional maintenance or repair can only be guaranteed by the manufacturer or an authorized specialist workshop.

This manual has been issued with utmost care. However, in case you should need any further information, please contact:

Voith Turbo GmbH & Co. KG

Start-up Components

Voithstr. 1

74564 Crailsheim

GERMANY

Tel. +49 7951 32-0

Fax. +49 7951 32-480

startup.components@voith.com

www.voithturbo.com/startup-components

© Voith Turbo 2010.

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

Voith Turbo reserves the right for modifications.

3.2 Proper use

The turbo coupling with constant fill is provided to transmit the torque from the drive motor to the driven machine.

The **power** permitted during stationary operation at a specific **input speed** and a specific **coupling fill** (operating fluid and filling) is entered on the cover sheet of this manual. Use for another purpose, e.g. higher power ratings, higher speeds or for other operating conditions not agreed, is considered not being in accordance with the regulations.

Use in accordance with the regulations also includes observing this installation and operating manual and complying with the inspection and maintenance conditions.

The manufacturer is **not** liable for damages resulting from use not in accordance with the regulations. The risk is to be borne solely by the user.



– **EX-PROTECTION! / ATTENTION!**

If no according information is given in Chapter 1, it is not possible to use this coupling in potentially explosive atmosphere!

Please check whether the coupling, according to the marking, is approved for hazardous areas.



DANGER!

– **Remaining risks on the turbo coupling:**

Improper use or mishandling may cause death, severe injuries or minor injuries as well as property damage and harm to the environment.

Only persons who are sufficiently qualified, trained and authorized are allowed to work on or with the turbo coupling!

Please pay attention to the warnings and safety information!


4 Safety




4.1 Notes and symbols

The safety notes included in this instruction manual are particularly marked with safety marks according to DIN 4844:

Damage/ harm to...	Signal word	Definition	Consequences	Symbol
Persons Property	EX-PRO- TECTION!	Notes to Ex- protection	Explosion hazard	
Persons	DANGER!	imminent danger	fatal or most serious injuries (crippling)	
Persons	WARNING!	dangerous situation possible	fatal or most serious injuries possible	
Persons	CAUTION!	less dangerous situation	slight or minor injuries possible	
Persons Property		warning of com- bustible materials	fire hazard	
Persons		use goggles	risk of losing sight, risk of going blind	
Persons		Use ear protection	hearing damage	
Property	ATTENTION!	harmful situation possible	damage possible to – the product – its environment	
–	Note! Information!	application hints and other useful infor- mation	efficient in operation	

Table 2

Marking with the Ex-symbol () indicates possible hazards which have to be observed only if applied in explosion hazardous areas.

If apart from the symbol for Ex-protection () there is another symbol ( or ) , adhere to the instructions for operation also out of explosion hazardous areas.

4.2 As delivered condition

- **Basic type T...:**
The turbo coupling is delivered complete with mounted connecting coupling (if included in the scope of supply).

Basic type T...N...:

The turbo coupling is delivered complete with mounted primary coupling flange.

→ Coupling fill:
Chapter 11,
page 50

- The turbo coupling is without fill.
Any operating fluid included in the scope of supply is delivered in a separate container.
The operator himself fills in the operating fluid.
- Other accessories are supplied as loose parts.
Basic type T...: Fixing bolt and holding disk are supplied additionally.
- One set of fusible plugs is supplied as spares.



ATTENTION!

Dispose of the packing and used parts in accordance with the stipulations of the country of installation!

4.3 Storage / Packing / Preservation

4.3.1 Storage of turbo coupling

As delivered condition:

The as delivered condition of the Voith Turbo Couplings depends on transportation and storage period:

Condition no. 1 represents the condition as delivered. For deviations, please refer to order documents.

No.	- Transport - adm. storage period	Packing / Measures taken
1	- Transport by land / by air - Storage up to 6 months in closed hall	- Device to suit transportation - Weather protection through means of transportation - Packed in PE foil
2	- Transport by sea - Storage up to 6 months in closed hall	- Device to suit transportation - Sharp edges protected - Welded in PE-foil - Drying agent acc. to DIN 55473/55474 - Water-proof cardboard or wooden box - Internal case cover lined with closed webplate (Akylux). Shimmed with PVC-foil in case of joint plates
3	- Transport by sea - Storage up to 12 months in closed hall	- like 2
4	- Transport by sea - Storage up to 24 months in closed hall	- like 2, - instead of PE-foil welded in alu-sandwich foil.

Table 3

Opening of the packing:

Foils, which have been opened for control upon receipt, are to be re-closed airtight for further storage. Use drying agent, if necessary.

Extension of storage period:

The admissible storage period may be extended 3 x maximum. Check and, if need be, replace the packing. Replace external preservation according to the permissible storage period. Realize internal preservation and repeat same annually (In case of packing 4: every 2 years). After replacing the drying agent, close the foil packings airtight.

Repeated preservation is also required, if the turbo coupling is installed in a machine which is not set into operation.

External preservation:

Spray bright metal parts (hub bores, brake discs etc.) with Shell Ensio Fluid S.

Internal preservation:

Moisten the turbo coupling inside with an oil according to selection list.

Turbo coupling mounted: Fill turbo coupling with oil above axis of rotation center and rotate turbo coupling input and output at least once.

Turbo coupling mounted or in mounting position (turbo coupling not turnable):

Fill turbo coupling up to upper fusible plug.

Then drain the oil and close the turbo coupling properly.

The oil may remain in the turbo coupling for other planned represervations if it is ensured that prior to commissioning, the turbo coupling is filled with new oil (oil filling according to design data).

Selection list for internal preservation agents:

Producer	Designation
ARAL	Aral Oel KONIT SAE 20W-20
Mobil	Mobilarm 524 (SAE 30)
Shell	Shell Ensio Motoröl 20 (Standard)
Wintershall	Wintershall Antikorröl 20W-20
The recommended operating fluids are also admitted for preservation	

Table 4

ATTENTION!

When storing couplings type "TW" below 0°C, drain the water! Risk of frost!
Remove flexible parts (item 1820) prior to cleaning the coupling components and applying long-term preservation!



4.3.2 Storage of flexible elements

EX-PROTECTION!

Storage of flexible elements (item 1820) until use in connecting coupling must not exceed 4 years.

The storage area has to be dry and free of dust.

Never store flexible elements (item 1820) together with chemicals, solvents, fuels, acids, etc. Protect them against light with high ultraviolet content.



4.4 Lifting



DANGER!

Slings and lifting of coupling

Improper slinging and lifting of the turbo coupling may cause damage of property and personal injuries!

It is only allowed to lift the coupling at the slinging points provided at the housing top (see the following pictures)!

Lifting appliances, load suspension devices, slinging/lifting points

Pay attention to the turbo coupling weight (see cover sheet)!

Lifting appliances (e.g. crane, high-lift truck), slings (ropes, chains, etc.) and slinging points (swivels, thread size as for item 1830 or 0780, see chapter 6.3) need to be

- checked and approved,
- sufficiently dimensioned and in sound condition and
- only authorized and trained persons are allowed to operate same!

Pay attention to operating manuals of lifting appliances, slings (ropes, chains, etc.) and slinging points!

Damaged load suspension devices or those with insufficient carrying capacity may break under load, with the consequence of most serious or even fatal injuries!

Check the lifting appliances and load suspension devices for

- sufficient carrying capacity (weight see cover sheet),
- sound condition.

Eye bolts are prohibited!

Please use swivels as illustrated on the following pictures!

If a connecting coupling is screwed on, remove same to screw in the swivels.

Proper suspending of a Voith turbo coupling (exemplary):

Remove flexible connecting coupling (if any).

Screw suitable swivel (thread size as for item 1830 or 0780, see chapter 6.3) into the coupling, as shown in the pictures, and attach slings (ropes, chains etc.).

Do not screw out existing screws for this purpose, use provided threads:




Fig. 1

DANGER!

Do not loop the coupling with slings (ropes, chains, etc.) for lifting and turning around!

Do not step under suspended material and pay attention to the general instructions for the prevention of accidents.

Unless the turbo coupling is mounted between driving and driven machine, secure same against tipping over and sliding.

Danger of life and risk of injury caused by falling load, tipping and sliding of the coupling!

For turning the coupling around, suspend it to the slings (ropes, chains etc.) as shown below:




Fig. 2

**DANGER!**

Always use at least 2 slings (ropes, chains etc.) for lifting.

For turning round use 2 slings (ropes, chains etc.) on each side!




Fig. 3




Fig. 4

Place coupling cautiously onto a wooden board or pallet and secure it against tipping over.

4.5 General information with regard to dangerous situations

For all works performed on the turbo coupling, please observe the local regulations for prevention of accidents!

DANGERS!



– **Danger occurring during works performed on the turbo coupling:**

There is the risk of injury by cutting, squeezing and cold burns in case of minus degrees.

Never touch the turbo coupling without wearing protective gloves!

Start to work on the coupling only after it has cooled down below 40 °C otherwise there is the risk of burns!

Ensure that there is sufficient light, a sufficiently big working space and good ventilation when working on the turbo coupling.

Switch off the unit the coupling is installed into and secure the switch against switching on.

For all work performed on the turbo coupling ensure that both, drive motor and driven machine have stopped running and startup is absolutely impossible!

– **Hot surfaces:**

The coupling temperature rises during operation.

Please provide a guard for protection against contact with the coupling! However, ventilation of coupling must not be impaired.

Never use fluids to cool down the coupling!

→ Protective cover see chapter 12

– **Rotating parts:**

Rotating parts, for example, the turbo coupling itself and exposed shaft parts need to be protected against contact by a guard! However, ventilation of coupling must not be impaired.

Never operate the coupling without these guards!

→ Protective cover see chapter 12

– **Noise:**

The turbo coupling generates noise during operation.

If the A-classified equivalent sound pressure level exceeds 80 dB(A) this may cause hearing damage!

Wear ear protection!



→ Sound pressure level see cover sheet

– **Electric shock:**

Contact with open or free terminals, lines and components may cause serious or even fatal injuries!

In the event of a fault even operationally potential-free assemblies may have a respective potential.

– **Overspeed:**

This refers only to installations where overspeed (exceeding the rated speed) is possible:

Check whether the entire system is equipped with a device which safely prevents overspeed (for example brake or back-run safety mechanism).

For rated speed, please refer to cover sheet.

– **Extreme ambient temperatures:**

Extreme ambient temperatures may cause thermal overload of the turbo coupling, which may result in spraying of fusible plugs, seriously injuring persons in its surroundings and damaging the turbo coupling!

For operating medium water:

Ambient temperature must be above freezing point of operating fluid! The frozen operating fluid may damage the coupling.

Adhere to the temperature limits indicated (see Chapter 4.6)!

– **Sprayed-off and discharged operating fluid:**

In the event of thermal overload of the turbo coupling the fusible plugs respond. Operating fluid is discharged through these fusible plugs.

If the fusible plugs spray off, immediately switch off drive!

Electrical devices located near the coupling need to be protected against spraying!

Please ensure that the sprayed-off operating fluid cannot get in contact with persons! Danger of burning!

Persons being in the surrounding of turbo coupling have to wear goggles. Spraying off hot operating fluid means a risk of losing sight!

Make sure that spraying operating fluid cannot get into contact with hot machine parts, heaters, sparks or open flames! There is a risk of fire!

In order to prevent danger (e.g. risk of skidding, risk of fire) caused by escaping oil, remove same immediately!

Catch spraying solder of fusible plugs.

Collect operating fluid leaking out to prevent contact with parts (motor, belt) which might ignite or catch fire.

Please provide a catch pan of sufficient size, if required!



– **Fire hazard:**

After response of fusible plugs the spraying oil may ignite on hot surfaces causing fire, as well as releasing toxic gases and vapor. There is a risk of burning and intoxication, as well as a risk of harm to machines, environment and property.

After response of the fusible plugs, immediately switch off driven machine!

4.5.1 Fire extinguishing means, Fire fighting

In case of fire act as follows:

- Extinguish the fire using **ABC-powder** or **carbon dioxide**.
- **Never use water to extinguish a fire!**
- The minimum distance depends, besides others, on the nozzle diameter, spraying jet or full jet. If a 2"-pipe with nozzle (12 mm) and spraying jet is used the minimum distance is one meter, in case of full jet the minimum distance is five meters.

– **Control of methane content prior to Works on the turbo coupling:**

In order to guarantee safety of works on turbo couplings with housing of aluminium alloy and the guard of which has been removed during underground installation, maintenance and dismounting, the methane content has to be controlled locally using appropriate devices. Prior to starting and during performance of these works the methane content in the area of turbo coupling must not exceed the permissible limit (e.g. 1 Vol.-% in Russia). Should this limit value be exceeded, all works have to be stopped until the local value falls under the limit value again.



4.6 Important information with regard to operation



ATTENTION!

If irregularities are found during operation, immediately switch off the drive unit!

- **Power transmission:**

The cover sheet of this manual shows the possible power transmission at a specific input speed and a specific coupling fill (operating fluid and filling). These values describe a permissible working point for stationary operation of coupling. Voith Turbo's approval is required for stationary operation of coupling at a different working point!

- **Operating fluid:**

Use only the operating fluid shown on the cover sheet of this operating manual.

Operate the turbo coupling only with the filling amount shown on the cover sheet of this operating manual.

A too low filling results in thermal overload of the coupling and, in case of overfill, the coupling may be damaged by internal pressure.



- **Temperature rise at start-up:**

At start-up the temperature rise in the turbo coupling is higher than at stationary operation due to an increased slip. Please provide sufficient intervals between starts to avoid thermal overload!

- **Starting characteristic of turbo couplings with delay chamber:**

At start-up, the operating fluid is delivered from the delay chamber into the turbo coupling working chamber. On standstill, the operating fluid flows back into the delay chamber. Please provide sufficient intervals (a few minutes!) between starts to obtain a correct starting characteristic!

EX-PROTECTION! / ATTENTION!**– Coupling temperature:**

Please consult Voith Turbo, if the turbo coupling should be used for ambient temperatures

- below -25 °C for operating fluid oil
- below 0 °C for operating fluid water (freezing point) !


Please also refer to order documents.

Overheating may damage the coupling!

The nominal coupling temperature will not be exceeded for the planned application as long as sufficient ventilation is provided.

The following applies only to couplings in hazardous areas:

Make sure that the air surrounding the turbo coupling does not exceed the permissible value.



→ Technical Data:
Chapter 1,
page 5

– Fusible plugs:

The fusible plugs protect the turbo coupling against damage due to thermal overload.

Switch off the drive motor immediately on response of one of the fusible plugs!

Use original fusible plugs only with the response temperature shown on the cover sheet of this operating manual!

→ Technical Data:
Chapter 1,
page 5

– Monitoring devices:

Check whether the existing monitoring devices are in a state ready for operation.

Repair any defective monitoring device immediately!

Never bridge safety devices!

→ For monitoring
devices, see
Chapter 18,
page 81

– Blocking:

Blocking of the driven machine may cause overheating of the turbo coupling and response of the fusible plugs thus endangering persons as well as the turbo coupling and environment.

Immediately switch off driven machine!


EX-PROTECTION!

→ Technical Data:
Chapter 1,
page 5

– Overload of the coupling:

On response of the thermal fuse switch off power supply after the time required in Chapter 1 at the latest.

In case of multi-motor-drive switch off the entire system!

If additional monitoring of overload is required, monitor output speed.

If the output speed falls below the input speed by more than 10%, immediately switch off power supply.

It is necessary to switch off the power supply, otherwise the max. surface temperature indicated there cannot be kept



Note!

The coupling will be overloaded in case that

- the driven machine blocks
- the driven machine is loaded excessively during nominal operation or during running-up
(contact Voith Turbo).

→ Connecting couplings:
Chapter 20,
page 100

– Connecting couplings:

Connecting couplings of type EPK:

After breakage (shearing) of a flexible element of the EPK connecting coupling, switch off the drive immediately!

In case of multi-motor drives, switch off the entire system!

We recommend regular control of the wear condition of the pads.

Connecting couplings of types ENK, EEK, Nor-Mex G:

In case of too heavily worn flexible elements, there is the risk of a hitting together of parts of the connecting coupling.

- Fire and explosion hazard by spark formation!
- Danger to life by flying debris!
- Risk of damage on drive and driven machine!



→ Chapter 12,
page 56

4.7 Transportation

EX-PROTECTION!

In potentially explosive atmospheres the coupling is only to be transported in suitable packing. This has to meet the same minimum mandatory requirements as the guard.

WARNING!

Falling parts may seriously injure or kill you!

Secure the coupling sufficiently, pay attention to the center of gravity position and use the provided slinging and lifting points!

Use appropriate transportation means and slings (ropes, chains, etc.)

Incorrect handling of the turbo coupling may cause bruising of upper and lower limbs and seriously injure persons.

Expert staff only is allowed to carry out transportation!



→ Masses:
Cover sheet

4.8 Staff qualification

WARNING!

Personnel not sufficiently qualified is exposed to danger or is dangerous for third parties. Possible consequences can be death, serious or minor injuries, damage of property or harm to the environment.

Only sufficiently trained, instructed and authorized persons are allowed to work on or with the turbo coupling! Keep unauthorized people away!

Qualified experts only are allowed to carry out maintenance and inspection works, trouble shooting and remedial action!



The staff in charge of any work to be done on the coupling must

- be reliable,
- have the legal minimum age,
- be trained, instructed and authorized with regard to the intended work.
- at use in potentially explosive atmosphere observe **EN 1127-1 Annex A** and **EN 1127-1 Section 7**. Only use tools admissible in potentially explosive areas. Avoid sparking.



4.9 Product observation

We are under legal obligation to observe our products, even after shipment. Please therefore inform us about anything that might be of interest to us. For example:

- change in operating data.
- experience gained with the unit.
- recurring problems.
- problems experienced with this installation and operating manual.

→ You will find our
address on
page 9

5 Voith Turbo Couplings with Constant Fill

5.1 Function




Fig. 5

The Voith turbo coupling is a hydrodynamic coupling working to the Föttinger principle. Its main components consist of two blade wheels – the pump impeller and turbine wheel – enclosed by a shell. Both wheels are provided with bearings relative to each other. The power is transmitted nearly without wear, there is no mechanical contact between the power-transmitting parts. A constant amount of operating fluid is in the coupling.

The mechanical energy provided by the drive motors is converted to kinetic energy of the operating fluid in the connected pump impeller. In the turbine wheel this kinetic energy is converted back to mechanical energy.

Three conditions are to be considered with regard to the coupling function:

– **Standstill:**

The total operating fluid is resting statically in the coupling.




Fig. 6




Fig. 7

– Starting condition:

The pump impeller accelerates the operating fluid with increasing motor speed causing a circulating flow in the working chamber. The complete blade chamber of turbine wheel is flooded, starting to move as a result of the kinetic energy of fluid flow. The coupling characteristic determines the torque curve during start-up.




Fig. 8

– Normal operation:

During normal operation only the torque required by the driven machine is transmitted. The low speed difference between pump impeller and turbine wheel (the so-called rated slip) results in a stationary flow condition in the coupling.

5.2 Type designation

For hydrodynamic couplings with constant fill the type designation is determined as follows:

→ **Type designation:**
See cover sheet
of this operating
manual

1	2	3	4	5	6	7	8	9	10	11	12
---	---	---	---	---	---	---	---	---	----	----	----

Example: 562 TVVS03

562	T			VV	S		03			
-----	---	--	--	----	---	--	----	--	--	--

1	Coupling size (profile diameter in mm) possible sizes: 154, 206, 274, 366, 422, 487, 562, 650, 750, 866, 1000, 1150
2	Number of hydrodynamic circuits T: single-circuit coupling DT: double-circuit coupling
3	Material "no code letter": Silumin U: ferrous product
4	Operating fluid "no code letter": mineral oil W: water (for antifreezing compound consult Voith)
5	Delay chamber "no code letter": without delay chamber V: with delay chamber VV: with enlarged delay chamber
6	Draining of delay chamber "no code letter": time-dependent draining without dynamic refill F: with centrifugal valves (standard type open on standstill) Y: with dynamic refill
7	Shell "no code letter": standard design S: designed as annular chamber
8	Turbo coupling connection "no code letter": designed for flexible connecting coupling mounted on the outer wheel side. N: designed for primary coupling flange and flexible connecting coupling mounted on the coupling shaft.
9	Design status "old": A, B, C, E, G, H, J "new": 01, 02, 03, 04, 05, 06, 07, 08, 09, 10, ...
10	Throttle plate "no code letter": without throttle plate D: with throttle plate
11	Design "no code letter": standard design -X: special constructional design -Z: special hydrodynamic design
12	Possible supplementary information in plain text

5.3 Design examples

5.3.1 Connecting coupling on the input side

Type T (basic type):




Fig. 9

Type TV:




Fig. 10

Type TVV:




Fig. 11

Type TVVS:




Fig. 12

Type DT:




Fig. 13

Type DTV:




Fig. 14

5.3.2 Connecting coupling on the output side

Type TN (basic type):




Fig. 15

Type TVN:




Fig. 16

Type TVVN:




Fig. 17

Type TVVSN:




Fig. 18

Installation and Operating Manual 3626-011000 en.
2010-03 / Rev. 8.2 Printed in Germany
Subject to modification due to technical development.

6 Tightening Torques




Fig. 19

- 1) For arrangement and quantity, please refer to tables in Chap. 13.4.
2) From size 366.

6.1 Set screws and fixing bolts

The tightening torque applicable for set screw (item 1845) and fixing bolt (item 0050) depends on its dimension of thread:

Tightening torque in Nm										
Thread	M6	M8	M10	M12	M16	M20	M24	M30	M36	M42
Set screw	4	8	15	25	70	130				
Fixing bolts		23	46	80	195	380	660	1350	2350	3750

Table 5

The tightening torques for set screws apply for property classes to DIN EN 898-5 / ISO 898-5.

Tightening torques of fixing bolts apply to bolts with property class 8.8 or higher (to DIN EN ISO 898-1), oil-moistened and of relevant shaft journal material.

6.2 Fusible plugs, filler plugs, sight glasses, blind- and nozzle screws

Tightening torque in Nm (dimension of thread)					
Coupling size	Fusible plug, item 0395 / 0260	Filler plug, item 0390	Blindscrew, item 0394 / 0265	Sight glass, item 0396	Nozzle screw, item 0455, item 0456
154	8 (M8)	13 (M10)	8 (M8)	– –	– –
206	13 (M10)	20 (M12x1.5)	13 (M10)	– –	– –
274	13 (M10)	30 (M14x1.5)	13 (M10)	– –	– –
366 to 650	50 (M18x1.5)	80 (M24x1.5)	50 (M18x1.5)	50 (M18x1.5)	48 (M16x1.5)
750 to 1150	144 (M24x1.5)	235 (M36x1.5)	144 (M24x1.5)	144 (M24x1.5)	48 (M16x1.5)

Table 6

6.3 Fastening screws

Tightening torque in Nm (dimension of thread)					
Coupling size	Fastening screw ¹⁾ , item 1830 / 0780	Fastening screw ¹⁾ , item 0850	Fastening screw ¹⁾ , item 1660	Socket head screw Nor-Mex G, item 1816 ³⁾	Hexagonal screw ¹⁾ EPK, item 1870
154	9 (M6)	– –	– –	– –	– –
206	23 (M8)	– –	– –	– –	– –
274	68 (M12)	– –	– –	– –	– –
366	68 (M12)	23 (M8)	80 (M12)	49 ¹⁾ (M10)	23 (M8)
422	68 (M12)	23 (M8)	80 (M12)	49 ¹⁾ (M10)	46 (M10)
487	68 (M12)	23 (M8)	80 (M12)	49 ¹⁾ (M10)	46 (M10)
562	68 (M12)	46 (M10)	195 (M16)	125 ²⁾ (M12)	46 (M10)
650	135 (M16)	46 (M10)	380 (M20)	200 ²⁾ (M14)	46 (M10)
750	135 (M16)	68 (M12)	380 (M20)	– –	46 (M10)
866	250 (M20)	68 (M12)	380 (M20)	– –	80 (M12)
1000	250 (M20)	68 (M12)	-- --	– –	80 (M12)
1150	580 (M27)	68 (M12)	-- --	– –	80 (M12)

Table 7

¹⁾ Screws with property class 8.8 or higher (to DIN EN 20898-1 / DIN EN ISO 898-1) are used.

²⁾ Screws with property class 10.9 or higher (to DIN EN 20898-1 / DIN EN ISO 898-1) are used.

³⁾ See Fig. 68, Chapter 20.2.1, page 101.

7 Installation of Basic Coupling Type T

DANGER!

Please observe, in particular, Chapter 4 (Safety) when working on the turbo coupling!



– Outer wheel drive:

The coupling is mounted on the driven machine shaft and then, via a flexible connecting coupling, coupled with the drive motor.

– Inner wheel drive (special case):

The coupling is mounted on the drive motor shaft and then, via a flexible connecting coupling, coupled with the driven machine shaft.

7.1 Tools

EX-PROTECTION!

When using or assembling an Ex-coupling use only tools approved for application in explosion hazardous areas. Avoid sparking!



The list does not claim to be complete, check in detail with assembly plan.

Tools:

Open-end wrench spanner set
 Ring spanner set
 Hexagon socket spanner box (contains hexagon spanners, ratchet etc.)
 Hexagonal recess/allen wrenches (Allan key set)
 Screwdriver
 Torque wrenches
 Hammer, rubber hammer
 File set
 File brush (Wire brush)

→ Dimension of thread see Chapter 6, page 29

Measuring instruments:

Dial gauge with holder
 Caliper gauge
 External micrometer gauge according to shaft-diameter
 Inside micrometer (Bore gauge) according to hub-diameter

→ Dial gauges: Chapter 9.4, page 43

Mounting auxiliaries:

Auxiliaries for alignment of motor and gearbox (fastening screws),
 e.g. shims for motor and gearbox pedestals (0.1 – 0.3 – 0.5 – 1.0 – 3.0mm).
 Grinding cloth, graining 100, 240

Lifting appliances and load suspension devices:

- Crane.
- Two shackles with appropriate slings (ropes, chains etc.) for coupling suspension.
Observe Fig. 20 and 21 on page 34 !
- Adjustable chains or ropes with sufficient tensile strength (see individual weights).

→ Swivel size see Chapter 6.3, page 30 item 1830 for T, item 0780 for TN

7.2 Preparation

→ Fig. 22,
page 35

- Check the length of fixing bolt, if the length of shaft journal, on which the coupling is mounted, changed or was not indicated to Voith Turbo.
- Check radial runout of shaft journals of drive motor and driven machine.
- Clean fitting surfaces on shaft journals and hubs using emery cloth and check fitting dimensions.
- In case of installation, degrease flanges to be screwed.
- Slightly oil screw threads of screws.



EX-PROTECTION!

- Shafts connected to the turbo coupling by means of a flexible connecting coupling must not exceed 80 °C during operation.

- Apply a thin slip additive film to the shaft journals.

Note!

Please use a slip additive with the following characteristics:

- operating temperature range: -20 °C...+180 °C,
- water and wash-out resistant,
- protection against fretting corrosion and corrosion.

- **Proposed slip additive:**

Manufacturer	Designation
Dow Corning	Molykote D Molykote G-Rapid plus Molykote TP 42
Fuchs	gleitmo 815 gleitmo 100 S
Liqui Moly	LM 48
Optimol	PASTE WHITE T PASTE MP 3

Table 8



ATTENTION!

- Keys should be provided with sufficient back clearance, be axially fixed and run smoothly in the keyways.
- Observe that the balancing method is the same for shaft and hub. Our parts are marked to DIN ISO 8821 / ISO 8821:
H: Half key agreement
F: Full key agreement
- When using a shaft-hub connection with one (1) key and balancing to half key agreement, with the key being longer than the hub, reduce or shorten the key accordingly to avoid unbalance.



- Insert the keys.
- Prepare suitable tools and lifting appliances; observe the turbo coupling weight!

→ Lifting appliances:
Chapter 4.4

Note!

The cover sheet indicates the turbo coupling weight. The weight is also stamped on the outer diameter of coupling flange, if it exceeds 100 kg.



WARNING!

Damaged load suspension devices or those with insufficient carrying capacity may break under load, with the consequence of most serious or even fatal injuries!

Check the lifting appliances and load suspension devices for

- sufficient carrying capacity (weight see cover sheet),
- sound condition.



7.3 Mounting



Note!

We recommend to use the **mounting and removal devices**, available at Voith Turbo as accessories from **size 274**.



ATTENTION!

The use of unsuitable working means and methods may cause damage to property.

When mounting the coupling prevent the use of

- pressure plates,
- hammers,
- welding torches.

In case of couplings with operating fluid water the hub bore is provided with solid film lubricant. Do not remove the solid film lubricant!




Fig. 20

- Fix the coupling to a suitable lifting appliance.
- Careful warming-up of the coupling hub (to approx. 80 °C) facilitates coupling mounting.




Fig. 21

- Position the coupling at the relevant shaft journal.
- Insert the holding disk supplied.

Note!

- For couplings up to **size 274** remove the circlip prior to inserting the holding disk and then reinsert it.
- For couplings from **size 366** secure the holding disk by means of a roll pin against rotation.

ATTENTION!

Depending on the design of shaft, the coupling hub must be in contact with the shaft collar or the end face of shaft journal.



Coupling sizes 154 and 206:

- Insert a suitable and slightly oiled threaded rod in the shaft of the relevant machine.
- Mount the coupling on the shaft journal using a nut and a spacer tube.

Coupling sizes 274 up to 1150:

- Oil the mounting spindle slightly.
- Mount the coupling on the shaft journal using the mounting spindle, the spacer tube and the holding disk.

→ Mounting devices:
Chapter 7.4,
page 36




Fig. 22

- Check the proper seat of holding disk. Tighten the fixing bolt using the specified tightening torque.

→ Chapter 6.1,
page 29

EX-PROTECTION! / ATTENTION!

The connecting coupling hub has to be secured axially! Usually this is achieved by means of a set screw pressing on the key. Axial butting to a shaft collar and lock by means of a holding disk and fixing bolt is also possible. Provide a spacer ring between hub and shaft collar, if necessary.



- Fix the hub to a suitable lifting appliance.
- Careful warming up of the connecting coupling hub (to approx. 80 °C) facilitates mounting.
- Mount the flexible connecting coupling hub on the relevant shaft journal.
- Tighten the set screw in the connecting coupling hub, if necessary.
- Move the connecting coupling hub with the relevant machine next to the turbo coupling. Observe correct number and proper seat of flexible elements in the connecting coupling!
- Fix the machine slightly.
- Align the drive.
- Report the mounting (see Chapter 14)
- If the turbo coupling is connected with a flexible pad coupling of type EPK, check that sheet-metal holder (item 1860) and ring (item 1810) do not touch.

→ Chapter 9,
page 40

→ Chap. 20.1.3
page 101

EX-PROTECTION! / ATTENTION!

- Report the mounting (see Chapter 14).



7.4 Mounting devices

The following mounting devices are available at Voith Turbo for turbo couplings of basic type T:




Fig. 23

- | | | | |
|-----------|-----------------------|-------------|--------------------------------------|
| A: | mounting spindle | L1: | total length |
| B: | original holding disk | L2: | length of spacer tube |
| C: | coupling hub | n: | dimension of mounting spindle thread |
| | | SW1: | wrench size across flats |

Coupling sizes	L1	L2	n	SW1
274	520	135	M10	17
			M12	19
			M16	24
			M20	30
366, 422	520	190	M10	17
			M12	19
			M16	24
			M20	30
487, 562, 650, 750	780	245	M16	24
			M20	30
			M24	36
			M30	46
866, 1000, 1150	1150	480	M20	30
			M24	36
			M30	46
			M36	55
			M42	65

8 Installation of Basic Coupling Type TN

DANGER!

Please observe, in particular, Chapter 4 (Safety) when working on the turbo coupling!

**ATTENTION!**

The use of unsuitable working means or methods may cause damage to property.

When mounting the coupling prevent the use of

- pressure plates,
- hammers,
- welding torches.



The application is an **outer wheel drive**. Mount the primary coupling flange on the motor shaft. Then connect the turbo coupling with the primary coupling flange and couple it with the driven machine shaft through a flexible connecting coupling.

8.1 Mounting

→ page 32

- Have tools available according to **Chapter 7.1.**
- Make the necessary preparations according to **Chapter 7.2.**




Fig. 24

- Mount the primary coupling flange on the motor shaft securing it with the relevant set screw in axial direction. Careful warming-up of primary coupling flange (to approx. 80 °C) facilitates mounting.
- Mount the connecting coupling hub on the coupling shaft securing it with the relevant set screw in axial direction.
- Position the turbo coupling in front of the primary coupling flange.
- In the event of **complete balancing**, balancing marks (e.g. 0/0, 1/1, 2/2 etc.) are provided at the outer periphery of turbo coupling and the primary coupling flange. **Observe that these balancing marks match!**



ATTENTION!

Prior to tightening the bolts (item 0780) push the external spigot of turbo coupling manually into internal spigot of primary coupling flange. Do not tighten bolts (item 0780) before the two flange surfaces touch each other without any gap, otherwise there is a risk to damage the centerings!




Fig. 25

- Fix the turbo coupling to the primary coupling flange using the relevant screws (item 0780).
- Insert the flexible element in the connecting coupling hub.

→ Tightening torque:
Chapter 6.3,
page 30

WARNING!

Fix the slings (chains, ropes etc.) only to the drive motor!
Fixing the slings to the coupling may cause damage.



- Move the mounted drive motor/turbo coupling unit next to the driven machine and bolt the drive motor slightly.
- Align the drive.

→ Chapter 9

EX-PROTECTION! / ATTENTION!

- Report the mounting (see Chapter 14, page 67).



9 Alignment



DANGER!

Please observe, in particular, chapter 4 (Safety) when working on the turbo coupling!

9.1 Flexible connecting couplings

- A flexible connecting coupling couples the turbo coupling with a shaft journal.
- Following alignment some misalignment remains between turbo coupling and shaft journal. The flexible connecting coupling absorbs this misalignment..



EX-PROTECTION!

Connecting couplings delivered by Voith meet the requirements for use in potentially explosive atmospheres.

If connecting couplings are used which are not Voith supply, an ex-proof approval is required, otherwise there is a risk of explosion!

9.1.1 Connecting couplings on input side (Outer wheel drive)

Connecting couplings available at Voith Turbo for turbo couplings of basic type T:

Flexible roller coupling
type **ERK**:




Fig. 26

Flexible pad coupling
type **EPK**:




Fig. 27

Flexible element coupling
type **EEK-M**:




Fig. 28

Flexible element coupling
type **EEK-E**:




Fig. 29

Flexible cam coupling
type **ENK-SX**:




Fig. 30

Flexible cam coupling
type **ENK-SV**:




Fig. 31

9.1.2 Connecting couplings on output side (Outer wheel drive)

Connecting couplings available at Voith Turbo for turbo couplings of basic type TN:

Flexible connecting coupling
type **Nor-Mex G**:




Fig. 32

9.2 Laid lengths and type allocations turbo coupling / flexible connecting coupling

Laid lengths L for flexible connecting couplings, as shown in chapter 9.1:

Laid length L in mm							
Coupling size and type	ERK with coupling	EPK	EEK-E	EEK-M	ENK-SX	ENK-SV	Nor-Mex G
154 T...	143 +1	-	-	-	-	-	-
154 DT...	165 +1	-	-	-	-	-	-
206 T...	183 +1	-	-	-	-	-	-
206 DT...	223 +1	-	-	-	110.5 ±1.5	56.5 ±1.5	-
274 T...	255 +1	78 ±1	-	-	158.5 ±2	67 ±2	-
274 DT...	295 +1	78 ±1	159 ±2	67 ±2	158.5 ±2	67 ±2	-
366 T...	-	78 ±1	159 ±2	67 ±2	158.5 ±2	67 ±2	176 ±1
422 T...	-	102 ±1	173 ±2	72 ±2	173 ±2	72 ±2	198 ±1.5
487 T...	-	106 ±1	190 ±2	88 ±2	190 ±2.5	87.5 ±2.5	221 ±1.5
562 T...	-	116 ±1	221 ±2	103 ±2	221 ±2.5	102.5 ±2.5	267 ±2
650 T...	-	152 ±1.5	274 ±2.5	126 ±2.5	274 ±2.5	125.5 ±2.5	310 ±2.5
750 T...	-	163 ±1.5	-	-	276 ±2.5	127.5 ±2.5	-
866 T...	-	189 ±1.5	-	-	-	-	-
1000 T...	-	210 ±1.5	-	-	-	-	-
1150 T...	-	210 ±1.5	-	-	-	-	-
1150 DT...	-	210 ±1.5	-	-	-	-	-

Table 9



ATTENTION!

To avoid any axial constraining forces, it is absolutely necessary to adhere to the laid lengths! Please observe, in particular, displacements due to temperature changes.



EX-PROTECTION!

If shaft ends axially protrude the connecting coupling hub, measure the dimensions to make sure that a distance of 6mm to the turbo coupling is kept.

9.3 Alignment tolerances



EX-PROTECTION!

- Undue misalignments cause material damage.
- It is necessary to meet the values specified for radial and axial runout at all operating conditions.
- Please observe, in particular, displacements due to temperature changes.

Note!

The smaller the radial and angular displacement between turbo coupling and shaft journal the

- higher the lifetime and reliability of the unit,
- the better is smooth running.



Maximum permissible **alignment tolerances** apply to:

- **radial runout** in the radial plane of flexible elements (maximum permissible radial deflection of dial gauge!)
- **axial runout**, measured over the largest connecting coupling diameter (maximum permissible axial deflection of dial gauge!).

Maximum permissible alignment tolerances for the **radial and axial deflection of dial gauge** when using the connecting couplings shown in **chapter 9.1**:

Coupling sizes	Speed range in min^{-1}			
	0...750	750...1200	1200...1800	1800...3600
154 to 274	0.4 mm	0.4 mm	0.3 mm	0.2 mm
366 to 487	0.6 mm	0.4 mm	0.3 mm	0.2 mm
562 to 1150	0.8 mm	0.6 mm	0.4 mm	0.3 mm

Table 10

The values mentioned above describe the maximum permissible **radial and axial deflection of dial gauge**!

ATTENTION!

Observe maximum permissible speed!

Do not exceed maximum permissible speed! You will find maximum permissible speed on the cover sheet of this instruction manual.



→ **Maximum speed:**
See cover sheet

9.4 Alignment

Note!

For alignment support the motor feet using shims or foil sheets. It would be advantageous to use claws with adjusting screws on the foundation for lateral movement of the drive unit.

Alignment methods and its accuracy:

Method	Accuracy
LASER optical	very accurate
dial gauges	accurate
feeler gauge, depth gauge, Caliper gauge	less accurate

Table 11




Suggestions how to fit dial gauges:


Fig. 33




Fig. 34




Fig. 35




Fig. 36

How to proceed:

→ Chapter 7 or 8,
page 31 or 37

- Mount the turbo coupling.
- Align input with output shaft.
- Fix input and output unit on the foundation.

→ Alignment
tolerances:
Chapter 9.3,
page 42

- Check alignment after tightening all screws, correct alignment, if necessary.
Misaligned connecting couplings result in an irregular gap in the periphery.

→ Chapter 14,
page 67

- Document alignment.

10 Operating Fluids

ATTENTION!

- Use only the operating fluid mentioned on the cover sheet of this operating manual.
- Unsuitable operating fluids may damage the turbo coupling permanently!
- Consult Voith Turbo if you want to use an operating fluid not mentioned.



ATTENTION!

Operating fluids are detrimental to health and may pollute the environment. Dispose of used operating fluid via an authorized collecting station in accordance with the national statutory provisions.
Make sure that no operating fluid reaches the sewage system, soil or water!



DANGER!

The operating fluid could spray off from defective components or fusible plugs, seriously injuring persons!

Maintain the turbo coupling regularly!
Experts only are allowed to work on the turbo coupling!



10.1 Requirements to be fulfilled by the operating fluid mineral oil

- Viscosity class ISO VG 32 to DIN 51519 *)
- Starting viscosity less than $15000 \text{ mm}^2\text{s}^{-1}$ (cSt)
- Pourpoint the limit is 4 °C below actual minimum ambient temperature or lower
- Flash point greater than 180 °C and at least 40 °C above nominal response temperature of fusible plugs
- Fire point at least 50 °C above max. surface temperature (see chapter 1)
(only relevant for couplings used in hazardous areas (Ex))
- Resistance to aging aging-resistant refined product
- Compatibility with seals NBR (Nitril-Butadien caoutchouc) and FPM/FKM (fluor caoutchouc)

Advantageous additional qualities

- FE 8: D7.5 / 80-80 Abrasion of rolling elements < 30mg
 Abrasion of cage < 100mg

*) for special cases ISO VG 10 – 46 usable

10.1.1 Usable operating fluids

- Hydraulic oils HLP 32 to DIN 51524, Part 2 ^{*)}
- Lubricating Oil CLP 32 to DIN 51517, Part 3
- Steam turbine oils LTD 32 to DIN 51515, Part 1 ^{*)}
- HD engine oils SAE 10 W
- ATF type A Suffix A (TASA) and type Dexron II, IID, IIE, III, MERCON
- M-891205 and M 921253

^{*)} for special cases ISO VG 10 – 46 usable

10.1.2 Proposed operating fluids

Manu- facturer	Designation	Pour- point in °C	Flash point in °C	Fire point in °C	Class	FE8-test satisfied
Addinol	Hydraulik-Oil HLP 32	-21	195		HLP	
Agip	Agip Oso 32	-30	204		HLP	
	Agip Blasia 32	-29	215		CLP	
Aral	Degol BG 32	-27	200	250	CLP	
Avia	Avia Fluid RSL 32	-27	214	237	HLP	
	Gear RSX 32 S	-33	210	231	CLP	
BP	Energol HLP-HM 32	-30	216		HLP	
Castrol	Hyspin SP32	-28	200		HLP	ja
	Hyspin AWS 32	-27	200		HLP	
CEPSA	HIDROSIC HLP 32	-24	204		HLP	
	EP 125	-30	206		HLP	
ExxonMobil	Nuto H32	-24	212		HLP	
	DTE 24	-27	220		HLP	
	Mobil SHC 524	-54	234	234	HLP	
Fuchs	Renolin MR10	-30	210		HLP	
	Renolin B10	-24	205		HLP	
Klüber	Lamora HLP 32	-18	200		HLP	
Kuwait Petroleum	Q8 Haydn 32	-30	208	232	HLP	
	Q8 Holst 32	-30	208	234	HLP	
Optimol	Hydo MV 32	-38	209	234	HLP	
Ravenol	Hydr.- Oil TS32	-24	220		HLP	
Shell	Tegula V32	-33	211		HLP	ja
SRS - Salzbergen	Wintershall Wiolan HS 32	-24	220	240	HLP	
	Wintershall Wiolan HF 32	-27	200	240	HLP	ja
Texaco	Rando HD 32	-30	196	246	HLP	
Total	Azolla ZS 32	-27	210	220	HLP	

Table 12

The above oil list is a recommendation and does not claim to be complete.



ATTENTION!

- The values mentioned for the pourpoint, flash and fire point are approximate values and data originating from the oil suppliers. These may vary and Voith Turbo will not accept any warranty claims!
Country-specific production of basic oil may result in deviating values.
- In the event of critical applications, we suggest to consult the respective oil supplier!

10.2 Proposed operating fluids for special requirements

Operating fluid for the use in the food industry

Manufacturer	Description	Pourpoint in °C	Flashpoint in °C	Class
Klüber	Summit HySyn FG 32	-45	>230	HLP

Note: The USDA H1-Registration meets the FDA Requirements.

Fire-resistant operating fluid

Supplier	Description	Pourpoint in °C	Flashpoint in °C	Class
Voith Turbo GmbH & Co. KG	HIFluid	-33	305	HFD-U

Note: Voith-HIFluid is a fire-resistant fluid of the viscosity class ISO VG 46 and contains neither chlorinated hydrocarbons nor phosphorus acid ester. The density of the fluid is lower than the density of water.

Biodegradable operating fluid

Supplier	Description	Pourpoint in °C	Flashpoint in °C	Class
Voith Turbo GmbH & Co. KG	EPFluid	-36	230	HEES

Note: Voith-EPFluid is a fast biodegradable fluid of the viscosity class ISO VG 46 to VDMA 24568. The water risk class is 1 and the density of the fluid is lower than the density of water.

10.3 Requirements to be fulfilled by the operating fluid water



ATTENTION!

Water filling is only allowed in a coupling of type TW !

- Seal compatibility..... NBR (Nitril-Butadien caoutchouc)
- pH-value 5...8

The water used should

- be free from an solid particles,
- contain only a low amount of salt,
- should contain only a low concentration of other additives.

10.3.1 Usable operating fluids

Usually these requirements are satisfied by drinking water.

→ You will find the **type designation** of your **turbo coupling** on the **cover sheet** of this operating manual.

10.3.2 Operating fluid water used for turbo couplings with centrifugal valves (types TW...F...)

For turbo couplings with centrifugal valves it is necessary to add a low amount of grease to the water. The grease guarantees permanent function of centrifugal valves. In the as delivered condition the corresponding amount of grease is already in the working chamber of coupling.



ATTENTION!

On refill of turbo couplings with centrifugal valves (types TW...F...) it is necessary to add a low amount of grease to the water!

- Required amount of grease:

Coupling size	366	422	487	562	650	750	866
Amount of grease	80 g	100 g	120 g	150 g	180 g	210 g	240 g

Table 13

- Requirements to be fulfilled by the grease:

Consistency class	2 to NLGI
Thickeners	anorganic thickener (gel), when the added water is non-alkaline
Service temperature	-20...+120 °C
Material compatibility	NBR (Nitril-Butadien caoutchouc)

Table 14

– **Proposed greases:**

Supplier	Designation
Agip	GR NF
Aral	Aralub HTR 2
Autol	PRECIS Bentonit grease
Avia	Aviation 2 EP
BP	Energrease HTG 2
ELF	Staterma Mo 2
ESSO	HT Grease 275
Fuchs	Renogel FHT 2
Klüber	Pentamo GHY 133
Mobil	Mobiltemp SHC 100
Oest	High melting-point grease 4854
Optimol	Optitemp HT 2
Shell	Darina Grease 2
Texaco	Thermatex FRA 1
Total	Caloris 2
Valvoline	High melting-point grease w-k
Wintershall	Wiolub HTF 940

Table 15

The above grease list is a recommendation and does not claim to be complete.

11 Fill, Filling Check and Draining

- The quantity and type of operating fluid used determines the turbo coupling behavior substantially.
- A too large quantity leads to a higher load on the drive motor during start-up and to a higher stall torque.
- A too low filling leads to a higher thermal load of coupling and to a lower stall torque.




DANGER!

Please observe, in particular chapter 4 (Safety) when working on the turbo coupling !



CAUTION!

- Operating fluids may cause irritations or inflammation when in contact with skin and mucous membranes.
- Please always wear protective glasses for any work to be done in connection with the operating fluid!
- Should you get any operating fluid in your eyes, rinse them immediately using a lot of water and consult a physician without delay!
- After you finished your work, clean your hands carefully with soap.
- Begin any work only after the coupling has cooled down to below 40 °C, otherwise there is a risk of burning!



EX-PROTECTION! / ATTENTION!

- Impurities in the operating fluid cause an increased wear of the coupling and bearing damages. Then explosion protection is no longer given. Make sure that any containers, funnels, filling tubes etc., used for filling the coupling, are clean.



ATTENTION!

- Comply with the quantity to be filled in mentioned on the cover sheet.
- Do not overfill! This would lead to an undue high internal pressure in the coupling, which may destroy the coupling.
- Fill and drain the turbo coupling only after it has cooled down.
- Do not mix the different types of operating fluids.
- Use only the operating fluid mentioned on the cover sheet of this operating manual.
- Ensure that the original sealing rings used are in sound condition.



Note!

You will find the tightening torques in chapter 6 from page 29, please observe Fig. 19 on page 29.

11.1 Coupling fill

Note!

- Turbo couplings are delivered without fill.
- The operating fluid included in the scope of supply is shipped in a separate container.



→ **Fill level:**
See cover sheet

11.1.1 How to fill couplings installed in horizontal position

- Couplings of size 154 - 274:
Turn coupling until the filler plug (item 0390) is on top.
- Couplings of size 366 - 1150:
Turn coupling until the filler plug (item 0390) closest to the sightglass (item 0396) is on top.
- Unscrew the filler plug.
- Remove the top fusible plug (item 0395 or item 260) for pressure compensation.
- In the event of a refill of turbo couplings with centrifugal valves and the operating fluid water (types TW...F...) fill in a specified quantity of grease into the coupling working chamber.
- Fill in the specified operating fluid quantity (→ **Chapter 10**) through a fine screen (mesh size $\leq 30\mu\text{m}$) through the filler plug opening.
- Tighten the filler plug.
- If the coupling is provided with a sight glass (item 0396), tighten the fusible plug.

→ **Quantity:** See
Chapter 10.3.2,
page 48

→ **Operating fluid**
and fill quantity
see cover sheet




Fig. 37

- Turn the coupling until the operating fluid is just visible at the sight glass (if available) or until the operating fluid can be seen at the opening of the (still) unscrewed fusible plug, but is not yet leaking out.
- Determine the **number z** of flange screws from the sight glass or fusible plug to the vertical axis. The first screw is the one in counting direction, **after** the intersection line through the sight glass and/or fusible plug.
- For later filling level checks, record the **number z** of screws determined and additionally mark the coupling guard.
- If not yet done, tighten the fusible plug.
- After a test run (with guard!) check the coupling for leaks.

z = _____

→ **Assembly control**
report:
Chapter 14.1,
page 68

→ **Tightening**
torques:
Chapter 6.2,
page 30

11.1.2 How to fill couplings installed in vertical position




Fig. 38

→ The **level check device** is available as **accessory** at Voith Turbo for couplings from **size 366**

- Remove the two top screws (either two fusible plugs or two blind screws).
- Remove the screw plug.
- Fill in the specified operating fluid quantity through a fine screen (mesh size $\leq 30\mu\text{m}$) into a screw opening. The other screw opening is provided for pressure compensation.
- Re-close screw holes on top using the screws (items 0260, 0265, 0394, or 0395). Rotate coupling with nominal speed for a short period of time to let the operating fluid spread regularly.
- Turn out two screws on top once again.
- Fix the level check device to the connection provided for this purpose.
- Provide the level mark at the coupling or guard for later level checks.
- Remove the level check device.
- Tighten the slackened screws.
Tightening torque for the screw plug: **30 Nm** (M14x1.5).
- After a test run (with guard!) check the coupling for leaks.

11.2 Filling check

You will find the **fill rate** provided on the **cover sheet** of this operating manual.

11.2.1 Level check for couplings installed in horizontal position



Note!

- From **size 366** turbo couplings are equipped with a sight glass in the outer wheel; the position of sight glass is marked by an arrow.

- If a sight glass does not exist, turn the coupling until a fusible plug is on top. Then remove this fusible plug.
- Turn the coupling until the operating fluid is just visible at the sight glass or the operating fluid is not yet leaking out at the opening of unscrewed fusible plug.
- Determine the **number z** of flange screws from the sight glass or fusible plug up to the vertical axis. The first screw is the one in counting direction, **after** the intersection line through the sight glass or fusible plug.
- Compare the number of screws determined with the number of screws determined during filling. Please observe the mark additionally provided on the coupling or guard.
- Correct the filled-in quantity in case of any variations!
- If a fusible plug has been unscrewed, retighten the same.
- After a test run (with guard!) check the coupling for leaks.

→ Fig. 37:
page 51

→ Number z:
Chapter 11.1,
page 51

→ Tightening
torques:
Chapter 6.2,
page 30

11.2.2 Level check for couplings installed in vertical position

Note!

- B The level of couplings from **size 366** is checked using a level check device. This level check device is available at Voith Turbo as accessory.
- Couplings up to **size 274** are to be drained for level check and then to be refilled.

→ Fig. 38,
page 52



- Unscrew a top screw (fusible plug or blind screw) for ventilation.
- Remove the screw plug.
- Fit the level check at the connection provided for this purpose.
- Compare the level with the mark provided during filling.
- In case of variations, correct the fill level accordingly!
- Remove the level check device.
- Tighten slackened screws.
Tightening torque for the screw plug: **30 Nm (M14x1.5)**.
- After a test run (with guard!) check the coupling for leaks.

→ Fig. 38,
page 52

→ Chapter 11.1.2,
page 52

11.3 Draining the coupling



ATTENTION!

Improper disposal of operating fluid may cause most severe environmental damage! On disposal please observe the applicable laws and the manufacturers or suppliers instructions!

- Provide suitable containers to collect the operating fluid.

11.3.1 Draining of couplings without delay chamber installed in horizontal position

- Turn the coupling until one fusible plug is at the lowest point.
- Unscrew this fusible plug.
- For venting purposes, remove one filler or fusible plug on the opposite side.
- After draining the coupling, retighten the screws. Only use original sealing.

→ Tightening
torques:
Chapter 6.2,
page 30

11.3.2 Draining of couplings with delay chamber installed in horizontal position

- Turn the coupling until one fusible plug is at the lowest point.
- Unscrew this fusible plug.
- For venting purposes, remove one filler or fusible plug on the opposite side.
- Wait until the coupling working chamber is drained.

Coupling size 274:	Coupling sizes 366 to 1150:
<ul style="list-style-type: none"> ■ Retighten fusible and filler plugs. ■ Switch on drive motor for approximately half a minute to one minute. The operating fluid in the delay chamber drains into the working chamber. Observe the safety regulations! ■ Unscrew the fusible plug again. 	<ul style="list-style-type: none"> ■ Remove nozzle screw (item 0455 / 0456). ■ Turn the coupling until the nozzle screw opening is at the lowest point. ■ Wait until the delay chamber is drained. ■ Tighten the nozzle screw.

Table 16

→ Tightening
torques:
Chapter 6.2,
page 30

- Turn the coupling until the fusible plug opening is at the lowest point.
- After draining the rest out of the coupling working chamber, retighten the screws.

11.3.3 How to drain couplings installed in vertical position

- For venting purposes, remove one blind screw or fusible plug on the top side of coupling.

→ Fig. 38,
page 52

Up to coupling size 274:	From coupling size 366:
<ul style="list-style-type: none"> ■ Unscrew one bottom blind screw or fusible plug. 	<ul style="list-style-type: none"> ■ Remove the connection of level check device.

Table 17

- Retighten screws after draining the coupling.
Tightening torque for the connection: **80 Nm** (M24x1.5).
Tightening torque for the screw plug: **30 Nm** (M14x1.5).

Note!

On account of the design, complete draining is not possible when the coupling is installed!



12 Commissioning




DANGER!

Please observe, in particular, chapter 4 (Safety) when working on the turbo coupling!

Improper commissioning may cause personal injuries, or harm to property and the environment!

Experts only are allowed to perform commissioning, in particular first starting of the turbo coupling!

Secure the installation against unintentional switching on!



EX-PROTECTION! / ATTENTION!

- Check whether the coupling, according to the marking, is approved for use in potentially explosive atmospheres.
- Equip the coupling with a protective cover (e.g. perforated plate, size of holes approx. 10-12 mm). This protective cover needs to be designed to:
 - prevent intrusion of damaging foreign matter (stones, corrosive steels etc.).
 - withstand the impacts to be expected without excessive damages, thus preventing contact of the coupling with the guard. Especially couplings with aluminium surfaces are not to contact corrosive steel or iron parts.
 - catch spraying solder of fusible plugs.
 - collect operating fluid leaking out to prevent contact with parts (motor, belt) which might ignite or catch fire.
 - provide sufficient ventilation to maintain the maximum surface temperature specified.
A perforated plate with 65% hole section enclosing the coupling on all sides does not cause reduction of ventilation (where necessary, consult Voith).
 - guarantee safe distance against hazardous points or situations (DIN EN ISO 13857).
- The turbo coupling is not equipped with insulated ball and roller bearings! Current passage and stray currents are possible from the machines connected (e.g. VFD).
- To avoid static charging or load prevent turbo coupling installation with an insulation on both sides.
- Provide equipotential bonding between input and output.
- Provide units with possible overspeed with a device preventing overspeed safely (for example: brake or back stop).

DANGER!

Loose clothes, long hair, jewelry, rings or loose parts could get stuck and be drawn in or wound up causing serious injuries, damage of the turbo coupling and harm to the environment.

Only work with close clothes!

Fix long hair underneath some headgear!

Do not wear jewelry (e.g. chains, rings etc.)!

Never operate the coupling without protective cover!



ATTENTION!

- Never operate the turbo coupling without operating fluid!
- On account of the type of bearings used for standard turbo couplings size 366, 422, 487, 562, 650, 750, 866, 1000 and 1150 at least one standstill is required within a period of 3 months.
- On account of the type of bearings used for standard turbo couplings size 154, 206 and 274, at least one standstill is required once a week.



EX-PROTECTION! / ATTENTION!

- Check, whether the flexible connecting coupling touches.
- Check reference dimensions of connecting couplings prior to commissioning (see chapter 13.2.1).
- If you use a BTS-Ex to limit the maximum surface temperature, make sure not to exceed the maximum permissible temperature of the turbo coupling when switching on the motor.
- After installation and filling, put the coupling into operation, observe any irregularities.
- Document commissioning (see commissioning report, Chapter 14.2).



→ Technical Data:
Chapter 1,
page 5

EX-PROTECTION! / Note!

- At the periphery the couplings are provided with an identifying mark according to Directive 94/9/EG and EN13463. The identifying mark specifies the potentially explosive atmosphere and the operating conditions permitted.



Example: C €  II 2D c 180°C X

**Note!**

- The turbo coupling may be used for any direction of rotation.
- The direction of rotation of driven machine may be specified! The direction of rotation of motor must be in accordance with the specified direction of rotation of driven machine!
- If the motor is started with star/delta connection, switchover from star to delta connection should be effected after maximum 2...5sec.
- In the event of a multi-motor drive you should determine the load of individual motors. Great differences in motor load may be balanced by an appropriate adjustment of the respective coupling fill levels. **However, do not exceed maximum permissible coupling fill level!**

13 Maintenance, Repair

Definition according to IEC 60079:

Maintenance and Repair: A combination of all activities conducted in order to maintain an object in a condition or to re-condition the article in a way that satisfies the requirements of the respective specification and secures the required functions.

Inspection: An activity containing the careful examination of an object which aims to a reliable statement as to the condition of this object. This examination is performed without disassembly or, if required, with partly disassembly supplemented by measures, such as e.g. measurements.

Visual test: A visual test is an examination which detects visible defects, such as e.g. missing screws or bolts, without using accessive devices or tools.

Short-range examination: An examination, where, in addition to the visual test, also such defects, as e.g. loose screws or bolts, are detected which can only be seen when using accessive devices, such as e.g. mobile stair steps (if required) and tools. Usually short range examinations do not require to open the housing or to electrically disconnect the utility.

Detail test: An examination which, in addition to the aspects of the short range examination, detects such defects, as e.g. loose connections which can only be found by opening the housing and/or by using tools and test devices, if required.

- Only skilled, trained and authorized personnel or persons trained by Voith Turbo are allowed to execute repair measures.
- Components may only be replaced by original spare parts.
- Regularly clean devices used in explosion hazardous areas. The operator specifies the intervals according to ambient conditions at site, e.g. at dust deposit of approx. 0.2...0.5 mm.
- Following maintenance and/or repair re-attach all barriers and notes which have been removed in its original position.

DANGER!

Please observe, in particular, chapter 4 (Safety) when working on the turbo coupling!



Due to improper action and insufficient access persons may fall and be seriously injured!

Care for permanently free access to the turbo coupling!

Death, serious or minor injuries, harm to property or environment may be the consequence of improper servicing and maintenance.

Qualified experts only are allowed to perform servicing and maintenance works!

Switch off the unit the coupling is installed into and secure the switch against switching on.

For all work performed on the turbo coupling ensure that both, drive motor and driven machine have stopped running and startup is absolutely impossible!

Mount all safety casings and safety devices immediately after completion of servicing and maintenance works and check their function!

Maintenance plan:


Time	Maintenance work
Routine inspection every 500 operating hours, every 3 months, at the latest	inspect the unit for irregularities (Visual test: Tightness, noise, vibrations). Check foundation bolts of the installation, if required tighten with specified torque
3 months after commissioning, at the latest, then every year	Check electrical unit for sound condition, if temperature monitoring is required in Chapter 1 (detail examination).
Connecting couplings EEK, ENK, Nor-Mex G: 3 months after commissioning at the latest, then annually, however, after 4000 operating hours at the latest or different to 13.2.2	Check flexible elements (item 1820) for wear and replace them by original spare parts when the wear limit is reached , since metallic contact of the connecting coupling halves may cause sparking. There is hazard of fire and explosion! (see Chapter 13.2 and 20).
Connecting couplings ERK, EPK: 3 months after commissioning at the latest, then annually or different to 13.2.2	Check flexible elements (item 1820) for wear and replace them by original spare parts when the wear limit is reached , since flexible elements may break when worn.
After 3 years or 5 years (in case of ERK and EPK couplings) use	Replace flexible elements by sets of original spare parts.
If mineral oil is used as operating fluid: Every 15000 operating hours	- Change the operation fluid or check it for aging and - Determine remaining servicelife (see records, Chapter 14)! Consult the operating fluid supplier with regard to the permissible values (see Chapter 10 and 11).
on response of a fusible plug	change all fusible plugs and the operating fluid (→ Chapter 13.4). check operating conditions (Chapter 1). check devices provided for temperature monitoring (see Chapter 18 : MTS, BTS(ex), BTM).
In case of impurity	Cleaning (→ Chapter 13.1).
After contact with materials against which NBR (Nitril- Butadien-caoutchouc) and PUR (polyuretane) are not or only partially resistant.	Replace flexible elements by sets of original spare parts.

Table 18

Maintenance works and routine inspections are to be performed according to report. Document maintenance works (report sample see **Chapter 14.3**).

EX-PROTECTION!

The following additional maintenance works are required for ex-proof couplings:



Maintenance intervals	Maintenance work
In case of impurities or a dust layer of max. 5 mm It is the customer's own responsibility to define maintenance intervals in accordance with the ambient conditions	Cleaning (→ Chapter 13.1).
Maintenance interval see chapter 1	Replace roller bearings (see Chapter 13.3.3).

Table 19

EX-PROTECTION!

- Maintenance works according to schedule are required in order to guarantee proper operation in the meaning of Ex protection.
- Remove any combustible dust deposit on the turbo couplings immediately.
- If the unit is not cleaned in regular intervals there is a risk of fire and explosion!
- For perfect coupling ventilation it is necessary to check and clean the protective cover in regular intervals.
- On response of fusible plug cover the opening caused by response immediately or close it, to prevent intrusion of combustible dust into the coupling.



13.1 Outside cleaning

ATTENTION!



- Please observe that the cleaning agent is compatible with the NBR and FPM/FKM sealing materials used!
- Do not use a high-pressure cleaning apparatus!
- Be careful with gaskets. Avoid high pressure water jet and compressed air.
- Clean the coupling with a grease solvent, if required.



13.2 Flexible connecting coupling

13.2.1 Control of flexible elements wear

→ Chapter 9.1,
page 40

Connecting coupling of type ERK, EEK, EPK, Nor-Mex G:	Connecting coupling of type ENK:
	
<ul style="list-style-type: none"> ■ Turn turbo coupling until flexible elements touch without load. ■ Mark opposite points on hub and flange or the 2nd hub. ■ Turn turbo coupling in opposite direction until flexible elements touch without load. ■ Measure distance of markings in peripheral direction at outer diameter of hub or at ring in the area of the outer diameter. ■ Document reference dimension. 	<ul style="list-style-type: none"> ■ Measure driver distance in direction of rotation at the outer diameter of hub. ■ Measure driver distance in direction of rotation at the outer diameter of hub. ■ The reference dimension is the smallest value of both measurements. ■ Document reference dimension.

→ Chapter 14,
page 67

Perm. reference dimensions of flexible connecting couplings in mm

Coupling size	ERK	EPK	EEK-E EEK-M	ENK-SX ENK-SV	Nor-Mex G
154	< 6				
206	< 6			> 14	
274	< 8		< 8	> 14	
366		< 12	< 8	> 15	< 12
422		< 12	< 8	> 16	< 12
487		< 12	< 9	> 16	< 11
562		< 12	< 11	> 13	< 10
650		< 12	< 10	> 13	< 7
750		< 12			
866		< 12			
1000		< 12			
1150		< 12			

Table 20



Note!

Extremely rapid wear of flexible elements might be a sign of **improper alignment!**

13.2.2 Maintenance intervals

If, based on the previous wear, wear of 80% of the table value can be expected until the next control, exchange the flexible elements or shorten the maintenance intervals accordingly.

Consider additional wear on account of changed operating conditions.

ATTENTION!

Realign the unit, if the coupled machines were displaced on replacement of flexible elements.



13.3 Bearings

13.3.1 Bearing lubrication when using mineral oil as operating fluid

Please observe the following in order to guarantee bearing lubrication:

ATTENTION!

- On account of the type of bearing used for standard turbo couplings from size 366, at least one standstill is required within a period of 3 months.
- On account of the type of bearings used for standard turbo couplings up to size 274, at least one standstill is required once a week.



Note!

- Couplings of **all sizes** can be provided with special bearings allowing continuous operation and are filled with a lifetime grease.



13.3.2 Bearing lubrication when using water as operating fluid

The turbo coupling bearings provided for the operating medium water are filled with a lifetime lubricating grease. Subsequent lubrication is not required.

13.3.3 Replacement of bearings / regreasing

EX-PROTECTION!

On overhaul of the turbo coupling, experts ordered by Voith have to replace / regrease the bearings.



→ Replacement of roller bearings:
Chapter 1,
page 5

13.4 Fusible plugs

→ **Nominal response temperature of fusible plugs:**
See cover sheet

- The fusible plugs protect the turbo coupling against damage due to thermal overload.
- When the nominal response temperature is reached, the solder core of fusible plugs melts and the operating fluid escapes.

Fusible plugs are identified by

- the engraved nominal response temperature in °C,
- a color coding:

Nominal response temperature	Color coding
95 °C	without (tinned)
110 °C for operating fluid water	yellow
125 °C	brown
140 °C	red
160 °C	green
180 °C	blue

Table 21



ATTENTION!

- Use original fusible plugs only with the required nominal response temperature (see cover sheet), as well as the required version SSS or SSS-X (see chapter 1)!
- Do not replace any fusible plugs by blind screws!
- Do not alter the arrangement of fusible plugs.
- There is a MTS- or a BTS switching element or a blind screw opposite of the sight glass (position is marked by an arrow).
- Insert a weight-tolerated BTM blind screw opposite to the BTM switching element in order to not create any unbalance.
Do not insert the BTM switching element opposite a light-weight sightglass or blind screw. Risk of unbalance !
- For operating fluid water only fusible plugs with a response temperature of 110 °C are permitted!

→ **Tightening torques:**
Chapter 6.2,
page 30

- After one fusible plug responded, replace all fusible plugs, change the operating fluid.

13.4.1 Fusible plugs in couplings not suitable for usage in potentially explosive atmospheres

Number and position of fusible plugs, blind screw and switching elements for outer wheel drive (inner wheel drive):

Coupling size and type	Outer wheel (item 0300)				Shell (item 0190)		
	Fusible plug	Blind screw	MTS, BTS-BTM ³⁾ -switching element ²⁾	Sight-glass ⁴⁾	Fusible plug	Blind screw	MTS, BTS-switching element ²⁾
	item 0395	item 0394		item 0396	item 0260	item 0265	
154 T...	1 (1 ¹⁾)	- (2)	- (1)	-	- (-)	- (-)	- (-)
154 DT...	2 (2 ¹⁾)	- (2)	- (1)	-	- (-)	- (-)	- (-)
206 T...	1 (1 ¹⁾)	- (2)	- (1)	-	- (-)	1 (1)	1 (-)
206 DT...	2 (2 ¹⁾)	- (2)	- (1)	-	- (-)	- (-)	- (-)
274 T...	1 (1 ¹⁾)	- (2)	- (1)	-	- (-)	1 (1)	1 (-)
274 DT...	2 (2 ¹⁾)	- (2)	- (1)	-	- (-)	- (-)	- (-)
366 T...	- (-)	5 (1)	1 (1)	1	1 (1)	1 (1)	- (-)
422 T...	- (-)	7 (1)	1 (1)	1	2 (2)	- (-)	- (-)
487 T...	- (-)	3 (3)	1 (1)	1	2 (2)	- (-)	- (-)
562 T...	- (-)	3 (3)	1 (1)	1	2 (2)	- (-)	- (-)
650 T...	- (-)	5 (5)	1 (1)	1	3 (3)	1 ⁵⁾ (-)	- (-)
750 T...	- (-)	5 (5)	1 (1)	1	2 (2)	2 (2)	- (-)
866 T...	- (-)	5 (5)	1 (1)	1	3 (3)	1 ⁵⁾ (-)	- (-)
1000 T...	- (-)	3 (3)	1 (1)	1	4 (4)	- (-)	- (-)
1000 TW...	3 (3)	- (-)	- (-)	1	- (-)	4 (4)	1 (1)
1000 DT...	6 (6)	1 (1)	1 (1)	1	- (-)	- (-)	- (-)
1150 T...	- (-)	5 (5)	1 (1)	1	4 (4)	- (-)	- (-)
1150 DT...	8 (8)	3 (3)	1 (1)	1	- (-)	- (-)	- (-)

Table 22

1) Radial arrangement.

2) The MTS, BTS or BTM switching element is inserted instead of a blind screw.

3) The blind screw opposing the BTM has to be replaced by the compensation weight.

4) Position is marked by an arrow.

5) Only for annular chamber (type T...S...).

ATTENTION!

The fusible plugs of couplings type "TW" of size 366, 422, 487, 562, 650, 750, 866 and 1150 are arranged in the outer wheel.

If a brake is used, select the position of the fusible plugs so that they do not spray onto the brake.

Check same and, if need be, exchange the fusible plugs with opposing blind screws.





13.4.2 Fusible plugs in couplings suitable for usage in potentially explosive atmospheres

Number and position of fusible plugs, blind screw and switching elements for outer wheel drive (inner wheel drive):

Coupling size and type	Outer wheel (item 0300)				Shell (item 0190)		
	Fusible plug item 0395	Blind screw item 0394	MTS/BTS-switching element ³⁾	Sight-glass ⁵⁾ item 0396	Fusible plug item 0260	Blind screw item 0265	MTS/BTS-switching element ³⁾
154 T...	1 (1 ¹⁾)	- (2)	-	-	- (-)	- (-)	-
154 DT...	2 (2 ¹⁾)	- (2)	-	-	- (-)	- (-)	-
206 T...	1 (1 ¹⁾)	- (2)	-	-	- (-)	1 (1)	-
206 DT...	2 (2 ¹⁾)	- (2)	-	-	- (-)	- (-)	-
274 T...	1 (1 ¹⁾)	- (2)	-	-	- (-)	1 (1)	-
274 DT...	2 (2 ¹⁾)	- (2)	-	-	- (-)	- (-)	-
366 T...	2 (2)	3 (3)	1	1	- (-)	2 (2)	-
422 T...	4 (4)	3 (3)	1	1	- (-)	2 (2)	-
487 T...	2 (4)	1 (1 ²⁾)	1	1	- (-)	2 (2)	-
562 T...	2 (4)	1 (1 ²⁾)	1	1	- (-)	2 (2)	-
650 T...	3 (2)	2 (3)	1	1	- (-)	3 (3)	-
650 T...S...	3 (2)	2 (3)	1	1	- (-)	4 (4)	-
650 T... ⁴⁾	- (2)	5 (3)	1	1	3 (-)	- (3)	-
650 T...S... ⁴⁾	- (2)	5 (3)	1	1	3 (-)	1 (4)	-
750 T...	2 (-)	3 (5)	1	1	- (2)	2 (-)	-
866 T...	3 (-)	2 (5)	1	1	- (3)	3 (-)	-
866 T...S...	3 (-)	2 (5)	1	1	- (3)	4 (1)	-
866 T... ⁴⁾	- (-)	5 (5)	1	1	3 (3)	- (-)	-
866 T...S... ⁴⁾	- (-)	5 (5)	1	1	3 (3)	1 (1)	-
1000 T...	- (-)	3 (3)	1	1	4 (4)	- (-)	-
1000 DT...	6 (6)	1 (1)	1	1	- (-)	- (-)	-
1150 T...	4 (-)	1 (5)	1	1	- (4)	4 (-)	-
1150 DT...	8 (8)	3 (3)	1	1	- (-)	- (-)	-

Table 23

¹⁾ Radial arrangement.

²⁾ The blind screw has to be inserted in the outer wheel opposite the sightglass (position is marked by an arrow).

³⁾ The MTS or BTS switching element is inserted instead of a blind screw.

⁴⁾ Only valid if a BTS-Ex switch unit is used.

⁵⁾ Position is marked by an arrow.



ATTENTION!

If a brake is used, select the position of the fusible plugs so that they do not spray onto the brake.

Check same. In case of any deviation, consult Voith.



Note!

A thermal monitoring system can prevent that operating fluid is sprayed off (see chapter 18, page 81). Thermal monitoring systems are available at Voith Turbo as accessories.

14 Assembly Control-, Commissioning and Maintenance Report

DANGER!

Please observe, in particular, chapter 4 (Safety) when working on the turbo coupling!




Document all assembly works in the assembly control report (Chapter 14.1).

Document the commissioning in the commissioning report (Chapter 14.2).

EX-PROTECTION! / ATTENTION!

Document any maintenance works of the flexible connecting coupling in the maintenance report for the flexible connecting coupling (Chapter 14.3.1).

Document any maintenance works of the turbo coupling in the maintenance report provided for general maintenance (chapter 14.3).



Use copies of the originals, if necessary.

14.1 Assembly control report

Affirm control or accomplishment of the works by an "X" or enter the required values.

Voith turbo coupling

Size/ type (Chapter 17):
 Serial No. (Chapter 17):
 Coupling approved for hazardous areas yes ☐ / no ☐

Operating fluid of turbo coupling

Fill: ltr.
 Manufacturer:
 Designation:

Motor

Serial-No.
 Input speed rpm
 Rated power kW

Assembly works have been done:

Name:
 Date:
 Signature:

Driven machine / gearbox

Serial-No.



Assembly – control step	Explanations	Completion notice / dimensions
Inspection of fixing bolt length (item 0050)	see order documents	<input type="checkbox"/>
Measure concentricity ¹⁾ of drive machine	Manufacturer's specification	Set: <input type="text"/> [mm] ACTUAL: <input type="text"/> [mm]
Measure diameter ¹⁾ of drive machine	Manufacturer's specification	Set: <input type="text"/> [mm] ACTUAL: <input type="text"/> [mm]
Measure concentricity ¹⁾ of driven machine	Manufacturer's specification	Set: <input type="text"/> [mm] ACTUAL: <input type="text"/> [mm]
Measure diameter ¹⁾ of driven machine	Manufacturer's specification	Set: <input type="text"/> [mm] ACTUAL: <input type="text"/> [mm]
Input (drive) diameter ¹⁾	Chapter 1	Set: <input type="text"/> [mm] ACTUAL: <input type="text"/> [mm]
Output diameter ¹⁾	Chapter 1	Set: <input type="text"/> [mm] ACTUAL: <input type="text"/> [mm]
Back clearance input side key checked (drive side)	Chapter 7.2	<input type="checkbox"/>
Back clearance output side key checked (driven side)	Chapter 7.2	<input type="checkbox"/>
Key runs smoothly in keyway of input hub	Chapter 7.2	<input type="checkbox"/>
Key runs smoothly in keyway of output hub	Chapter 7.2	<input type="checkbox"/>
Input of shaft-hub connection checked. Balancing method corresponds to DIN ISO 8821 and ISO 8821	Chapter 7.2	Method used: <input type="checkbox"/> semi-inserted key <input type="checkbox"/> fully-inserted key
Output of shaft-hub connection checked. Balancing method corresponds to DIN ISO 8821 and ISO 8821	Chapter 7.2	Method used: <input type="checkbox"/> semi-inserted key <input type="checkbox"/> fully-inserted key
Input side shaft and hub cleaned and provided with parting agent	Chapter 7.2	<input type="checkbox"/>
Output side shaft and hub cleaned and provided with parting agent	Chapter 7.2	<input type="checkbox"/>
Connecting coupling hub	Torque	<input type="checkbox"/>
Set screw (item 1845) tightened with torque	Chapter 6.1	<input type="checkbox"/>
Fixing bolt (item 0050) tightened with torque	Torque Chapter 6.1	<input type="checkbox"/>
When installing type TN : Are balancing marks of primary coupling flange in correct position ?	Chapter 8.1	<input type="checkbox"/>
Mounting dimension "L" measured	Chapter 9.2	Set: <input type="text"/> [mm] ACTUAL: <input type="text"/> [mm]

Table 24

¹⁾ Dimensions of shaft or hub to be connected by means of shaft-hub connection.

Assembly – control step	Explanations	Completion notice / dimensions
Foundation bolts tightened	Chapter 9.4	<input type="checkbox"/>
Mounting of coupling Bolts (item 1830) tightened	Chapter 6.3	<input type="checkbox"/>
MTS / BTS / BTM (if required); position checked accord. to operating manual	Chapter 1, 18	<input type="checkbox"/>
MTS / BTS / BTM (if required) tested for electrical function	Chapter 1, 18	<input type="checkbox"/>
Protective system installed accord. to recommendation	Chapter 12	<input type="checkbox"/>
Equipotential bonding between input and output effective	Chapter 12	<input type="checkbox"/>
Coupling filled with operating fluid	Chapter 11	<input type="checkbox"/>
Only for <u>horizontally</u> installed couplings: Screw number "Z" determined for filling	Chapter 11.1	Z= screws
Only for <u>vertically</u> installed couplings: Fill level control device used. Fill level marking attached to coupling.	Chapter 11.1.2	<input type="checkbox"/>
Alignment of turbo coupling checked	Enter alignment values	<input type="checkbox"/>
Concentricity of motor shaft o.k.		<input type="checkbox"/>

Enter alignment values (see Chapter 9.3):

Viewing motor towards driven machine	RADIAL	AXIAL
<p>cross-mark where applicable</p> <p>- data from gauge <input type="checkbox"/></p> <p>data from shaft center displacement <input type="checkbox"/></p> <p>- gauge runs on turbo coupling <input type="checkbox"/></p> <p>gauge runs on machine shaft <input type="checkbox"/></p> <p>- AXIAL values measured on Ø: mm</p>		

Displacements during operation (are to be indicated by unit manufacturer):
Observe displacements resulting from temperature increase or mechanical movement.
Only enter values which may alter values specified above.

- Radial (e.g. different thermal expansion input / output) mm
- Axial (e.g. by angular displacements) mm
- Linear expansion (for mounting tolerance dimension "L", e.g. shaft expansion) mm

Table 25

14.2 Commissioning report

Affirm control or accomplishment of the works by an "X" or enter the required values.

Voith turbo coupling

Size / type (Chapter 17):

Serial No. (chapter 17):

 Coupling approved for hazardous areas: yes ☐ / no ☐
Commissioning was carried out

at

Oper. hrs

Name:

Date:

Signature:

Commissioning – control step	Explanations	Completion notice
Inspections prior to switching on the driving motor:		
Mounting - test steps executed Completed assembly test report, Chap. 14.1	Chapter 14.1	<input type="checkbox"/>
Applies only to coupling used in hazardous areas: Checked whether the coupling, according to marking, is approved for hazardous areas.	Chapter 3.2	<input type="checkbox"/>
Only for horizontally installed couplings: Fill level checked - Screw number "Z" determined for filling	Chapter 11.2	<input type="checkbox"/> / Z= Screws
Only for vertically installed couplings: Fill level control device used. Fill level compared with previously attached fill level marking	Chapter 11.2.2	<input type="checkbox"/> / Difference= mm
A protective cover (properties see Chapter 12) attached around the turbo coupling.	Chapter 12	<input type="checkbox"/>
Checked whether the installation is earthed with a grounding cable (16mm ²).		<input type="checkbox"/>
Applies only to installations where overspeed is possible: Installation equipped with a device which safely prevents overspeed (e.g. brake or back-run safety mechanism).	Chapter 6	<input type="checkbox"/>
Next coupling standstill for maintenance works determined.	Chapter 12	<input type="checkbox"/>
Geprüft, ob es im Bereich der elastischen Verbindungskupplung zu metallischen Berührungen kommt.	Chapter 9.1, Chapter 13.2	<input type="checkbox"/>
Bei den Verbindungskupplungen das Kontrollmaß geprüft.	Chapter 13.2	<input type="checkbox"/>
Applies only to use of a BTS-Ex as temperature monitoring system: On motor switching-on ascertained that the maximum admissible turbo coupling temperature is not exceeded!	Chapter 1	<input type="checkbox"/>
Foundation bolts checked		<input type="checkbox"/>
Inspections during test run:		
Motor run-up is normal		<input type="checkbox"/>
Coupling is tight		<input type="checkbox"/>
Floor and environment checked for oil moistening, oil did not leak		<input type="checkbox"/>
Machine running is normal		<input type="checkbox"/>
Normal noises		<input type="checkbox"/>
Inspections after switching off the driving motor:		
Coupling is tight		<input type="checkbox"/>
Floor and environment checked for oil moistening, oil did not leak		<input type="checkbox"/>
Switching units for temperature monitoring ¹⁾ checked, if applicable		
Visual test done	¹⁾	<input type="checkbox"/>
Dust deposits removed	¹⁾	<input type="checkbox"/>
Electric system checked	¹⁾	<input type="checkbox"/>

Table 26

¹⁾ See separate instruction manual / Chapter 18.

14.3 Maintenance report for general maintenance

Affirm control or accomplishment of the works by an "X" or enter the required values.

Voith turbo coupling

Size / type (Chapter 17):

Serial No. (chapter 17):

Coupling approved for hazardous areas:

 yes ☐ / no ☐
Maintenance works have been done

at

Oper. hrs

Name:

Date:

Signature:

Maintenance – control step	Explanations	Completion notice
Check for irregularities (In intervals of 500 h , every 3 months , at the latest)		
- Coupling is tight Floor and environment checked for oil moistening, oil did not leak		<input type="checkbox"/>
- Machine running is normal		<input type="checkbox"/>
- Normal noises		<input type="checkbox"/>
- Protective cover checked	Chapter 12	<input type="checkbox"/>
- Foundation bolts checked		<input type="checkbox"/>
Switching units for temperature monitoring ¹⁾ checked, if applicable (every 3 months)		
- visual test done	¹⁾	<input type="checkbox"/>
- dust deposits removed	¹⁾	<input type="checkbox"/>
- electric system checked (after 3 months , then every year)	¹⁾	<input type="checkbox"/>
Operating fluid (every 15000 h)		
- Operating fluid checked		<input type="checkbox"/>
- Remaining operating period determined		<input type="checkbox"/> / hours
- Operating fluid exchanged	Chapter 11	<input type="checkbox"/>
Roller bearings (after every interval see chapter 1)		
- roller bearings replaced	Chap. 13.3.3	<input type="checkbox"/>
Coupling cleaned (after every dirt contamination)		
- Cleaned	Chap. 13.1	<input type="checkbox"/>

Table 27

¹⁾ See separate instruction manual / Chapter 18.

14.3.1 Maintenance report for flexible connecting coupling

Affirm control or accomplishment of the works by an "X" or enter the required values.

Voith turbo coupling

Size / type (Chapter 17):

Serial No. (chapter 17):

Coupling approved for hazardous areas:

 yes ☐ / no ☐
Maintenance works have been done

at

Oper. hrs

Name:

Date:

Signature

Installed flexible connecting coupling (see cover sheet):

	ERK	EPK	EEK-E EEK-M	ENK-SV ENK-SX	Nor-Mex G
Replace flexible elements after max [months]	60	60	36	36	36
perm. refer. dimension (see chapter 13.2.1):					
80% value [mm]					

Maintenance works		EEK, ENK, Nor-Mex G					
		ERK, EPK connecting couplings					
Maintenance work		Commissioning new flex. element	Control, replace, if nec.	Control, replace, if nec.	Control, replace, if nec.	Control, replace, if nec.	Control, replace, if nec.
Operating period [months]		0	3	12	24	36	48
Flex. element 1 (New condition)	Actual ref. dimension						
	Name						
	Date						
	Signature						
Reduced operating period [months] (see chapter 13.2.2)							
Flex. element 2 (1 st exchange)	Actual ref. dimension						
	Name						
	Date						
	Signature						
Reduced operating period [months] (see chapter 13.2.2)							
Flex. element 3 (2 nd exchange)	Actual ref. dimension						
	Name						
	Date						
	Signature						
Reduced operating period [months] (see chapter 13.2.2)							

Table 28

15 Coupling Disassembly

DANGER!

Please observe, in particular, chapter 4 (Safety) when working on the turbo coupling!



Unauthorized or unintentional switching on of the machine may cause most serious, even lethal injuries !

Before you start working on the turbo coupling, switch off the main switch of the drive motor and secure same against switching on.

For all work performed on the turbo coupling ensure that both, drive motor and driven machine have stopped running and startup is absolutely impossible!

Note!

This section describes the disassembly of turbo couplings of **basic type T**. Couplings of **basic type TN** are disassembled in reverse order according to **chapter 8, page 37**.



15.1 Preparation

- Prepare suitable tools and lifting appliances; observe the turbo coupling weight!

Note!

The cover sheet indicates the turbo coupling weight. The weight is also stamped on the outer diameter of coupling flange, if it exceeds 100 kg.



WARNING!

Damaged load suspension devices or those with insufficient carrying capacity may break under load, with the consequence of most serious or even fatal injuries!



Check the lifting appliances and load suspension devices for

- sufficient carrying capacity (weight see cover sheet),
- sound condition.

- Fix the coupling to a suitable lifting appliance.

→ Lifting appliances:
Chapter 4.4

15.2 Removal



Note!

We recommend to use the **mounting and removal devices** for removal of turbo couplings, these are available as accessories from Voith Turbo for couplings from size 274.

Coupling size 154 and 206:

- Remove the fixing bolt.
- Remove the coupling by inserting a suitable and slightly oiled screw into the internal thread of holding disk.

→ Removal devices:
Chapter 15.3
and 15.4




Fig. 39

Coupling size 274:	Coupling sizes 366 to 1150:
<ul style="list-style-type: none"> ■ Remove circlip, fixing bolt and holding disk. ■ Put the threaded ring, supplied together with the removal device, into the coupling hub. ■ Secure the threaded ring using the circlip. ■ Apply a lubricant to the thread of puller spindle. ■ Insert the puller spindle in the internal thread of threaded ring. 	<ul style="list-style-type: none"> ■ Remove fixing bolt and holding disk. ■ Apply lubricant to the thread of puller spindle. ■ Insert the puller spindle in the thread of coupling hub.

Table 29

- Support the puller spindle by a substructure.
- Remove the coupling using the puller spindle.

15.3 Mechanical removal devices

Mechanical removal devices available at Voith Turbo for turbo couplings of basic type T:




Fig. 40

- A: puller spindle
- C: coupling hub
- L: total length
- Q: dimension of thread of puller spindle
- SW: wrench size across flats

Coupling sizes	L	Q	SW
274	360	G ¾	36
366	350	G 1	46
422, 487	460	G 1-¼	55
562, 650	650	G 1-½	60
750, 866, 1000, 1150	1000	G 2-¼	55

Table 30

Note!

To facilitate removal, Voith Turbo has **hydraulic removal devices** available for couplings from **size 422**.



→ Hydraulic removal devices:
Chapter 15.4,
page 76

15.4 Hydraulic removal devices

Hydraulic removal devices available at Voith Turbo for turbo couplings of basic type T:




Fig. 41

A:	puller spindle	L:	total length
C:	coupling hub	Q:	dimension of thread of puller spindle
D:	thrust bolt	SW1:	wrench size across flats (spindle)
H:	stroke	SW2:	wrench size across flats (thrust bolt)
K:	piston		

Coupling sizes	L	H	Q	SW1	SW2
422, 487	406	15	G 1-¼	36	24
562, 650	580	15	G 1-½	36	—
750, 866, 1000, 1150	1141	15	G 2-¼	36	36

Table 31

How to proceed:

1. Remove thrust bolt (D).
2. Apply lubricant to the thread of puller spindle (A) and to the thread of thrust bolt (D).
3. Screw puller spindle (A) via hexagon SW1, up to the stop, in the thread of coupling hub (C).
4. Support puller spindle (A) by a substructure.



WARNING!

If dimension 5 mm is undercut, there is the risk of thread wearout (thread seizing).

The pressure chamber of the hydraulic removal device is under high pressure and must not be opened!

5. Insert thrust bolt (D), stop 5mm before the limit stop.
6. Remove thrust bolt (D).
7. Screw puller spindle (A) via SW1 hexagon, up to the stop, into the thread of coupling hub (C).
8. Repeat steps 4 to 7 until the puller spindle moves in easily, then remove it through SW1

16 Malfunctions – Remedial Action

DANGER!

Please observe, in particular, chapter 4 (Safety) when working on the turbo coupling!



The following table is intended to help finding the cause of failures or problems quickly and to take remedial action, if necessary.

Malfunction	Possible cause(s)	Remedial action	
Starting behavior of driven machine is not as expected.	Coupling is not filled with the correct quantity of operating fluid.	Check and correct the quantity filled in.	→ Chapter 11, page 50 pp.
	The operating conditions have changed.	Consult Voith Turbo ¹⁾ .	
Driven machine does not reach the specified speed.	Driven machine is blocked or overloaded.	Eliminate blocking or the cause of overload.	→ Chapter 11, page 50 pp.
	Coupling is not filled with the correct quantity of operating fluid.	Check and correct the quantity filled in.	
Drive motor does not reach normal operation within the expected time.	Changeover from star to delta too late.	Changeover from star to delta should be effected after 2...5s, at the latest.	
	Drive motor is electrically or mechanically not in order.	Have the drive motor checked by authorized personnel.	
Operating fluid leaks out of the coupling	A fusible plug responded due to overload (excess temperature).	Clarify the overload cause. Replace all fusible plugs and change the operating fluid.	→ Chapter 13.4, page 64
	The coupling is leaking.	Eliminate the leak, check, in particular, tightening torques and seal rings of fusible and filler plugs as well as sight glasses and, if necessary, check the switching element of thermal switch unit. If you should not be able to eliminate the leak, please consult Voith Turbo ¹⁾ .	

Malfunction	Possible cause(s)	Remedial action	
An existing thermal switch unit (MTS, BTS or BTM) responded.	The coupling was overloaded.	Clarify the cause for coupling overload and avoid further overload. Check and correct the fill level.	→ Chapter 18, page 81 → Chapter 11.2, page 52
	Thermal monitoring unit (MTS, BTS or BTM) is defective.	Check monitoring unit	→ Chapter 18, page 81
Uneven running of the unit. (increased vibration)	Foundation fixing is loose.	Retighten foundation fixing. Align the unit.	
	The unit is not aligned.	Align the unit.	→ Chapter 9, page 40
	Unit is not balanced.	Clarify the cause and eliminate unbalance.	
	Flexible elements of connecting coupling are defective.	Replace the flexible elements in sets. Align the unit, if necessary.	→ Chapter 13.2, page 62
	Bearings are damaged.	Eliminate the bearing damage; consult Voith Turbo ¹⁾ in the event of a bearing damage on the turbo coupling.	
	Loose screw connections	Check coupling components for damages, replace same, if necessary. Check unit alignment. Fasten screws and bolts with specified tightening torque.	

Please consult Voith Turbo ¹⁾ in the event of a malfunction which is not included in this table.

Table 32

¹⁾ see chapter 17, page 80.

Malfunction	Possible cause(s)	Remedial action
Premature wear of flexible element	Alignment error	Eliminate cause for alignment error. Align unit again. Check wear of flexible elements.
	Impermissible temperatures	Eliminate cause for excessive temperature. Replace flexible element. Align unit again, if necessary.
	Contact with aggressive media.	Check coupling components for damages, replace same, if necessary. Replace flexible elements Align unit again, if necessary. Eliminate cause for contact with aggressive media.
	Excessive torque.	Eliminate cause for excessive torque. Check fill level.
Roller wear / breakage of connecting coupling EEK, ENK, Nor-Mex G	Flexible elements worn	Replace damaged coupling components. Align unit again. Shorten maintenance intervals
	Excessive torque	Check coupling design. Consult Voith Turbo ¹⁾ . Install new coupling. Align unit again.

→ Chapter 11.2,
page 52

Please consult Voith Turbo ¹⁾ in the event of a malfunction which is not included in this table.

Table 33

¹⁾ see chapter 17, page 80.

17 Queries, Orders placed for Service Engineers and Spare Parts

In the event of

- queries
 - orders placed for service engineers
 - spare parts orders
- we need...




Fig. 42

...the **serial number** and type designation of turbo coupling.

- You will find the **serial number** and type designation either on the **outer wheel / shell (A)** or at the coupling **periphery (B)**.
- The **serial no.** is marked with figure stamps.
- for couplings to be used in potentially explosive atmospheres, you will find the **Ex-identification** at the coupling **periphery (B)**.

If an **order is placed for a service engineer** we need, in addition,

- the turbo coupling site,
- the address of a contact person,
- details of the occurred problem.

In the event of a **spare parts order** we need, in addition,

- the destination of spare parts shipment.

Please contact:

Voith Turbo GmbH & Co. KG

Voithstr. 1

74564 Crailsheim, Germany

Tel. +49 7951 32-1881

Fax. +49 7951 32-480

startup.components@voith.com

Outside business hours:

Voith Turbo GmbH & Co. KG

Tel. +49 7951 32-1666

Fax. +49 7951 32-903

coupling-service@voith.com

www.voith-coupling-service.com

18 Temperature Monitoring

EX PROTECTION!

The thermal switching elements MTS and BTS may be used in potentially explosive areas to monitor the temperature. The signals indicate pre-alarm. MTS and BTS do not limit the maximum surface temperature.

BTS-Ex is available as safety element for limitation of the maximum surface temperature and can be used as thermal switch-off device.

In this case, too, never replace the existing fusible plugs by fusible plugs with different nominal response temperatures or by blind screws.

Never override safety devices!



DANGER!

Electric voltages may kill or severely injure you!

An electric expert has to properly carry out the connection to the electric supply network in consideration of both the system voltage and the maximum power consumption!

The system voltage has to be in conformity with the system voltage indicated on the nameplate!

There has to be a corresponding electric fuse on the network side!



18.1 MTS mechanical thermal switch unit for pre-warning




Fig. 43

Function:

On excess temperature, the switching element releases a pin. During rotation, the pin activates a switch. This signal, for example, may trip an alarm or switch off the drive motor. The switching element needs to be replaced.



→ Operating manual 3626-011800 is available for MTS (see web page).

ATTENTION!

In case of inner wheel drive and blocking of driven machine, the function is no longer guaranteed!



The MTS is available for turbo couplings of all sizes.
For arrangement, please refer to table in **Chapter 13.4.1**.
The switch is available in two designs:

- enclosed [degree of protection IP 65],
 - suitable for use in potentially explosive atmospheres
- type of protection:  II 2G EEx d IIC T6 (PTB 03 ATEX 1067 X).
 II 2D IP65 T 80°C (PTB 03 ATEX 1067 X).

18.2 BTS non-contacting thermal switch unit

18.2.1 BTS non-contacting thermal switch unit for pre-warning

→ Operating Manual
3626-011500 is
available for BTS
(see web page).




Fig. 44

Function:

On excess temperature, the switching element gives a specific signal to the initiator. This signal is transferred to an evaluator and may, for example

- trip an alarm
- or switch-off the drive motor.

After cooling-down of the coupling, the switching element is ready for service again, it does not have to be replaced.

The BTS is provided for turbo couplings from **size 206**.

For arrangement, please refer to table in **Chapter 13.4.1**.

Switching element and initiator are

- cast in plastic,
 - insensitive to dirt,
 - suitable for use in potentially explosive atmospheres
- type of protection: Ex II 2G EEx ia IIC T6 (PTB 00 ATEX 2048 X).
 Ex II 1D Ex iaD 20 T...°C (ZELM 03 ATEX 0128 X).



EX PROTECTION!

Since the control circuit of evaluator is not intrinsically safe, provide an appropriate isolating switch amplifier between evaluator and initiator!

Isolating switch amplifier type KFD2-SOT2-Ex2 (24 V DC)

- type of protection: Ex II (1) GD [EEx ia] IIC (PTB 00 ATEX 2035).

Isolating switch amplifier type KFA6-SOT2-Ex2 (230 V AC)

- type of protection: Ex II (1) G [EEx ia] IIC (PTB 98 ATEX 2164).

18.2.2 BTS-Ex non-contacting thermal switch unit for limiting the maximum surface temperature




Fig. 45

Function:

On excess temperature, the switching element gives a specific signal to the initiator. This signal is transferred to an isolating switch amplifier and has to enforce switch-off of the drive motor.

Use a BTS-Ex approved by Voith for this application.

After cooling-down of the coupling, the switching element is ready for service again, it does not have to be replaced.



EX-PROTECTION!

→ Observe separate operating manual 3626-019600 of BTS-Ex! (see web page).

The BTS-Ex is provided for turbo couplings from size 366.

For arrangement, please refer to table in Chapter 13.4.2.

The BTS-Ex is provided to be used in potentially explosive atmospheres as per Directive 94/9/EC in Device Group II, Device Category 2G and 2D (Ex II 2GD).

EX-PROTECTION!

The BTS-Ex for limiting the maximum surface temperature is approved with the components supplied by Voith according to BTS-Ex operating manual, only. Use of original Voith spare parts is imperative in case of replacement.

The evaluator serves to transmit control commands from potentially explosive atmospheres into non-explosive areas and to safely isolate intrinsically safe and non-intrinsically safe circuits.

Make sure not to exceed the maximum permissible temperature of turbo coupling when switching on the motor.



→ Technical Data: Chapter 1, page 5

18.3 BTM non-contacting thermal measuring unit for pre-warning

→ Operating Manual 3626-019800 is available for BTM (see web page).




Fig. 46

Function:

The temperature sensor permanently transmits a measuring signal to the antenna. This signal is forwarded to an evaluator with 4 channels.

The measured temperatures of every channel are indicated on the evaluator. In addition, the measured temperatures are output as 4-20 mA-signals.

Furthermore, two relay outputs are available per measuring channel with switching thresholds (e.g. prewarning, tripping) adjustable via the keyboard on the evaluator.

The BTM is provided for turbo couplings from size 366.

For arrangement, please refer to table in Chapter 13.4.1.



DANGER!

The BTM is not provided for use in potentially explosive areas as per Directive 94/9/EC.

- Blank page -

19 Spare Parts Information

Considering the great variety, please find in the following only the basic turbo coupling designs with constant fill.



Notes!

– **Spare parts:**

Spare parts must comply with the requirements determined by Voith.

This is guaranteed when original spare parts are being used.

Installation and/or use of non-original spare parts may negatively change the mechanical properties of the **Voith Turbo coupling** and thus have an adverse impact on the safety.

Voith is not liable for damages resulting from use of non-original spare parts.

- You will find the type of your turbo coupling on the cover sheet of this operating manual.
- If the scope of supply includes a flexible connecting coupling, you will also find the type of flexible connecting coupling on the cover sheet of this operating manual. Please find the allocation alternatives of turbo coupling and flexible connecting coupling in **chapter 9.2**.
- Please observe **chapter 5.2** (Type designation) and **17** (Queries, Orders placed for Service Engineers and Spare Parts).



EX-PROTECTION!

If the coupling is used in potentially explosive atmospheres (as per Directive 94/9/EC), then only use of original parts is allowed which are released for use in hazardous areas.



DANGER!

Do not modify or retrofit the coupling on your own authority!

Do not retrofit using equipment or utilities of other manufacturers!

Modifications or conversions without preceding written approval of M/s Voith will result in the loss of warranty!

Please observe, in particular, chapter 4 (Safety) when working on the turbo coupling!



ATTENTION!

A professional overhaul or repair can only be guaranteed by the manufacturer!

19.1 Spare parts for type 154 T




Fig. 47

19.2 Spare parts for types 206 - 274 T




Fig. 48

Example for
connecting coupling
type **ERK**.

→ Connecting
couplings:
Chapter 20,
page 100

1) Not shown!

Installation and Operating Manual 3626-011000 en.
 2010-03 / Rev. 8.2. Printed in Germany.
 Subject to modification due to technical development.

Screws and Standard parts				Wearing parts				Coupling main parts			
Pos.- Nr.	Description	154 T	206 274 T	Pos.- Nr.	Description	154 T	206 274 T	Pos.- Nr.	Description	154 T	206 274 T
0050	Fixing bolt	x	x	0130	Grooved ball bearing	x	x	0040	Coupling hub	x	x
0070	Circlip	x	x	0170	Radial shaft seal ring	x	x	0080	Holding disk	x	x
0230	Filler plug		x	0395	Fusible plug	x	x	0090	Inner wheel	x	x
0265	Blind screw		x	0545	Flat seal	x	x	0190	Shell	x	x
0390	Filler plug	x	x	0660	Flexible element	x	x	0300	Outer wheel	x	x
1845	Set screw	x						0670	Hub	x	x

19.3 Spare parts for types T and TN




Fig. 49

Installation and Operating Manual 3628-01/000 en.
2010-03 / Rev. 8.2 / Printed in Germany
Subject to modification due to technical development.

19.3.1 Spare parts for types 366 - 1150 T




Fig. 50

Upper Part:
Representation
exemplary with
connecting coupling
type **EPK**.

Lower Part:
Representation
exemplary with
connecting coupling
type **EEK-E**.

19.3.2 Spare parts for types 366 - 650 TN




Fig. 51

→ Connecting
couplings:
Chapter 20,
page 100

1) For arrangement and quantity, please refer to tables in **Chapter 13.4**.

2) Only for continuous operation or operating fluid water (TW...).

Screws and Standard parts				Wearing parts				Coupling main parts			
Item-No.	Description	T	TN	Item-No.	Description	T	TN	Item-No.	Description	T	TN
0050	Fixing bolt	x		0130	Grooved ball bearing	x	x	0040	Coupling hub / -shaft	x	x
0265	Blind screw	x	x	0140	Grooved ball bearing	x	x	0080	Holding disk	x	
0390	Filler plug	x	x	0160	Radial shaft seal ring	x	x	0090	Inner wheel	x	x
0394	Blind screw	x	x	0165	Radial shaft seal ring	x	x	0100	Rivet-/screw-/clamping ring	x	x
0396	Sight glass	x	x	0170	Radial shaft seal ring	x	x	0190	Shell	x	x
0780	Hexagon Screw		x	0175	Radial shaft seal ring	x	x	0300	Outer wheel	x	x
1830	Hexagon Screw	x		0210	Tolerance ring	x	x	0770	Primary coupling flange		x
1845	Set screw	x	x	0260	Fusible plug	x	x	0830	Sealing ring cover	x	x
				0320	Tolerance ring	x	x	0990	Connecting cover	x	x
				0395	Fusible plug	x	x	1800	Hub	x	
				0545	Flat seal	x	x	1810	Ring / Flange	x	
				0820	O-ring	x	x				
				0994	Flat seal	x	x				
				1820	Flexible element	x					

- blank page -

19.4 Spare parts for types 274 TV/TVV




Fig. 52

→ Example of connecting coupling type **ENK-SV**.

→ Connecting couplings:
Chapter 20,
page 100

Screws and Standard parts				Wearing parts				Coupling main parts			
Pos.-Nr.	Description	274 TV	274 TVV	Pos.-Nr.	Description	274 TV	274 TVV	Pos.-Nr.	Description	274 TV	274 TVV
0050	Fixing bolt	x	x	0130	Grooved ball bearing	x	x	0040	Coupling hub	x	x
0070	Circlip	x	x	0170	Radial shaft seal ring	x	x	0080	Holding disk	x	x
0230	Filler plug	x	x	0395	Fusible plug	x	x	0090	Inner wheel	x	x
0265	Blind screw	x	x	0545	Flat seal	x	x	0190	Shell	x	x
0390	Filler plug	x	x	0994	Flat seal	x	x	0300	Outer wheel	x	x
1830	Hexagon Screw	x	x	1820	Flexible element			0410	Delay chamber	x	x
1840	Spring washer	x	x					1800	Hub	x	x
1845	Set screw	x	x					1810	Ring / Flange	x	x

19.5 Spare parts for types TV/TVV and TVN/TVVN




Fig. 53

Installation and Operating Manual 3625-011000 en.
2016-03 / Rev. 8.2 / Printed in Germany
Subject to modification due to technical development.


19.5.1 Spare parts for types 366 - 1150 TV/TVV


Fig. 54

Representation
exemplary with
connecting coupling
type **EPK**.


19.5.2 Spare parts for types 366 - 650 TVN/TVVN


Fig. 55

Upper Part:
Flange design 1
(Long laid length)

Lower Part:
Flange design 2
(Short laid length)
For type TVVN only.

→ Connecting
couplings:
Chapter 20,
page 100

1) For arrangement and quantity, please refer to tables in **Chapter 13.4**.

2) Only for continuous operation or operating fluid water (TW...).

3) For type T...F... only, not shown as illustration!

4) For sizes 366 and 422 inserted in delay chamber groove.

5) In case of not ex-proof coupling: Set screw optional for connecting couplings ENK-SV, ENK-SX and EPK.
For ex-proof coupling: Set screw is standard

Screws and Standard parts				Wearing parts				Coupling main parts			
Pos.- Nr.	Description	TV TVV	TVN TVVN	Pos.- Nr.	Description	TV TVV	TVN TVVN	Pos.- Nr.	Description	TV TVV	TVN TVVN
0050	Fixing bolt	x		0130	Grooved ball bearing	x	x	0040	Coupling hub / -shaft	x	x
0265	Blind screw	x	x	0140	Grooved ball bearing	x	x	0080	Holding disk	x	
0390	Filler plug	x	x	0160	Radial shaft seal ring	x	x	0090	Inner wheel	x	x
0394	Blind screw	x	x	0165	Radial shaft seal ring	x	x	0100	Rivet-/screw-/clamping ring	x	x
0396	Sight glass	x	x	0170	Radial shaft seal ring	x	x	0190	Shell	x	x
0455	Nozzle screw	x	x	0175	Radial shaft seal ring	x	x	0300	Outer wheel	x	x
0780	Hexagon Screw		x	0210	Tolerance ring	x	x	0410	Delay chamber	x	x
1830	Hexagon Screw	x		0260	Fusible plug	x	x	0770	Primary coupling flange		x
1845	Set screw		x	0320	Tolerance ring	x	x	0800	Bearing support cover	x	x
1870	Hexagon Screw	x		0395	Fusible plug	x	x	0830	Sealing ring cover	x	x
1880	Spring washer	x		0510	O-ring	x	x	1000	Valve insert (Type T...F...)	x	x
				0820	O-ring	x	x	1800	Hub	x	
				0545, 0994	Flat seal	x	x	1810	Ring / Flange	x	
				1820	Flexible element	x		1860	Sheet-metal holder	x	

19.6 Spare parts for types TVVS and TVVSN




Fig. 56

Installation and Operating Manual 3626-011000 en.
2010-03 / Rev. 8.2. Printed in Germany.
Subject to modification due to technical development.


19.6.1 Spare parts for types 422 - 1150 TVVS


Fig. 57

Upper Part:
Representation
exemplary with
connecting coupling
type ENK-SV.

Lower Part:
Representation
exemplary with
connecting coupling
type ENK-SX.


19.6.2 Spare parts for types 422 - 650 TVVSN


Fig. 58

Upper Part:
Flange design 1
(Long laid length)

Lower Part:
Flange design 2
(Short laid length)

→ Connecting
couplings:
Chapter 20,
page 100

1) For arrangement and quantity, please refer to tables in **Chapter 13.4**.

2) Only for continuous operation or operating fluid water (TW...).

3) For type T...F... only, not shown as illustration!

4) For size 422 inserted in delay chamber groove.

5) In case of not ex-proof coupling: Set screw optional for connecting couplings ENK-SV, ENK-SX and EPK.
For ex-proof coupling: Set screw is standard

Screws and Standard parts				Wearing parts				Coupling main parts			
Pos.- Nr.	Description	TVV- S	TVV- SN	Pos.- Nr.	Description	TVV- S	TVV- SN	Pos.- Nr.	Description	TVV- S	TVV- SN
0050	Fixing bolt	x		0130	Grooved ball bearing	x	x	0040	Coupling hub / -shaft	x	x
0265	Blind screw	x	x	0140	Grooved ball bearing	x	x	0080	Holding disk	x	
0390	Filler plug	x	x	0160	Radial shaft seal ring	x	x	0090	Inner wheel	x	x
0394	Blind screw	x	x	0165	Radial shaft seal ring	x	x	0100	Rivet-/screw-/clamping ring	x	x
0396	Sight glass	x	x	0170	Radial shaft seal ring	x	x	0190	Shell	x	x
0455	Nozzle screw	x	x	0175	Radial shaft seal ring	x	x	0300	Outer wheel	x	x
0780	Hexagon Screw		x	0210	Tolerance ring	x	x	0410	Delay chamber	x	x
1830	Hexagon Screw	x		0260	Fusible plug	x	x	0770	Primary coupling flange		x
1840	Spring washer	x		0320	Tolerance ring	x	x	0800	Bearing support cover	x	x
1845	Set screw	x	x	0395	Fusible plug	x	x	0830	Sealing ring cover	x	x
				0510, 0820	O-ring	x	x	1000	Valve insert (Type T...F...)	x	x
				0545, 0994	Flat seal	x	x	1800	Hub	x	
				1820	Flexible element	x	x	1810	Ring / Flange	x	

19.7 Spare parts for type 154 DT

Example connecting
coupling type **ERK**.




Fig. 59

→ Connecting
couplings:
Chapter 20,
page 100

Screws and Standard parts		Wearing parts		Coupling main parts	
Item-No.	Description	Item-No.	Description	Item-No.	Description
0050	Fixing bolt	0130	Grooved ball bearing	0040	Coupling hub
0070	Circlip	0170	Radial shaft seal ring	0080	Holding disk
0390	Filler plug	0395	Fusible plug	0090	Inner wheel
1845	Set screw	0545	Flat seal	0300	Outer wheel
		0660	Flexible element	0305	Outer wheel
				0670	Hub

19.8 Spare parts for types 206 DT and 274 DT/DTV




Fig. 60

Upper Part:
Representation of
type DT with
connecting coupling
type ERK.

Lower Part:
Representation of
type DTV with
connecting coupling
type ENK-SV.


¹⁾ Only for continuous operation or operating fluid water (DTW...).

²⁾ In case of not ex-proof coupling: Set screw optional for connecting couplings ENK-SV.
For ex-proof coupling: Set screw is standard.


→ Connecting
couplings:
Chapter 20,
page 100

Screws and Standard parts			Wearing parts				Coupling main parts			
Pos.- Nr.	Description	DT / DTV	Pos.- Nr.	Description	DT	DTV	Pos.- Nr.	Description	DT	DTV
0050	Fixing bolt	x	0130	Grooved ball bearing	x	x	0040	Coupling hub	x	x
0070	Circlip	x	0170	Radial shaft seal ring	x	x	0080	Holding disk	x	x
0390	Filler plug	x	0175	Radial shaft seal ring	x	x	0090	Inner wheel	x	x
1830	Hexagon Screw	x	0395	Fusible plug	x	x	0300	Outer wheel	x	x
1840	Spring washer	x	0545	Flat seal	x	x	0305	Outer wheel	x	x
1845	Set screw	x	0660	Flexible element	x	x	0410	Delay chamber		x
			0994	Flat seal		x	0670	Hub	x	x
			1230	O-ring	x	x	1250	Oil retaining ring	x	x
			1820	Flexible element	x	x	1800	Hub	x	x
							1810	Ring / Flange	x	x

Fig. 61



Installation and Operating Manual 3626-011000 en.
2010-03 / Rev. 8.2. Printed in Germany.
Subject to modification due to technical development.



Upper Part:
Example of type DT
with connecting
coupling type EPK.

Lower Part:
Example of type DTV
with connecting
coupling type EPK.

Fig. 62 → Connecting
couplings:
Chapter 20,
page 100

¹⁾ For arrangement and quantity, please refer to tables in Chapter 13.4.

²⁾ Only for continuous operation or operating fluid water (DTW...).

Screws and Standard parts				Wearing parts				Coupling main parts			
Pos.-Nr.	Description	DT	DTV	Pos.-Nr.	Description	DT	DTV	Pos.-Nr.	Description	DT	DTV
0046	Circlip	x	x	0130	Grooved ball bearing	x	x	0040	Coupling hub	x	x
0050	Fixing bolt	x	x	0140	Grooved ball bearing	x	x	0045	Threaded ring	x	x
0070	Roll pin	x	x	0170	Radial shaft seal ring	x	x	0080	Holding disk	x	x
0110	Hexagon Screw	x	x	0175	Radial shaft seal ring	x	x	0090	Inner wheel	x	x
0390	Filler plug	x	x	0320	Tolerance ring	x	x	0100	Clamping ring	x	x
0396	Sight glass	x	x	0395	Fusible plug	x	x	0300	Outer wheel	x	x
0470	Spring washer	x	x	0405	Sealing ring	x	x	0410	Delay chamber		x
0530	Hexagon Screw	x	x	0510	Sealing ring		x	0800	Sealing ring cover	x	x
0540	Hexagon Screw	x	x	0545	Flat seal	x	x	0995	Intermediate piece	x	x
0550	Hexagon Nut	x	x	0820	O-ring	x	x	1800	Hub	x	x
0560	Spring washer	x	x	0994	Flat seal		x	1810	Ring / Flange	x	x
0810	Hexagon Screw	x	x	1820	Flexible element	x	x	1860	Sheet-metal holder	x	x
0840	Spring washer	x	x					1865	Sheet-metal holder 2	x	x
1830	Hexagon Screw	x	x								
1835	Hexagon Nut		x								
1840	Spring washer		x								
1845	Set screw	x	x								
1870	Hexagon Screw	x	x								
1880	Spring washer	x	x								

20 Spare parts information Connecting couplings

20.1 Connecting couplings on the input side

20.1.1 Flexible cam coupling type ENK

Outer shaft hub, type ENK-SX




Fig. 64

Inner shaft hub, type ENK-SV




Fig. 63

¹⁾ Set screw not shown here, see Fig. 30 and 31 on page 41.

20.1.2 Flexible element coupling type EEK

Outer shaft hub, type EEK-E




Fig. 66

Inner shaft hub, type EEK-M




Fig. 65

20.1.3 Flexible packet coupling type EPK




Fig. 67

Screws and Standard parts					Wearing parts		Coupling main parts				
Item-No.	Description	ENK	EEK	EPK	Item-No.	Description	Item-No.	Description	ENK	EEK	EPK
1830	Hex. screw	x	x	x	1820	Flexible element	1800	Hub	x	x	X
1840	Spring washer	x	x	x			1810	Ring / Flange	x	x	x
1845	Set screw	x	x	x			1860	Sheet-metal holder			x
1870	Hex. screw			x							
1880	Spring washer			x							

20.2 Connecting coupling on the output side

20.2.1 Coupling Nor-Mex G




Fig. 68

Screws and Standard parts			Wearing parts		Coupling main parts	
Item-No.	Description		Item-No.	Description	Item-No.	Description
1816	Socket head screw		1820	Flexible element	0770	Primary coupling flange 1
1845	Set screw				0770	Primary coupling flange 2
					1800	Hub
					1811	Flange hub
					1815	Claw ring

- blank page -

21 Representatives

Voith Turbo GmbH & Co. KG

West Europe:

Germany (VTCR):
Voith Turbo GmbH & Co. KG
Start-up Components
Voithstr. 1
74564 CRAILSHEIM
GERMANY
Tel.: +49-7951 32-0
Fax: +49-7951 32-480
e-mail:
startup.components@voith.com
[www.voithturbo.com/
startup-components](http://www.voithturbo.com/startup-components)

Austria:
Indukont Antriebstechnik GmbH
Badenerstraße 40
2514 TRAIKIRCHEN
AUSTRIA
Phone: +43-2252-81118-22
Fax: +43-2252-81118-99
e-mail: info@indukont.at

Belgium (VTBV):
Voith Turbo S. A. / N. V.
Square Louisa 36
1150 BRÜSSEL
BELGIUM
Phone: +32-2-7626100
Fax: +32-2-7626159
e-mail: voithturbo.be@voith.com

Denmark (VTDK):
Voith Turbo A/S
Egegårdsvej 5
4621 GADSTRUP
DENMARK
Phone: +45-46 141550
Fax: +45-46 141551
e-mail: postmaster@voith.dk

Finland (Masino):
Masino Oy
Kärkikuja 3
01740 VANTAA
FINLAND
Phone: +358-10-8345 500
Fax: +358-10-8345 501
e-mail: sales@masino.fi

France (VTFV):
Voith Turbo S. A. S.
21 Boulevard du Champy-Richardets
93166 NOISY-LE-GRAND CEDEX
FRANCE
Phone: +33-1-4815 6903
Fax: +33-1-4815 6901
e-mail: voithfrance@voith.com

Greece (Boznos):
Chr. Boznos and Son S. A.
12, K. Mavromichali Street
18545 PIRAEUS
GREECE
Phone: +30-210-422 5134
Fax: +30-210-422 5159
e-mail: info@boznos.gr

Great Britain (VTGB):
Voith Turbo Limited
6, Beddington Farm Road
CRO 4XB CROYDON, SURREY
GREAT BRITAIN
Phone: +44-20-8667 0333
Fax: +44-20-8667 0403
e-mail: turbo.uk@voith.com

Ireland:
see Great Britain (VTGB)

Italy (VTIV):
Voith Turbo s.r.l.
Via G. Lambrakis 2
42122 REGGIO EMILIA
ITALY
Phone: +39-05-2235-6714
Fax: +39-05-2235-6790
e-mail: info.voithturbo@voith.com

Liechtenstein:
see Germany (VTCR)

Luxembourg:
see Belgium (VTBV)

Netherlands:
see Germany (VTCR)

Norway (VTNO):
Voith Turbo AS
Tevlingveien 4 b
1081 OSLO
NORWAY
Phone: +47 2408 4802
Fax: +47 2408 4801
e-mail: info.turbo.norway@voith.com

Portugal:
see Spain (VTEV)

Spain (VTEV):
Voith Turbo S. A.
Avenida de Suiza 3
P.A.L. Coslada
28820 COSLADA (MADRID)
SPAIN
Phone: +34-91-6707816
Fax: +34-91-6707841
e-mail: info.voithturbo@voith.com

Sweden:
see Denmark (VTDK)

Switzerland:
see Germany (VTCR)

East Europe:

Bosnia Herzegovina:
see Hungary (VTHU)

Bulgaria:
see Hungary (VTHU)

Croatia:
see Hungary (VTHU)

Czech Republic (VTCZ):
Voith Turbo s.r.o.
Hviezdoslavova 1a
62700 BRNO
CZECH REPUBLIC
Phone: +420-543-176163
Fax: +420-543-176164
e-mail: info@voith.cz

Estonia:
see Poland (VTPL)

Hungary (VTHU):
Voith Turbo Kft.
Felvég Útca 4
2051 BIATORBÁGY
HUNGARY
Phone: +36-23-312 431
Fax: +36-23-310 441
e-mail: vtu@voith.com

Latvia:
see Poland (VTPL)

Lithuania:
see Poland (VTPL)

Macedonia:
see Hungary (VTHU)

Poland (VTPL):
Voith Turbo sp.z o.o.
Majków Duży 74
97-371 WOLA KRZYSZTOPORSKA
POLAND
Phone: +48-44 646 8848
Fax: +48-44-646 8520
e-mail: voithturbo.polska@voith.com

Romania (VTRO):
Voith Turbo S.R.L.
Bd. Dimitrie Pompeiu 8
10th floor, Sector 2
020337 BUCHAREST
ROMANIA
Phone: +40-31-22 36100
Fax: +40-31-22 36210
e-mail: voith.romania@voith.com

Russia (VPPT-MO):
Voith Paper Technology Russia
Branch Office Moskau
Nikoloyamskaya ul. 21/7, str. 3
109240 MOSKAU
RUSSIA
Phone: +7 495 915-3296
Fax: +7 495 915-2303
mobil Herr Bulanzev: +7 919 108 2468
e-mail: voithmoscow@Voith.com

Voith Turbo
Branch Office Novokusnetsk
(Shcherbinin, Anatoliy)
Skorosnaya ul. 41, Liter B1
654025 NOVOKUSNETSK
Kemerovskaya oblast
RUSSIA
Phone/Fax: +7 3843 311 109
mobil: +7 9132 802 110
e-mail: voith22@bk.ru

Serbia:
see Hungary (VTHU)

Slovak Republic:
see Czech Republic (VTCZ)

Slovenia:
see Hungary (VTHU)

Ukraine (VTUA):
Voith Turbo Ukraine TOW
Degtyarivska Str. 25, building 1
04119 KIEV
UKRAINE
Phone: +380-44-489 4621
Fax: +380-44-489 4621
e-mail: Dmitriy.Kalinichenko@Voith.com

see also Poland (VTPL)

North America:

Canada (VTC):
Voith Turbo Inc.
171 Ambassador Drive, Unit 1
L5T 2J1 MISSISSAUGA, ONTARIO
CANADA
Phone: +1-905-670-3122
Fax: +1-905-670-8067
e-mail: VTC-Info@voith.com

Mexico (VTX):
Voith Turbo S.A. de C.V.
Alabama No.34 Col. Nápoles
C.P. 03810 MÉXICO, D.F.
MÉXICO
Phone: +52-55-5340 6976
Fax: +52-55-5543 2885
e-mail: infovoith@voithmexico.com

see also U.S.A. (VTI)

U.S.A. (VTI):
Voith Turbo Inc.
25 Winship Road
17406 YORK
UNITED STATES
Phone: +1-717-767 3201
Fax: +1-717-767 3210
e-mail: voithturbo.usa@voith.com

South- + Middle America

Brazil (VTPA):
Voith Turbo Ltda.
Rua Friedrich von Voith 825
02995-000 JARAGUÁ,
SÃO PAULO - SP
BRAZIL
Phone: +55-11-3944 4650
Fax: +55-11-3941 1447
e-mail: info.turbo-brasil@voith.com

Chile (VTCI):
Voith Turbo S. A.
Avda.Pdte.Eduardo Frei Montalva 6001-
83
8550 189 SANTIAGO DE CHILE
CHILE
Phone: +56-2-624 2777+1185
Fax: +56-2-624 1794
e-mail: voithturbo.chile@voith.cl

Peru:
Voith Turbo S. A.
Av. Camino Real 348, Piso 15
LIMA 27
PERU
Phone: +51-1-422 4419
Fax: +51-1-999 60 0835
e-mail: Robert.Haselsteiner@Voith.com

see also Brazil (VTPA)

Africa:

Algeria:
see France (VTFV)

Botswana:
see South Africa (VTZA)

Egypt:
Copam Egypt
33 El Hegaz Street, W. Heliopolis
11771 CAIRO
EGYPT
Phone: +20-2-2566 299
Fax: +20-2-2594 757
e-mail: copam@datum.com.eg

Gabon:
see France (VTFV)

Guinea:
see France (VTFV)

Ivory Coast:
see France (VTFV)

Lesotho:
see South Africa (VTZA)

Marocco (VTCA):
Voith Turbo S.A.
Lotissement At-Tawfiq
Lot no 30 rue Ibnou el Koutia
20250 CASABLANCA
MAROCCO
Tel.: +212 22 34 04 41
Fax: +212 22 34 04 45
e-mail: info@voith.ma

Mauretania:
see Spain (VTEV)

Mozambique:
see South Africa (VTZA)

Namibia:
see South Africa (VTZA)

Niger:
see France (VTFV)

Senegal:
see France (VTFV)

South Africa (VTZA):
Voith Turbo Pty. Ltd.
16 Saligna Street
Hughes Business Park
1459 WITFIELD, BOKSBURG
SOUTH AFRICA
Phone: +27-11-418-4007
Fax: +27-11-418-4080 + 81
e-mail: info.vtza@voith.com

Swaziland:
see South Africa (VTZA)

Tunesia:
see France (VTFV)

Zambia:
see South Africa (VTZA)

Zimbabwe:
see South Africa (VTZA)

Near + Middle East:

Bahrain:
see United Arab Emirates (VTSJ)

Cyprus:
see United Arab Emirates (VTSJ)

Iran (VTIR):
Voith Turbo Iran Co., Ltd.
1st Floor, No. 215
East Dastgerdi Ave.
Modares Highway
19198-14813 TEHRAN
IRAN
Phone: +98-21-2292 1524
Fax: +98-21-2292 1097
e-mail: voithturbo.iran@voith.ir

Iraq:
see United Arab Emirates (VTSJ)

Israel (VTIL):
Voith Turbo Israel Ltd.
Tzvi Bergman 17
49279 PETACH
ISRAEL
Phone: +972-3-9131 888
Fax: +972-3-9300 092
e-mail: tpt.israel@voith.com

**Jordan,
Kuwait,
Lebanon,
Oman,
Qatar,
Saudi Arabia,
Syria:**
see United Arab Emirates (VTSJ)

Turkey (VTTR):
Voith Turbo Güç Aktarma Tekniği Ltd. Şti.
Birlik Mah. 415. Cadde No. 9/5
06610 ÇANKAYA-ANKARA
TURKEY
Phone: +90 312 495 0044
Fax: +90 312 495 8522
e-mail: info@aserman.com.tr

United Arab Emirates (VTSJ):
Voith Turbo Ltd.
P.O.Box 7895
SAIF Zone - A2-003
SHARJAH
UNITED ARAB EMIRATES
Phone: +971-655-709 94
Fax: +971-655-709 96
e-mail: voith-middle-east@voith.com

Yemen:
see United Arab Emirates (VTSJ)

Australia:

Australia (VTAU):
Voith Turbo Pty. Ltd.
Branch Office Sydney
503 Victoria Street
2164 WETHERILL PARK, NSW
AUSTRALIA
Phone: +61-2-9609 9400
Fax: +61-2-9756 4677
e-mail: vtausydne@voith.com

New Zealand :
see Australia (VTAU)

South East Asia:

Brunei:
see Singapore (VTSG)

Cambodia:
see Singapore (VTSG)

India (VTIP):
Voith Turbo Private Limited
Transmissions and Engineering
P.O. Industrial Estate
500 076 NACHARAM-HYDERABAD
INDIA
Phone: +91-40-27173 561+592
Fax: +91-40-27171 141
e-mail: info@voithindia.com

Indonesia:
see Singapore (VTSG)

Laos:
see Singapore (VTSG)

Malaysia:
see Singapore (VTSG)

Myanmar:
see Singapore (VTSG)

Singapore (VTSG)
Voith Turbo Pte. Ltd.
10 Jalan Lam Huat
Voith Building
737923 SINGAPORE
SINGAPORE
Phone: +65-6861 5100
Fax: +65-6861-5052
e-mail: sales.singapore@voith.com

Thailand:
see Singapore (VTSG)

Vietnam:
see Singapore (VTSG)

East Asia:

China:
see Hongkong (VTEA)

Voith Turbo GmbH & Co. KG (VTCB)
Representative Office Beijing
Unit 808, Di Yang Tower, No. H2
Dongsanhuanbeilu, Chaoyang District
100027 BEIJING
CHINA
Phone: +86-10-8453 6322/23
Fax: +86-10-8453 6324
e-mail: voith@voith-ind-bei.com.cn

Voith Turbo Power Transmission
(Shanghai) Co. Ltd. (VTCN)
Representative Office Shanghai
No. 265, Hua Jin Road
201108 SHANGHAI
CHINA
Phone: +86-21-644 286 86
Fax: +86-21-644 286 10
e-mail: info.turbo-shanghai@Voith.com

Service Center (VTCT):
Voith Turbo Power Transmission
(Shanghai) Co. Ltd.
Taiyuan Branch
No. 36-A Workshop
No. 73, Gangyuan Road
030008 TAIYUAN, SHANXI
P.R. CHINA
Phone: +86 351 565 5047
Fax: +86 351 565 5049
e-mail: Lisheng.Hao@Voith.com

Hongkong (VTEA):
Voith Turbo Ltd.
908, Guardforce Centre,
3 Hok Yuen Street East,
HUNGHOM, KOWLOON
HONG KONG
Phone: +85-2-2774 4083
Fax: +85-2-2362 5676
e-mail: voith@voith.com.hk

Japan (VTFC):
Voith Turbo Co., Ltd.
9F, Sumitomo Seimei Kawasaki Bldg.
11-27 Hlgashida-chou, Kawasaki-Ku,
Kawasaki-Shi,
210-0005 KANAGAWA
JAPAN
Phone: +81-44 246 0335
Fax: +81-44 246 0660
e-mail: fvc-taki@fsinet.or.jp

Korea:
Sae-Rim Voith Corporation
Room #1408, Dae Chong Bldg., 143-48
Samsung-Dong, Kangnam-Gu
C.P.O. Box 9666
135-090 SEOUL
SOUTH COREA
Phone: +82-2-557 4368
Fax: +82-2-563 7734
e-mail: yskorea@hanafos.com

Macau:
see Hongkong (VTEA)

Philippines:
see Taiwan (VTTI)

Taiwan (VTTI):
Voith Turbo Co. Ltd.
Taiwan Branch
No. 3 Lane 241, Chin Fuh Street,
Chyan Jen District.
806 KAOHSIUNG
TAIWAN
Phone: +886-7-813 0450
Fax: +886-7-813 0448
e-mail: vtli@voith.com.tw

22 Index

Alignment	40, 43	Grease, Requirements	48
Alignment tolerances	42	Greases, proposed greases	49
Ambient temperatures	18	Guard	17
As delivered condition	12	Information, spare parts	86
Assembly control report	67	Inner wheel drive	31
Bearing	63	Installation	
Bearing lubrication	63	basic type T	31
Bearings, Replacement	63	basic type TN	37
Blind screw	87, 91	Keys	33
blockage of output	22	Laid lengths L	42
Blocking	21	Level check	
BTM	84	Horizontal position	52
BTS	82	Vertical position	53
BTS-Ex	83	Level check device	52
Catch pan	18	Lifting	14
Cleaning	61	Lifting appliances	14
Commissioning	56	Maintenance	58
Commissioning report	70	Bearing	63
Connecting couplings	40, 100	Flexible connecting coupling	62
Constructional examples	27	Fusible plugs	64
Control of flexible elements wear	62	Outside cleaning	61
Control report	68	Maintenance intervals	63
Coupling temperature	21	Maintenance plan	60
Danger	11	Maintenance report	67, 71
Data, additional	6	Malfunctions – Remedial action	77
Declaration of manufacturer	7, 8	Manufacturer's declaration	7, 8
Design examples	27	Methane content,	
Direction of rotation	58	Control of methane content	10, 19
Disassembly	73	Monitoring devices	21, 81
Draining	54	BTM	84
Horizontal position with		BTS	82
delay chamber	54	BTS-Ex	83
Horizontal position without		MTS	81
delay chamber	54	Monitoring systems	66
Vertical position	55	Mounting	34
Electrical components	17	Mounting and removal devices	74
Electrical devices	18	Mounting devices	34, 36
Equipotential bonding	56	MTS	81
Fill		Multi-motor drive	58
Horizontal position	51	Noise	17
Vertical position	52	Oil list	46
Fill, Coupling	51	Operating fluids	12, 20, 45
Filling check	52	Proposed operating fluids	46
Fire extinguishing means	19	Requirements	45, 47
Fire fighting	19	water	48
Fire hazard	18	Order placed for service engineer	80
Fire point	45	Orders	80
Fixing bolt	35, 87, 91, 96, 97	Outer wheel drive	31, 37
Flash point	45, 46	Overhaul	86
Flexible connecting couplings	40	Overload	18, 20, 21
Flexible elements wear	62	overload of the coupling	22
Function	24	Packing	12
Fusible plugs	12, 18, 21, 64	pH-value	48
Fusible plugs for normal application	65	Pourpoint	45, 46
Fusible plugs to be used		Power transmission	20
in potentially explosive atmospheres	66	Preparation	32, 73

Preservation	12	Sound pressure level	17
Primary coupling flange	101	Spanner wrench	74
Product observation	23	Spare parts	9, 86
Proper use	10	Spare parts information	86
Proposed operating fluids		1150 DT/DTV	98
for special requirements	47	154 DT	96
Protective cover	56	154 T	87
Protective cover	61	206 - 274 T	87
		206 DT and 274 DT/DTV	97
Qualification	23	274 TV/TVV	91
Queries	80	T and TN	88
		TV/TVV and TVN/TVVN	92
Regreasing	63	TVVS and TVVSN	94
Remaining risks	10	Spare parts order	80
Removal	74	Standstill	57, 63
Removal devices	74	Star / delta connection	58
hydraulic	76	Starting characteristic	20
mechanical	75	Storage	12
Repair	86	switch off in case of coupling overload	22
Repair, Maintenance	58	Symbols	11
Replacement of bearings	63		
Report	68, 70, 71	Technical Data	5
Representatives	103	Temperature monitoring	5, 81
Risk classes	11	Temperature rise	17, 20
		Tightening torques	29, 30
Safety	11	Tools	23, 31
Serial-No.	80	Transportation	22
Service engineer, order for	80	Trouble shooting – remedy	77
Set screw	87, 91, 96, 97, 101	Type designation	25
Sight glass	52, 99		
Signal words	11	Working on the turbo coupling	17

Voith Turbo GmbH & Co. KG
Start-up Components
Voithstr. 1
74564 Crailsheim
GERMANY
Tel. +49 7951 32-0
Fax. +49 7951 32-480
startup.components@voith.com
[www.voithturbo.com/
startup-components](http://www.voithturbo.com/startup-components)

VOITH
Engineered reliability.