

Table Of Contents

Introduction 2
 Drive Identification 3

Section I — Drive Installation

Outfitting 4
 Installation 6
 Lubrication 8
 Start Up 8

Section II — Drive Service & Repair


Preventive Maintenance 9
 Stored & Inactive Drives 9
 Removal Of Drive 9
 Drive Disassembly 11
 Identifying & Ordering Parts 13
 Recommended Spare Parts 13
 Parts List Of Falk Part Numbers 15
 Bearing Cross Reference Numbers 16
 Seal Cross Reference Numbers 16

Section III — Drive Reassembly

Drive Reassembly 17

Appendix

Appendix A: Lubrication Recommendations 22
 Appendix B: Backstop Installation 26
 Appendix C: TA Removal Tool 30
 Appendix D: Motor Mount Installation 32
 Appendix E: Vertical Standpipe Installation 34
 Appendix F: Modifications For Non-Standard
 Mounting Positions 36
 Appendix G: Retaining Rings For Bushing Nuts and
 Thrust Plates & Tooth Combinations For
 Vibrations Analysis 38
 Appendix H: Drive Shaft Recommendations for
 Tapered Drive Shafts 39
 Appendix J: Drive Shaft Recommendations
 Using TA Taper® Bushing 40
 Appendix K: Drive Shaft Recommendations
 Using (TCB) Kit 42
 Appendix L: V-Belt Guard Installation 44
 Appendix M: Electric Fan Installation 46





Introduction

WARRANTY

Rexnord Industries, LLC (the "Company") warrants that Quadrive Shaft Mounted gear drives (I) conform to Company's published specifications, and (II) are free from defects of material for three years from the date of shipment.

Company does not warrant any non-Company branded products or components (manufacturer's warranty applies) or any defects in, damage to, or failure of products caused by: (I) dynamic vibrations imposed by the drive system in which such products are installed unless the nature of such vibrations has been defined and accepted in writing by Company as a condition of operation; (II) failure to provide suitable installation environment; (III) use for purposes other than those for which designed, or other abuse or misuse; (IV) unauthorized attachments, modifications or disassembly, or (V) mishandling during shipping.

WARNING: Consult applicable local and national safety codes for proper guarding of rotating members.

Lock out power source and remove all external loads from drive before servicing drive or accessories.

CAUTION: Do not weld the drive housing or accessories without prior approval from Rexnord Gear Group. Welding on the drive may cause distortion of the housing or damage to the bearings and gear teeth. Welding without prior approval will void the warranty.


DRIVE RATING — Operate the drive only within the horsepower and output speed for which it was selected and specified in Selection Guide 371-110 for the application. Refer to the nameplate for drive size, ratio and data.

FACTORY REPAIR AND REBUILD — Falk/Renew wants to continue to be your primary supplier, and extend our service to you if your equipment is in the need of repair or replacement.

We are able to furnish a fast turn-around on both the quotation and rebuild. Nobody can do the job better than Falk. If you need repair on Falk products . . . just ask.

Contact your local Rexnord account executive or Rexnord-Falk Distributor for more information.

Drive Identification



J is the basic drive identification. It can be furnished as a shaft mounted drive JR; a flange mounted drive JF; or a screw conveyor drive JSC(Size 5407 only), as illustrated below. These unique identifiers, JR, JF & JSC, are used throughout this manual to assist you in identifying the instructions which apply to your drive arrangement.

(JR) Shaft Mounted Drive	<p>1) Drive 2) Torque Arm 3) TA Taper Bushing</p>	+ Motor Mounts	
(JF) Flange Mounted Drive	<p>1) Drive With Flange TA Taper Bushing Optional</p>	+ Backstops	
(JSC) Screw Conveyor Drive(Size 5407 only)	<p>1) Drive With Seal Housing 2) Drive Shaft</p>	+ Shaft Cooling	
		+ Electric Cooling	
		+ Vertical Standpipe	
		+ Trough Ends	
		+ Thrust Plate Kits	
		+ V-Belt Guards	
		+ TA Removal Tool	

NOTE: Use a TA-Taper bushing when mounting these drives on a straight driven shaft (hollow shaft is taper bored).

Section I Drive Installation


Outfitting

1. **JR, JF & JSC** — Find the desired mounting position in Figure 1 and install air vent and magnetic drain plug (packaged separately with drive). Also note and/or mark the oil level plug location OR in the case of a vertical mounting, refer to Appendix E, for installation of vertical stand pipe. If the mounting angle exceeds the limitations shown in Figure 1, refer to Appendix F, to determine modifications necessary within the limits illustrated therein. **DO NOT** fill drive with lubricant at this time.


2. **JR** — The tapered bore hollow shaft is designed for use with a TA Taper bushing for mounting on a driven shaft with a straight outside diameter. Shaft tolerances for driven shafts are shown in Table 1. The minimum and maximum driven shaft engagements, dimension N in Figure 2, are shown in Table 2. The minimum engagement is necessary for full bushing engagement; the maximum engagement is only required if a thrust plate will be employed to remove the drive from the driven shaft (See Appendix C for preferred removal method).

Figure 1

HORIZONTAL DRIVES



VERTICAL DRIVES



ANGULAR LIMITS FOR HORIZONTAL MOUNTING (ALL CLOCK POSITIONS)




TABLE 1 — Driven Shaft Tolerances ★

Shaft Diameter — Inches		Max Undersize (Inches)
Over	Thru	
2.500	4.000	.006
4.000	6.000	.007
6.000	7.000	.008

★ Millimeters - h10 tolerance.

Figure 2





TABLE 2 — N Dimension †



DRIVE SIZE	Minimum Inches (mm)	Maximum Inches (mm)
5407	8.38 (213)	12.40 (314)
5415	10.33 (263)	13.44 (341)
5507	10.66 (271)	14.53 (369)
5608	12.75 (324)	16.35 (415)

† The minimum engagement is necessary for full bushing engagement; the maximum engagement is only if a thrust plate will be employed to remove the drive from the driven shaft.

- a. **THIN WALL BUSHING** (with keyway slot through the bushing wall) — With the driven shaft keyway at the 12 o'clock position, slide bushing assembly onto the driven shaft, nut end first, and position the keyway slot over the shaft keyway. The bushing may have to be opened slightly to assist in installation. Insert a screwdriver into the slot in the bushing and very lightly pry open until the bushing slides onto the shaft. Insert the drive key furnished with the bushing into the shaft keyway. Proceed to Step 6.




- b. **THICK WALL BUSHING** (with separate internal and external keyways) — Insert the driven shaft key into the driven shaft keyway. If the driven shaft has an open-ended keyway, stake the keyway, Figure 3, to prevent axial dislocation of the shaft key under operating conditions. Slide the bushing assembly onto the driven shaft. The bushing may have to be opened slightly to assist in installation. Insert a screwdriver into the slot in the bushing and very lightly pry open until the bushing slides onto the shaft. Rotate the shaft so the external keyway in the bushing is at the 12 o'clock position. Insert the drive key, furnished with the bushing, into the keyway. Proceed to Step 6.


Figure 3

Figure 4


3. **JSC(5407 ONLY)** — Remove the output cover from the input side of the hollow shaft bore and save. Separate contents from the drive shaft kit. Install thrust plate and retaining ring in the hollow shaft, Figure 4. Insert key into drive shaft. Slide drive shaft thru the seal housing into the hollow shaft and insert the thrust plate fastener thru the thrust plate into the drive shaft. Tighten fastener to 792 lb-ft (1073 Nm). Reinstall hollow shaft cover. Continue outfitting based on the type of trough end seal to be installed: (a) Waste Packing Seal; or (b) Lip Seal.

- a. **WASTE PACKING SEAL (Figure 5)** — Pack seal housing with waste packing and proceed to Step 4.

Figure 5


- b. **LIP SEAL (Figure 6)** — Coat outside diameter of seal with Permatex #3 or equivalent. Coat the seal lips with bearing grease. Carefully slide seal over drive shaft extension taking care to not damage the seal lips. Drive seal into seal housing with the spring loaded seal lip toward the trough end side of the seal housing, flush with the seal housing. Proceed to Step 4.

Figure 6


4. **JSC** — Fasten the trough end to the seal housing using the hex head cap screws included in the drive shaft kit. Refer to Table 3 for torque value. Proceed to Step 6.

TABLE 3 — 5407JSC Trough End Fastener Size & Tightening Torque (Non-lubricated Fasteners)


Drive Shaft Diameter	3.000 & 3.437
Fastener Size	.750-10UNC
Tightening Torque, lb-ft (Nm)	245 (332)

5. **JF** — (NOTE: If the driven shaft has not been machined to Falk’s taper bore specifications per Manual 377-140 and a straight shaft is to be utilized, refer to Manual 377-144 for instructions).

Install backstop prior to installation of drive (refer to Appendix B). Installation of internal backstops NOT Factory installed may require removal of mounting flange, Ref. #12. Remove cover from input end of hollow shaft bore and save. Install the thrust plate and retaining ring in the hollow shaft (refer to Figure 4). Proceed to Step 6.

Installation

6. **JR, JF & JSC** — Refer to Figure 7 for recommended lifting method. In order to sling JR & JF drives as illustrated, install the torque arm fastener in the torque arm anchor brackets. Sling the drive from the fastener as shown. For vertical installation, use (3) eyebolts as illustrated. Eyebolt sizes are 1/2" for 5407 thru 5507 and 3/4" for 5608. DO NOT remove sling until drive is secured to shaft. Before lifting the drive into position, rotate the high speed shaft until the hollow shaft keyway will be in position to line-up with the driven shaft key. JF proceed to Step 11; JSC to Step 12.



7. **JR** — If the drive was received with a backstop installed, the backstop must be temporarily removed to facilitate mounting. Refer to Section II, Step 10 for backstop removal instructions. Proceed to Step 8.
8. **JR** — Lift the drive into position and slide onto the drive shaft taking care that the driven shaft key seats into the hollow shaft keyway. DO NOT hammer or use excessive force. Refer to Figure 8 for installation of the torque arm. The exact position of the torque arm may vary within the range shown. For torque arm mountings other than shown, refer to Factory. If it is necessary to shorten the torque arm assembly, cut the excess from either tie rod end.

The support to which the clevis bracket is to be fastened must sustain the torque reaction shown in Table 4. The maximum load reaction through the torque arm occurs when the torque arm is located in the extreme off angle position. Use Grade 5 fasteners to anchor the clevis bracket; refer to Table 5 for the fastener size and tightening torque.

Bolt the torque arm to both the clevis bracket and the drive anchor bracket and tighten the bolts until seated against the brackets. DO NOT bend the bracket as clearance between the clevis brackets and tie rod is necessary.

Figure 8 — Torque Arm Mounting Positions 6 O’Clock Mounting Position Shown




TABLE 4 — Load Reaction Through Tie Rod

DRIVE SIZE	5407	5415	5507	5608
Load ★, lb	21840	26120	32940	40930
Load ★, (N)	(97130)	(116170)	(146500)	(182060)

★ Load includes moment due to motor and motor mount with torque arm at maximum angle.

TABLE 5 — Tie Rod Clevis Bracket Fastener Tightening Torque

DRIVE SIZE	Fastener † Size	Tightening Torque — lb-ft (Nm)	
		Steel Foundation	Concrete Foundation
5407	1.000-8UNC	567 (768)	467 (633)
5415	1.250-7UNC	1050 (1424)	867 (1175)
5507	1.250-7UNC	1050 (1424)	867 (1175)
5608	1.250-7UNC	1050 (1424)	867 (1175)

† Grade 5 fasteners required.

9. **JR** — Thread the bushing nut onto the hollow shaft one to two turns. NOTE: The bushing nut threads have been coated with an anti-seize compound at the Factory. This compound should not be removed. Before re-installing a previously used nut, recoat the nut threads only with an anti-seize compound. KEEP THE TAPERED SURFACE OF THE BUSHING AND HOLLOW SHAFT BORE FREE FROM ALL ANTI-SEIZE OR LUBRICATING COMPOUNDS.

WARNING: Overtightening can fail the internal retaining ring. (See Appendix G, for listing of retaining rings).

- PREFERRED METHOD** — Use a spanner, chain or pipe wrench to tighten the bushing nut to the torque value indicated in Table 6. Apply Loctite 243 or equivalent to threads of setscrews. Tighten the setscrew on the bushing nut to 19 lb-ft (26 Nm) torque.
- ALTERNATE METHOD (TO BE USED WHEN EXACT TORQUE CAN NOT BE MEASURED.)** — Use a spanner (Table 6), chain or pipe wrench to tighten the bushing nut just until the drive can no longer be moved by hand axially on the driven shaft. Loosen nut ONLY until it can be turned by hand but do not unseat the taper. Retighten the nut hand tight. Now mark a spot on the bushing nut. Next mark a spot on the driven shaft 180° from the first mark. Use the spanner wrench to tighten the nut until the two marks are aligned i.e., one half turn. Apply Loctite 243 or equivalent to threads of setscrews. Tighten the setscrew on the bushing nut to 19 lb-ft (26 Nm) torque.

TABLE 6 — Spanner Wrench Type and Spanner Nut Tightening Torque

DRIVE SIZE	Adjustable Hook Spanner Wrench		Spanner Nut Tightening Torque lb-ft (Nm)
	Armstrong Tools	Williams	
5407	34-313 6 1/8"-8 3/4"	474B	333 (452)
5415	34-313 6 1/8"-8 3/4"	474B	333 (452)
5507	73-213 ★	CT-15-2 ★	400 (542)
5608	73-213 ★	CT-15-2 ★	400 (542)

★ These are chain wrenches where standard spanner wrenches are not available.

10. **JR** — Install backstop, motor mount, motor, sheaves (mount sheaves as close to the drive and motor housing as possible), belts and guard. Refer to Appendix D for motor mount installation instructions. Proceed to Step 13.
11. **JF (USING TAPERED DRIVE SHAFT)** — Put key into the driven shaft. Lift drive into position and slide onto the driven shaft taking care that the driven shaft key seats into the hollow shaft keyway. DO NOT hammer or use excessive force. Secure the drive to the foundation with fasteners using torque values shown in Table 7. Next, secure the drive to the shaft with the thrust plate fastener. Refer to Table 8 for torque value. Reinstall the hollow shaft cover. Install motor mount, motor, sheaves, belts and guard. Refer to Appendix D for motor mount installation instructions. Proceed to Step 14.

12. **JSC (5407 ONLY)** — Assemble drive to trough and install drive shaft coupling bolts per screw conveyor manufacturer's instructions. Install motor mount, motor, sheaves, belts and guard. Refer to Appendix D for motor mount installation instructions. Proceed to Step 14.
13. **JR** — When the torque arm turnbuckle is used for belt tension adjustment, position the motor so that the belt pull will be about 90° to a line through the drive input shaft and hollow shaft as shown in Figure 9. For drives where the motor is moved to adjust belt tension, mount the motor slide base so that the belt tension adjustment is approximately parallel to the belt centers. Refer to Appendix D, for instructions relative to alignment of sheaves and belts. Proceed to Step 14.

TABLE 7 — JF and JSC Drives — Foundation Fastener & Tightening Torque
(Non-Lubricated Fasteners)


DRIVE SIZE	Fastener Size & Grade	Torque lb-ft (Nm)
5407	.750-10UNC, Gr. 5	245 (323)
5415	1.250-7UNC, Gr. 5	1050 (1424)
5507	1.250-7UNC, Gr. 5	1050 (1424)
5608	1.500-6UNC, Gr. 5	1842 (2497)

TABLE 8 — Thrust Plate Fastener Data
(Non-Lubricated Fasteners)

DRIVE SIZE	Fastener Size & Grade ★	Torque lb-ft (Nm)	Minimum Thread Depth-Inches (mm)
5407	1.000-8UNCx4.00, Gr. 8	792 (1073)	2.75 (69,8)
5415	1.250-7UNCx4.00, Gr. 8	1596 (2164)	2.50 (63,5)
5507	1.250-7UNCx4.00, Gr. 8	1596 (2164)	2.50 (63,5)
5608	1.250-7UNCx4.00, Gr. 8	1596 (2164)	3.00 (76,2)

★ Fastener lengths given are for applications using tapered drive shafts. Other lengths may be needed for applications using tapered bushings.

Figure 9



Lubrication

CAUTION: DRIVES SHIPPED WITHOUT OIL.

14. **JR, JF & JSC** — Refer to Appendix A for selection of lubricant. Refer to Table 9 for approximate oil capacity of drives.

15. **JR, JF & JSC** — HORIZONTAL MOUNTING

Remove air vent and oil level plug (Refer to Step 1). Fill the drive until oil shows in the oil level hole. Coat the air vent and plug threads with Permatex #3 or equivalent thread sealant before replacing.

JRV, JFV & JSCV — (VERTICAL MOUNTING) - Refer to Figure 1, Step 1.


Remove the fill plug and fill with oil to level marked on the dipstick.

Coat the plug threads with Permatex #3 or equivalent thread sealant before replacing.

If stand pipe is used as oil fill, the intermediate cover plug must be removed to eliminate entrapped air.

16. **JR, JF & JSC** — Where applicable, **WITH A HAND GREASE GUN**, pump grease into the input seal cover, Figure 10, until the grease appears at the shaft. Wipe off excess grease from the shaft. **DO NOT** use grease where it could contaminate the product e.g., foods, drugs etc.

Figure 10



Start Up

17. **JR, JF & JSC** — Before operating the drive, check for any fasteners, pipe plugs, air vent, etc. which may have been loosened in the course of Outfitting, Installing and Lubricating the drive, to be sure that they have been properly retightened. Check correct rotation of motor & backstop and be sure drive is properly lubricated. After one week of operation repeat check of all external fasteners and pipe plugs.

18. After one month of operation:

- a. Operate the drive until the sump oil reaches normal operating temperature. Shut the drive down and drain immediately.
- b. Immediately flush the drive with an oil of the same type and viscosity grade as the original charge (warmed to approximately 100°F (38°C) in cold weather). Rapidly pour or pump a charge equal to 25-100% of the initial fill thru the drive, or until clean oil flows thru the drain.
- c. Close the drain and refill the drive to the correct level with new or reclaimed oil of the correct type and viscosity. If determined to be in good condition by the supplier, drain oil may be reused if it is filtered thru a 100 micron or finer filter.

TABLE 9 — Approximate Oil Capacity ★

DRIVE SIZE	JR, JF & JSC Gallons (Liters)	JRV & JFV Gallons (Liters)
5407	4.3 (16,3)	6.3 (23,8)
5415	7.0 (26,5)	9.5 (36,0)
5507	10.3 (39,0)	13.3 (50,3)
5608	12.0 (45,4)	19.5 (73,9)

★ Quantities are approximate. Always fill drive to specified level.

Section II

Drive Service & Repair

Preventive Maintenance

PERIODICALLY — Carefully check the oil level of the drive when it is stopped and at ambient temperature, add oil if needed. If the oil level is above the specified level, have the oil analyzed for water content. Moisture in the oil may indicate seal leakage or condensation. If so, correct the defect immediately and change the oil. **DO NOT** overfill or oil leakage may result. On vertical shaft drives, remove fill plug before filling or checking oil level. If a drive is equipped with a fan, periodically clean accumulated foreign matter from the fan and fan guard to allow adequate air flow.

GREASE PURGED SEALS — Periodically (at least every six months), depending upon the frequency and degree of contamination, purge contaminated grease by slowly pumping fresh bearing grease through the seal cage **WITH A HAND GREASE GUN** until fresh grease flows out along the shaft. Wipe off the purged grease. Refer to Appendix A.

Oil Changes

PETROLEUM LUBRICANTS — For normal operating conditions, change gear oil every six months or 2500 operating hours, whichever occurs first. If the drive is operated in an area where temperatures vary with the seasons, change the oil viscosity grade to suit the temperature. Where applicable, grease seals when changing oil. Refer to Appendix A.

SYNTHETIC LUBRICANTS — Synthetic lube change intervals can be extended to 8000-10,000 hours depending on operating temperatures and lubricant contamination. Laboratory analysis is recommended for optimum lubricant life and drive performance. Change lube with change in ambient temperature, if required. Refer to Appendix A.

Stored & Inactive Drives

NEW DRIVES WHICH HAVE NOT BEEN OPERATED — Each drive is spin tested with a rust preventive oil that will protect internal parts against rust for a period of 4 months in an outdoor shelter or 12 months in a dry building after shipment from the Factory.

If a drive is to be stored or inactive beyond the above periods, spray all internal parts with a rust preventive oil that is soluble in lubricating oil or add 1 ounce of "Motorstor ★" vapor phase rust inhibitor oil. Seal air vent immediately with pressure sensitive tape.

Before operating drives which have been stored or inactive, remove tape and fill to the proper level with oil meeting specifications given in the Lubrication Recommendation found in Appendix A.

★ Product of the Daubert Chemical Company, Chicago, Illinois.
(Formerly known as "Nucl Oil.")

SHUTDOWN OF NEW OR EXISTING DRIVES WHICH HAVE BEEN OPERATED

— If a drive is to be stored or inactive for more than 2 months after a period of operation, add 1 ounce of "Motorstor¹" to the oil sump and immediately seal the air vent with pressure sensitive tape. It is not necessary to drain the oil prior to storage if oil is still serviceable and not contaminated.

Before operating drive, remove tape and check oil level.

PERIODICALLY INSPECT STORED OR INACTIVE DRIVES AND SPRAY OR ADD RUST INHIBITOR EVERY SIX MONTHS, OR MORE OFTEN IF NECESSARY. INDOOR DRY STORAGE IS RECOMMENDED.

Drives Ordered for Extended Storage can be treated at the Factory with a special preservative and sealed to rust-proof parts for periods longer than those stated above, if specified on the order.

Repair & Replacement

WARNING: Consult applicable local and national safety codes for proper guarding of rotating members.

Lock out power source and remove all external loads from drive before servicing drive or accessories.

NOTE: Only the seals on the input side (See Figure 12) of 5407-5507 drives and high speed shaft seals of the 5608 drive can be replaced without removing the drive from the driven equipment. All other repairs require removal of the drive from the driven equipment. Proceed to Step 1 for drive removal. Proceed to Step 5 for replacement of seals.

Removal of Drive

See note above if only seal replacement is intended.

1. **JR, JF & JSC** — Drain the lubricant at this time. Remove safety guards and belts (motor and motor mount, optional). Remove backstop. Refer to Section II, Step 10, for backstop removal instructions.

WARNING: Drive must be supported during removal process. Use a sling around the motor mount or as recommended in Section I, Step 6. Take up the slack in the sling before proceeding.


2. **JR** — Refer to Appendix C, for instructions for using the TA torque assist removal tool.

ALTERNATE METHOD — Loosen the setscrew on the bushing nut which is located at the output end of the hollow shaft. Use a spanner, pipe or chain wrench to loosen the bushing nut (Section I, Table 6). Initially, the nut will freely rotate counter clockwise approximately 180° as the nut moves from the locked position to the removal position. At this point anticipate resistance which indicates unseating of the bushing. Continue to turn the nut until it is free from the hollow shaft. Prepare drive for lifting (Figure 7) by disconnecting the torque arm at the drive end. Slide the drive from the bushing. The bushing can be left in place or removed, as required. If bushing will not slide off of the shaft, insert a small prybar into the split of the bushing and pry the split open slightly to loosen the bushing and remove from the shaft. Proceed to Step 5 for replacement of seals only or Step 9 for drive disassembly procedure.

3. **JF** — Remove the hollow shaft cover, Ref. #14 (Figure 12), from the input end of the hollow shaft. Remove the bolts which fasten the mounting flange to the driven equipment.

Remove the fastener, retaining ring, and thrust plate from the hollow shaft. Refer to Table 10 and select a backing bolt and flat washer and install them into the drive shaft as illustrated in Figure 11. The bolt head provides a working surface for the removal bolt. Reinsert the thrust plate and retaining ring into the hollow shaft and select a removal bolt from Table 10. Thread the removal bolt into the thrust plate until it contacts the backing bolt head. Torque the removal bolt to the value shown in Table 10. (If the thrust plate rotates in the shaft, align the slot in the plate with the hollow shaft keyway and insert a screw driver or piece of key stock to prevent rotation of the plate.) After torquing the bolt, as instructed, strike the bolt, sharply with a hammer and retorque the bolt if separation of the drive

Figure 11



from the shaft did not occur. Repeat this procedure, retorquing the bolt after each blow, until separation occurs.

CAUTION: Failure to follow this procedure may result in the destruction the threads in the thrust plate. (If the retaining ring becomes damaged, refer to Appendix G, for replacement information.)

Proceed to Step 5 for replacement of seals only OR Step 9 for drive disassembly procedure.

4. **JSC (5407 ONLY)** — Remove drive from driven equipment trough end by removing the trough end mounting screws from seal housing. Remove coupling bolts from drive shaft and slide drive with drive shaft away from the driven equipment.

To remove drive shaft from the drive, remove the hollow shaft cover, Ref. #14 (Figure 12), from the input end of the hollow shaft and then refer to Step 3 above. The procedure to separate the JSC drive from the shaft is the same as for separation of a JF drive from driven equipment shaft.

After separation of the drive and shaft has been achieved, determine the type of seal equipped in the seal housing. If it is a waste packing seal, remove the waste packing material and then remove the loosened drive shaft from the seal housing side of the drive. If equipped with a lip seal, first remove the lip seal following the removal instructions from Step 5. After seal is removed from seal housing, remove the loosened drive shaft from the seal housing side of the drive.

CAUTION: The seal housing acts as the bearing cage, therefore, DO NOT remove from the drive unless complete drive disassembly is anticipated. Removal of the seal housing will require readjustment of the L.S. bearings, Section III.


TABLE 10 — Removal & Backing Bolt Size and Length

DRIVE SIZE	Removal Bolt Size & Minimum Length – Inches	Maximum Tightening Torque – lb-ft (Nm)	Backing Bolt Size & Maximum Length – Inches
5407	1.125-7UNC x 3.00	742 (1006)	1.000-8UNC x 2.75
5415	1.500-6UNC x 3.75	1842 (2497)	1.250-7UNC x 2.50
5507	1.500-6UNC x 3.75	1842 (2497)	1.250-7UNC x 2.50
5608	1.500-6UNC x 3.75	1842 (2497)	1.250-7UNC x 3.00

DRIVE DISASSEMBLY — (Refer To Parts Drawing Figure 14)

Prior to initiating any disassembly or repair, clean accumulated dirt and grime from the surface of the drive housing. Clean the exposed portion of the high speed and hollow shafts with a solvent and a non-abrasive cloth. If the seals only are being replaced proceed to Step 5. If the drive will be disassembled for inspection or repair, skip to Step 9.

CAUTION: Do not damage shaft; new seals will leak if seal contacting surface is marred. Do not use abrasive material on shaft seal contacting surface.

Figure 12


5. **SEAL REMOVAL** — (When drive is to be disassembled, proceed to Step 9.) Seal replacement is recommended after seal removal. When removing seals, maintain shafts in a horizontal plane to prevent any foreign matter from falling into the bearings. Refer to Figures 12, 13 & 14.

NOTE: Only seals on the input side (See Figure 12) of 5407-5507 drives and high speed shaft seals of the 5608 drive can be replaced if gear drive is mounted on driven equipment. If gear drive removal is necessary, proceed to Step 1 for removal instructions.

If drive removal is not necessary, drain lubricant at this time.

Depending upon seal(s) being replaced, remove v-belt guard, v-belts, high speed shaft sheave, shaft cooling fan (if so equipped), backstop (5507 & 5608J only, if so equipped) and other accessories as necessary.

- a. Two seal mounting arrangements are used as follows:

Seals are installed into seal cages where seal cage must be removed from drive to remove seals. Removal of these seal cages will require readjustment of the bearings. The following seals use this mounting arrangement:

- 5407-5507; All types, H.S. seals.
- 5407JF & JSC; L.S. seals (output side).
- 5608; All types, H.S. & L.S. seals.

Refer to Figures 12, 13 & 14 and remove seals with this mounting arrangement as follows:


- (1) Clean shaft extension with solvent and remove all sharp edges. Remove seal cage, Ref. #11, #12, #21 or #66.
- (2) Drive out old seal from seal cage.
- (3) Scrape old Permatex from bore exercising caution not to score the bore.

- b. Seals are installed into seal cages where seal cage may remain attached to drive. The following seals use this mounting arrangement:

- 5407 JF & JSC; L.S. seals (input side).
- 5407-5507JR; L.S. seals (input & output sides).
- 5415-5507JF; L.S. seals (input & output sides).

Refer to Figures 12, 13 & 14. Remove the hollow shaft cover, Ref. #14, on Sizes 5407-5507. Remove seals with this mounting arrangement as follows:

- (1) Clean shaft extension with solvent and remove all sharp edges. Use a sharp center punch to lightly punch the seal case as a guide for the drill. NOTE: DO NOT drive seal into the bore too deep. Seals are not axially retained and disassembly of the drive may be required if the seal is driven too deep.
- (2) Wrap several turns of tape around a .125" (3 mm) diameter drill bit approximately .25" (6 mm) from the drill point to prevent the drill bit from entering too deeply into the housing and damaging the bearing. Grease or magnetize the drill bit to help retain the chips. Drill two .125" (3 mm) diameter holes in the seal case 180° apart. Control the angle of the drill as illustrated in Figure 13 to prevent damage to the shaft.
- (3) Insert two #10-.750" (M5 x 20) sheet metal screws into the seal case leaving .5" (13 mm) of the screw protruding above the seal face. DO NOT drive the screw more than .25" (6 mm) beyond seal face or bearing damage may occur. Use a claw type pry bar under the screw head as shown in Figure 13 and lift the seal out. Remove all metal chips. Use a magnet to remove the metal chips that fall into the

Figure 13




bore. Flush the drive to remove metal chips from the bearing. Remove Permatex from the housing bore.

6. **SEAL SURFACE CONDITION** — Carefully inspect polished surface of shaft where the seal makes contact. If the seal surface shows any sign of a nick, scratch, spiral swirl or groove, the shaft should be replaced or refurbished to prevent leakage of the lubricant. (In many instances the seal surface can be restored by use of a thin wall wear sleeve. Check with your local seal supplier and follow the manufacturer's instructions for installing the wear sleeve.)

7. SEAL INSTALLATION

CAUTION: Protect seal lips from sharp edges of the keyway by wrapping thin strong paper (Kraft paper) around the shaft and coating the paper and seal lips with grease before sliding the seal on or off the shaft. Do not expand the seal lips more than .030" (0,75 mm) diameter.

- a. Install seals into seal cages where cages must be removed from drive:

5407-5507; All types, H.S. seals.
5407 JF & JSC; L.S. seals (output side).
5608; All types, H.S. & L.S. seals.

Shim-gaskets are used behind seal cages and end covers to adjust bearings. The correct shim-gasket pack must be determined prior to seal installation to attain proper bearing adjustment.

Proceed to Section III, Step 3 for instructions regarding output side seal cages. Proceed to Section III, Step 5f for instructions regarding input side seal cages.

Proceed to Section III, Step 6, bearing adjustment instructions to determine the proper shim-gasket pack thickness.

Remove seal cage and install seal as follows:

Note: When removing a seal cage to install a seal, be sure to use the shim-gasket pack determined from above to assure correct bearing adjustment.

Coat O.D. of seal with Permatex #3 or equivalent sealant. Position seal squarely in seal cage with spring loaded lip toward drive. Drive or press seal into cage using a flat faced tool until seated.

Install the complete seal cage shim pack. Carefully slip seal cage with seal over the shaft. Replace fasteners and cross tighten to torques listed in Table 14, Section III.

- b. Install seals into seal bores where seal cages may remain attached to housing:

5407 JF & JSC; L.S. seals (input side).
5407-5507JR; L.S. seals (input & output sides).
5415-5507JF; L.S. seals (input & output sides).

Coat O.D. of seal with Permatex #3 or equivalent sealant. Carefully slip seal over shaft and position squarely in seal bore with spring loaded lip toward drive. Use a cylindrical square faced tool to drive or press seal into bore until outer seal wall is seated 0.14" (3.5 mm) inside the seal bore outer wall.

CAUTION: DO NOT seat seal against bearing; a shoulder is NOT provided for stopping the seal. Measure seal axial runout with a dial indicator mounted on the shaft. If the seal axial runout is more than 0.010" (0,25 mm), tap high side of seal with installation tool until seal axial runout is 0.010" (0,25 mm) or less.

8. **DRIVE REPAIR IS COMPLETE** — Review instructions in Section I for drive installation.

Drive Disassembly — Continued

9. When seals, Ref. #22 & 23 are to be reused (replacement is recommended), wrap the high speed shaft keyway and hollow shaft threads with masking tape or light weight kraft paper to protect seal lips during disassembly. Cover wrapping with a light coat of grease.

10. Remove backstop parts if so equipped. (For all drives, note direction of rotation of high speed shaft for proper reassembly.)

For Sizes 5407 & 5415J14 remove cover Ref. #19, backstop Ref. #5A and appropriate spacers from backstop cage. Re-install cage and cover without the backstop and finger tighten fasteners.

For Size 5415J25, remove entire backstop cage. Disassemble retaining rings and remove backstop. Re-install cage and cover without the backstop and finger tighten fasteners.

For Sizes 5507 & 5608, remove retaining ring and slide backstop Ref. #5A off of shaft.

11. Lay drive on bench with high speed shaft up. Remove housing cover fasteners, Ref. #33. Tighten the dowel nuts to remove the dowels. Screw cap screws into tapped holes (5/8-11UNC, Sizes 5407-5507; 7/8-9UNC, Size 5608). Tighten cap screws until the seal between the cover plate and base is completely broken. Screw eyebolts into tapped holes diagonally opposite in cover plate. Attach hoist cables and lift cover plate off housing base.

12. Remove the shaft assemblies (J05, Ref. #3A & 4A; J14 or J25, Ref. #1A, 2A & 4A) from output housing, Ref. #10.

13. Turn housing on either narrow side. If tapered roller bearings are being replaced, remove end covers and seal cage from output side of drive and drive bearing cups through the bores. Remove bearing cups from the housing cover in the same manner.

14. Drive seals out from base and cover bores and seal cages if replacement is indicated. Remove gasket material, seal compound and any accumulated foreign matter from seal joints, bores and adjacent sealing surfaces. Use a solvent to clean out the housing covers and shaft assemblies.

15. If drive is equipped with an internal backstop, check the shaft surface and the backstop sprags (inside diameter) for signs of wear. If either component shows evidence of wear, both should be replaced (Assemblies Ref. #1A or 3A and 5A). Also refer to Step 6 for inspection of seal surfaces.

16. Inspect gear teeth for wear or indications of fatigue; e.g., hairline cracks at the root of the tooth. If one element has undergone severe wear or broken teeth, replace the mating element also.
17. Clean and inspect bearings for wear. Lubricate with light oil before spinning to avoid scoring of working surfaces. Remove any worn bearings with a wheel puller. If tapered roller bearings are being replaced, replace the bearing cups. DO NOT use new cone assemblies with worn (old) cups.
18. If gears are to be replaced, use a wheel puller or press to remove gears Ref. #1A4 or 4A4 from their shaft. Exercise caution to avoid scoring shaft seal diameter with the keyway in the gear.
19. Inspect all fasteners for damage or wear and replace with fasteners of equal grade. Grade 5 fasteners have three (3) radial lines on the head. Fasteners are available in kit form, Ref. #80.
20. If the shaft assemblies can be reused intact (no new parts required), refer to Section III, Steps 5 thru 8, for reassembly procedure. Replace all shim-gaskets with new parts, Kit Ref. #100.



Identifying & Ordering Parts

1. Refer to the parts diagram, Figure 14, and make a list of the parts required by part reference number. For example, Ref. #21, 23, 100, 1A, 2A1, and 2A2. When a gasket joint is separated, always replace with new shim-gaskets. Order Ref. #100 shim-gasket kit.
2. Now refer to the parts list, Table 11, and determine the part description and Falk part number using the part reference number (Step 1) and the drive identification (e.g., 5407J25C) in the column headers of the parts list.
3. Use the part description and Falk part number to order the required parts. In the examples of preceding Steps 1 and 2, Ref. #21, 23, 100, 1A, 2A1 and 2A2 for a 5407J25C, parts would be ordered as follows:
 - Ref. #21 — Seal cage 4729121
 - Ref. #23 — Seal 2914622
 - Ref. #100 — Shim-gasket kit 0786841
 - Ref. #1A — Shaft assembly with gear 4729124
 - Ref. #2A1 — Bearing. 0921780
 - Ref. #2A2 — Bearing. 0921780
4. Tables 12 and 13 converts Falk part numbers to bearing and seal manufacturer’s part numbers. Tooth combinations are listed in Appendix G.
5. Place your order with your local Rexnord-Falk Distributor. If you need to locate a distributor, phone (414) 342-3131 in the United States and Canada.

Recommended Spare Parts

1. For non-critical drive applications a complete set of bearings, seals and shim-gaskets is recommended. If stored in their original packaging in a dry, cool location, these parts have a minimum shelf life of 5 years.
2. For critical drive applications (where an outage would create a major production loss), a complete drive is recommended.




Figure 14 — Sizes 5407 thru 5608






TABLE 11 — Parts List Of Falk Part Numbers

Ref. No.	Part Description	DRIVE SIZE					
		5407	5415	5507	5608		
Housing Components - J05, J14 & J25							
11	Seal Cage	0352865	0344480	0344425	4723185		
12	Flange -- Seal Housing	0352889		
12	Mounting Flange	...	0426963	0426935	4723190		
14	Shaft Cover	2110604	1191500	4723160	...		
15	Shaft Cover	4729119	4729138	4723142	4729168		
16	Shaft Cover	4729119	4729138	4723164	4729168		
17	Shaft Cover - Type J05	4729120	0344426	7392017	1237503		
17	Shaft Cover - 5507J14 & 25	7392017	...		
18	Shaft Cover - Type J14 & J25	2110747	0344426	7392017	...		
19	Shaft Cover - Type J14 & J25	1219672	0344428		
20	Backstop Cage - Type J14	1231142	0344429		
20	Backstop Cage - Type J25	1231142	0344427		
21	Seal Cage	4729121	4723144	4723165	4723186		
22	Seal - 2 Required.	2922296	913004	2914624	2921418		
23	Seal	2914622	2914622	2920284	2921422		
40	Torque Arm Assembly - JR Only	0785271	0785272	0785272	0785272		
41	Air Vent	0914088	0914088	0914088	0914088		
64	Seal - 14	2917237	2916785		
64	Seal - 25	0912775	2916785		
66	Seal Cage - 14	4729318	4729169		
66	Seal Cage - 25	4729319	4729169		
67	Anchor Bracket - J14, 25	4729320	4729191		
68	Torque Arm - Backstop - J14, 25	4729346	4729346		
80	Fastener Kit - Includes Ref. #33 thru 39 & 42	4729122	4729139	4729321	4729170		
100	Shim-Gasket Kit - Includes Ref. #24 thru 31	0786841	0786842	6720196	0786844		
Rotating Elements - J05				Without Backstop	With Backstop	Without Backstop	With Backstop
3A	Shaft Assembly - Includes Ref. #3A1 - 3A4	4729129	4729148	4729161	4729161	4729185	4729187
3A1	Bearing	0921855	0921494	0921752	0921752	0921751	0921751
3A2	Bearing	0921863	0921859	0921858	0921858	2918722	2918722
3A3	Pinion & Shaft - Includes Ref. #3A4	4729130	4729149	4729162	4729162	4729186	4729186
4A	Shaft Assembly - Includes Ref. #4A1 - 4A6	4729133	4723150	4729163	4729163	4729189	4729189
4A1	Bearing	2905186	0921861	0921755	0921755	2905910	2905910
4A2	Bearing	2905186	0921861	0921755	0921755	2905910	2905910
4A3	Hollow Shaft - Includes Ref. #4A5	4729134	4723149	4729164	4729164	4729190	4729190
4A4	Gear	1238083	1238033	1238072	1238072	1237487	1237487
4A6	Spacer - 5608	1237496	1237496
6A	Fan Assembly - Includes Ref. #6A1 thru 6A3	0785773	0785881	0785893	0785893	0785468	0785468
6A1	Fan	4729135	4729135	4729165	4729165	4729192	4729192
6A2	Guard	4729136	4729151	4729166	4729166	4729193	4729193
6A3	Backplate	4729137	4729152	4729167	4729167	4729194	4729194
Rotating Elements - J14				Without Backstop	With Backstop	Without Backstop	With Backstop
1A	Shaft Assembly With 1A4 Gear	4729123	4729140	4729324	4729325	4729171	4729177
1A	Shaft Assembly Without 1A4 Gear	4729125	4729142	4729326	4729327	4729172	4729178
1A1	Bearing	0921682	0921529	0921752	0921752	0921751	0921751
1A2	Bearing	2915106	0921860	0921858	0921858	2918722	2918722
1A3	Pinion & Shaft - Includes Ref. #1A5	4729127	4729144	4729322	4729323	4729173	4729181
1A4	Gear	1238081	1238034	1238073	1238073	0359007	0359007
5A	Backstop Assembly	0769170	0757220	...	6720194	...	6720194
Rotating Elements - J25				Without Backstop	With Backstop	Without Backstop	With Backstop
1A	Shaft Assembly With 1A4 Gear	4729124	4729141	4729330	4729331	4729175	4729179
1A	Shaft Assembly Without 1A4 Gear	4729126	4729143	4729332	4729333	4729176	4729180
1A1	Bearing	0921349	0921494	0921752	0921752	0921751	0921751
1A2	Bearing	2915107	0921859	0921857	0921857	2918722	2918722
1A3	Pinion & Shaft - Includes Ref. #1A5	4729128	4729145	4729328	4729329	4729174	4729182
1A4	Gear	1238082	1238035	1238074	1238074	0359007	0359007
5A	Backstop Assembly	0769170	0757221	...	6720195	...	6720194

Continued on next page



TABLE 11 — Parts List Of Falk Part Numbers

Ref. No.	Part Description	DRIVE SIZE					
		5407	5415	5507		5608	
Rotating Elements - J14 & J25				Without Backstop	With Backstop	Without Backstop	With Backstop
2A	Shaft Assembly - Includes Ref. #2A1 - 2A4	4729131	4729146	4729159	4729159	4729183	4729183
2A1	Bearing	0921780	0921556	0921752	0921752	0921678	0921678
2A2	Bearing	0921780	0921556	0921530	0921530	0921678	0921678
2A3	Pinion & Shaft - Includes Ref. #2A4	4729132	4729147	4729160	4729160	4729184	4729184
4A	Shaft Assembly - Includes Ref. #4A1 - 4A5	4729133	4723150	4729163	4729163	4729189	4729189
4A1	Bearing	2905186	0921861	0921755	0921755	2905910	2905910
4A2	Bearing	2905186	0921861	0921755	0921755	2905910	2905910
4A3	Hollow Shaft - Includes Ref. #4A5	4729134	4723149	4729164	4729164	4729190	4729190
4A4	Gear	1238083	1238033	1238072	1238072	1237487	1237487
4A6	Spacer	1237496	1237496
6A	Fan Assembly	0785773	0785881	0785893	0785893	0785468	0785468
6A1	Fan	4729135	4729135	4729165	4729165	4729192	4729192
6A2	Guard	4729136	4729151	4729166	4729166	4729193	4729193
6A3	Backplate	4729137	4729152	4729167	4729167	4729194	4729194

TABLE 12 — Bearing Cross Reference Numbers

Falk Part Number	Manufacturer's Number
Tapered Roller Bearings ★	
0921349	HM212046/HM212011
0921494	H715336/H715311
0921529	H715345/H715311
0921530	H414249/H414210
0921556	H715332/H715311
0921678	850/832
0921682	HM212049/HM212011
0921751	JH217249/JH217210
0921752	JH415647/JH415610
0921755	JM736149/JM736110
0921780	HM212044/HM212011
0921855	5584/5535
0921857	65212/65500B
0921858	65237/65500B
0921859	65200/65500B
0921860	65225/65500B
0921861	67782/67720
0921863	5565/5535
2905186	LM330448/LM330410
2905910	LM742749/LM742710
2915106	HM807040/HM807015B
2915107	HM807035/HM807015B
2918722	HH814542/HH814510

★ Falk suppliers of Tapered Roller Bearings are: Timken, Bower and Tyson.

TABLE 13 — Seal Cross Reference Number

Falk Part Number	Manufacturer's Number †	
	Chicago Rawhide	National
0913004	64998V	...
2914622	24899	...
2914624	70054	...
2920284	29383	...
2921418	85018	...
2921422	29912	415995V
2922296	60013	...

† Subject to substitution of equivalent seals without notice.

Section III

Drive Reassembly

Refer To Parts Drawing Figure 14.

1. GENERAL

- a. Clean all parts to be reassembled and coat all taper roller bearing cups and pinion teeth with oil. **DO NOT** lubricate gear teeth prior to assembly on shaft.
- b. Heat all tapered roller bearing cones in an oven to 275°F (135°C).

CAUTION: Do not apply flame directly to bearings or rest bearings directly on a heated surface.

- c. Slide or press all bearing cones tight against the shaft shoulder or spacer.

CAUTION: Do not apply force to the bearing cage or rollers. Apply force against the cone only.

2. ASSEMBLY OF TAPERED ROLLER BEARING CUPS —

Where bearings will be reused and where bearing cups were not removed from the housing, skip to Step 3. It is recommended that bearings be replaced whenever drive is disassembled after being in service.

Install bearing cups only in housing base at this time. Coat bearing cups and housing bores with an SAE 20 (or heavier) oil and drive or press cup squarely into the housing bores until positioned as shown in Figures 15 and 16. Use a flat plate and a brass bar to avoid damaging the bearing cups. **NOTE:** The exact positioning of the bearings in the bores will be achieved during the bearing adjustment procedure in Step 6.

Figure 15





Figure 16



CAUTION: Take care not to allow cups to cock during their installation as this could result in permanent damage to housing.

If cups become cocked in the bores, tap the high side lightly to re-position.

3. Assemble seal cages to housing output side(base) as follows:

- a. Turn housing onto its side being careful that the bearing cups do not fall out of the bores. Assemble low speed seal cage without seal and one .015" (0,38 mm) shim-gasket, Ref. #11 or 12 and 24. Cross tighten fasteners, Ref. #34, to torque specified in Table 14.

Check to be sure that cages and covers are registered on the bearing cups to avoid hanging up of the cups.

TABLE 14 — Fastener Tightening Torques ★

Location	Fastener Size — Inch Tightening Torque — lb-ft (Nm)			
	.375-16	.500-13	.750-10	.875-9
Low Speed Seal Cage	330 (447)	533 (723)
Intermediate End Cover	27.5 (37,3)	68.8 (93,2)
High Speed Seal Cage/End Cover	27.5 (37,3)	68.8 (93,2)
Housing Cover	...	68.8 (93,2)	245 (332)	...

★ Torques are for non-lubricated fasteners.

- b. Assemble intermediate end cover and one .015" (0,38 mm) shim-gasket, Ref. #15 and 25. Cross tighten fasteners, Ref. #35, to torque specified in Table 14.

- c. Assemble high speed pinion shaft cover or seal cage without seal as follows:

SIZES 5407-5608 WITHOUT BACKSTOP —

Assemble shaft cover and one .015" (0,38 mm) shim-gasket, Ref. #17 and 27. Cross tighten fasteners, Ref. #37, to torque specified in Table 14.

SIZES 5407 & 5415 WITH BACKSTOP —

Assemble shaft cover, 1st .015" (0,38 mm) shim-gasket, backstop cage and 2nd .015" (0,38 mm) shim-gasket, Ref. #19, 20, 29 and 30. Finger tighten fasteners, Ref. #38. **NOTE:** The backstop, Ref. #5A will be added later.

SIZES 5507 & 5608 WITH EXTERNAL BACKSTOP —


Assemble seal cage without seal and one .015" (0,38 mm) shim-gasket, Ref #31 and 66. Cross tighten fasteners to torque specified in Table 14. **NOTE:** The seal, Ref. #64, will be added later.

4. **SHAFT ASSEMBLIES** — Where bearings and gears were not removed from the shafts, skip to Step 5. If bearings and gears were removed from the shafts, reassemble parts on the shaft per Figures 17 thru 20 as follows:

- a. To assemble gear (Ref. #1A4 or 4A4), heat gear in an oven to 325°F (163°C). Install key. Press gear onto the shaft tightly against the shoulder. For Size 5608, be sure to place spacer, Ref. #4A6, Figure 20, in the proper location on shaft assembly, Ref. #4A, before pressing on the bearing.
- b. To assemble bearings, heat bearing cone in an oven to a maximum of 275°F (135°C), then slide or press bearing cone tight against the shaft shoulder or spacer.

CAUTION: Allow assembly to cool. Apply a coat of oil to the cooled bearings and gear teeth to lubricate & avoid scoring of the working surfaces.

Figure 17 — 1A Shaft



- b. **DOUBLE REDUCTION** — Lower high speed shaft assembly, Ref. #1A, Figure 17, into housing and tip away from other bores. Simultaneously lower the intermediate shaft assembly, Ref. #2A, Figure 19, and the low speed shaft assembly, Ref. #4A, Figure 20, into the housing. As shafts approach their final position, tip the high speed shaft pinion into the high speed gear mesh, Ref. #1A4.

Figure 18 — 3A Shaft Assembly




Figure 19 — 2A Shaft Assembly






Figure 20 — 4A Shaft Assembly



5. **DRIVE ASSEMBLY** — Turn drive housing base on work bench to allow the shaft assemblies to be lowered into the housing. Block up the housing so that when low speed shaft assembly, Ref. #4A, is in place, the threaded end of the shaft will clear the bench surface. Before assembly, inspect housing and all shaft assemblies to see that all foreign matter has been removed.

- a. **SINGLE REDUCTION** — Lower high speed shaft assembly, Ref. #3A, Figure 18, into housing and tip away from other housing bores. While lowering the low speed shaft assembly, Ref. #4A, Figure 20, into housing tip high speed shaft into the gear mesh of the low speed gear as the shaft nears final position.

- c. Arrange the shaft assemblies to ensure that the gears are in mesh and bearing cones are in the cups.
- d. Apply a bead of Loctite Gasket Eliminator #515 or equivalent to housing base as shown in Figure 21. Carefully lower the housing cover (using eyebolts as recommended in Section II, Step 11). Remove eyebolts. Install taper screw dowels through the housing cover into the housing base. NOTE: Be sure the nut on the taper screw dowel is loose so that the nut does not interfere with seating the taper screw dowel. Seat taper screw dowel into housing base by striking the head of the taper screw dowel with a hammer. Install cover fasteners and immediately (within 3 minutes) tighten to torque specified in Table 14.

Figure 21


- e. Apply film of oil to housing cover bores and bearing cups & carefully install the bearing cups into the bores as described in Step 2.
- f. Install seal cages without seals and covers:


DOUBLE REDUCTION DRIVES — Use the entire shim-gasket kit with the .015" (0,38 mm) shim-gasket against the housing. It is important that the .015" (0,38 mm) shim-gasket be placed against the housing to prevent leakage. Cross tighten fasteners to torques specified in Table 14. Parts involved are as follows:

Low speed seal cage Ref. #11, 24 & 34; shaft cover Ref. #16, 26 & 36; high speed seal cage Ref. #21, 31 & 39.

SINGLE REDUCTION DRIVES — Install end cover, Ref. #16, with one .015" (0,38 mm) shim-gasket, Ref. #26, on unused bore. Cross tighten fasteners, Ref. #36, to torque specified in Table 14. For the other seal cages follow instructions from above as described for double reduction drives.

6. BEARING ADJUSTMENT

- a. **FOR DRIVES EQUIPPED WITH TA TAPER BUSHING** — Turn drive over onto the input housing and carefully thread bushing nut onto hollow shaft threads. Rotate the shaft to seat the cone assemblies in the bearing cups. Set up a dial indicator, Figure 22. Rotate and oscillate shaft with axial force applied in both directions to obtain the shaft axial float measurement (upward force can be applied by prying the bushing nut upward). If no float is measured, remove bushing nut and seal cage & add shim-gaskets until float is measurable. Proceed to Step 6(c).
- b. **FOR DRIVES WITHOUT THE TA TAPER BUSHING** — Insert the hollow shaft thrust plate and secure with the retaining ring as illustrated in Section I, Figure 4. Thread a bolt into the thrust plate. Set up a dial indicator on the input housing face with the indicator probe on the end of the

Figure 22


hollow shaft. DO NOT indicate from the thrust plate or fastener head. Rotate and oscillate shaft with axial force applied in both directions to obtain the axial float measurement. (Upward force can be applied by prying the head of the thrust plate bolt upward). If no float is measured, remove seal cage and add shim-gaskets until float is measurable.

- c. If the axial float from 6(a) or (b) is greater than .010" (0,25 mm), subtract sufficient shims to obtain .001" to .010" (0,03 mm to 0,25 mm) float. Refer to Table 15 for shim thickness. Take into account the compressibility of shim-gaskets from Table 16. Reassemble and repeat Step 6(a) or (b). When float is within .001" to .010" (0,03 mm to 0,25 mm), proceed to Step 6(d).

TABLE 15 — Individual Shim-Gasket Part Numbers

Ref. No.	Shim Thickness Inches (mm)	DRIVE SIZE			
		5407	5415	5507	5608
100	...	0786841	0785587	0786843	0786844
24	0.007 (0,18)	1231144	1220259	1220130	1231222
	0.009 (0,23)	0767761	0757456	0757453	0767802
	0.015 (0,38)	0767762	0757457	0757454	0767803
	0.031 (0,79)	0767763	0757458	0757455	0767804
25	0.015 (0,38)	0755904	0757460	0757460	3200133
26	0.007 (0,18)	1219682	1220540	1220128	0761568
	0.009 (0,23)	0755903	0757459	0755947	0761569
	0.015 (0,38)	0755904	0757460	0755948	3200133
	0.031 (0,79)	0755905	0757461	0755949	...
27 & 28	0.015 (0,38)	0755904	1220129	0757460	0710703
29 & 30	0.015 (0,38)	0755904	1220129	1220129	...
31	0.007 (0,18)	1219682	1220540	1220128	1130518
	0.009 (0,23)	0755903	0757459	0755947	0710702
	0.015 (0,38)	0755904	0757460	0755948	0710703
	0.031 (0,79)	0755905	0757461	0755949	...

TABLE 16 — Falk Shim-Gasket Compressibility

Thickness Inches (mm)	New				
	0.007 (0,18)	0.009 (0,23)	0.015 (0,38)	0.031 (0,79)	
	0.006 (0,15)	0.008 (0,20)	0.013 (0,33)	0.028 (0,71)	

- d. Refer to Table 17 and note the preload specified for bearings Ref. #4A1 and 4A2. Add to the upper and lower limits shown, the axial movement obtained in Step 6(c). This will indicate the thickness of shims to be removed to obtain the specified preload. For example, if the preload in Table 17 is .005" to .007" (0,13 mm to 0,18 mm) and the axial movement was .007" (0,18 mm), removal of shims with a total thickness of .012" to .014" (0,31 mm to 0,36 mm) will produce the desired preload. Table 15 provides shim thicknesses for each shim pack to assist in obtaining the desired results. Take into account the compressibility of shim-gaskets from Table 16.

TABLE 17 — Preload & Axial Settings – Inch (mm)

DRIVE SIZE	Bearings Ref. #4A1 & 4A2	Shaft & Pinion Ref. #2A3	Shaft & Pinion Ref. #1A3 or 3A3
	Bearing Preload	Axial Float	Axial Float ★
5407	.004-.006 (0,10-0,15)	.001-.003 (0,03-0,08)	.001-.003 (0,03-0,08)
5415	.005-.007 (0,13-0,18)		
5507	.006-.008 (0,15-0,20)		
5608	.008-.010 (0,20-0,25)		

★ NOTE: For Sizes 5407 & 5415 equipped with a backstop, axial float measurement must be within the following range: .001 preload to .001 float.

- e. Remove seal cage, Ref. #11, and remove shim-gasket(s) as determined in Step 6(d). Reattach the seal cage and tighten fasteners to torque specified in Table 14.
- f. **AXIAL FLOAT ADJUSTMENT, REF. #2A3** — Remove pipe plug from center of shaft cover, Ref. #16, and install a .375-16 x 2" or longer fastener thru the hole in the shaft cover into the threaded hole in the pinion shaft. Turn by hand until snug. Set up a dial indicator with the probe on the fastener head as illustrated in Figure 23. Turn the fastener in a clockwise direction, pushing and pulling the fastener to make certain the bearings are properly seated. Measure the axial float. Subtract from this reading the axial float for Ref. #2A3 shaft found in Table 15. This indicates the thickness of shims to be removed. When removing the shim(s) retain the .015" (0,38 mm) thickness against the drive housing. Retighten fasteners and recheck float. Readjust shimming, if necessary, until proper axial float is achieved (Table 17).
- g. **AXIAL FLOAT ADJUSTMENT, REF. #1A3 or 3A3** — Refer to Figure 24 and adjust float as follows:

Set up a dial indicator for determining axial movement of the high speed shaft Ref. #1A3 or 3A3. Lift upward with a twisting motion to obtain a reading.

WARNING: Cover keyway with tape to avoid lacerations to the hand.

Subtract from this reading the axial float for shaft, Ref. #1A3 or 3A3, found in Table 15. This indicates the thickness of shim(s), Ref. #31, to be removed. When removing the shim(s), retain the .015" (0,38 mm) thick shim against the housing, Ref. #10. Retighten fasteners and recheck float. Readjust shimming, if necessary, until proper float is achieved (Table 17).

7. SEAL INSTALLATION

Seals can be installed after all bearing adjustments have been completed. Refer to Section II, Step 7, to install seals, Ref. #22 & 23. NOTE: When removing a seal cage to install a seal, be sure to replace the same shim-gaskets as removed to assure correct bearing adjustments.

8. BACKSTOP INSTALLATION

If drive will be installed on the driven equipment using the thrust plate and thrust plate fastener, install the backstop at this time. Refer to Appendix B, for installation instructions.

DRIVE IS READY TO INSTALL — Refer to Section I.





TABLE OF CONTENTS

Appendix A: Lubrication Recommendations	22
Appendix B: Backstop Installation	26
Appendix C: TA Removal Tool	30
Appendix D: Motor Mount Installation	32
Appendix E: Vertical Standpipe Installation	34
Appendix F: Modifications For Non-Standard Mounting Positions	36
Appendix G: Retaining Rings For Bushing Nuts and Thrust Plates & Tooth Combinations For Vibrations Analysis	38
Appendix H: Drive Shaft Recommendations for Tapered Drive Shafts	39
Appendix J: Drive Shaft Recommendations Using TA Taper Bushing	40
Appendix K: Drive Shaft Recommendations Using (TCB) Kit	42
Appendix L: V-Belt Guard Installation	44
Appendix M: Electric Fan Installation	46

Lubrication

Introduction

Lubricants listed in this manual are typical products ONLY and should not be construed as exclusive recommendations. Industrial type petroleum based rust and oxidation inhibited (R & O) gear lubricants or industrial type sulfur-phosphorus extreme pressure (EP) gear lubricants are the recommended lubricants for ambient temperatures of +30°F to 125°F (-1°C to 52°C).

For drives operating outside the above temperature range, refer to the “Synthetic Lubricants” paragraphs. Synthetic lubricants can also be used in normal climates.

Carefully follow instructions on the drive nameplate, warning tags and installation manuals furnished with the drive.

Viscosity (Important)

The proper viscosity grade for R & O and EP lubricants is found in Table 3. For synthetic lubricant viscosity grades, refer to Table 4 and the “Synthetic Lubricants” paragraphs. Petroleum based lubricant selections must have a pour point at least 10°F (5.5°C) below the expected minimum ambient starting temperature.

Petroleum Based Lubricants

R & O GEAR LUBRICANTS (TABLE 3) — Industrial type petroleum based rust and oxidation inhibited (R & O) gear lubricants are the most common and readily available general purpose gear lubricants.

EXTREME PRESSURE (EP) LUBRICANTS (TABLE 3) — For highly loaded drives or for drives loaded in excess of original estimates, industrial-type petroleum extreme pressure lubricants are preferred. The EP lubricants currently recommended are of the sulphur-phosphorus type.

CAUTION: PETROLEUM BASED LUBRICANTS & INTERNAL BACKSTOPS — Do not use EP lubricants or lubricants with anti-wear additives or lubricant formulations including sulfur, phosphorus, chlorine, lead derivatives, graphite or molybdenum disulfides in drives equipped with internal cartridge type backstops. Some lubricants in Table 3 may contain anti-wear additives. EP lubricants in Table 3 do contain several of these additives.

WARNING: EP LUBRICANTS IN FOOD PROCESSING INDUSTRY — EP lubricants may contain toxic substances and should not be used in the food processing industry without the lubricant manufacturer’s approval. Lubricants which meet USDA “H1” classification are suitable for food processing applications.

Synthetic Lubricants

Synthetic lubricants of the polyalphaolefin type are recommended for cold climate operation, high temperature applications, extended temperature range (all season) operation and/or extended lubricant change intervals. The proper viscosity grade of synthetic lubricant is given in Table 4. Usable temperature ranges can sometimes be widened if specific application conditions are known.

NOTE: SYNTHETIC LUBRICANTS & INTERNAL BACKSTOPS – Synthetic lubricants of the Polyalphaolefin Type may be used in drives with internal backstops. Select proper lubricant grade from Table 4.

NORMAL CLIMATE CONDITIONS — For temperatures of 30°F (-1°C) and above, use viscosity grades as recommended in Table 3 for petroleum based lubricants, or see Table 4 for synthetic lubricants.

WARNING: SYNTHETIC LUBRICANTS IN FOOD PROCESSING INDUSTRY — Synthetic lubricants may contain toxic substances such as sulfur, phosphorus, chlorine, lead derivatives, graphite or molybdenum disulfides and should not be used in the food processing industry without the lubricant manufacturer’s approval. Lubricants which meet USDA “H1” classification are suitable for food processing applications.

Lubricant Changes

OIL ANALYSIS REPORT — Checking oil condition at regular intervals is recommended. In the absence of more specific limits, the guidelines listed below may be used to indicate when to change oil:

1. Water content is greater than 0.05% (500 ppm).
2. Iron content exceeds 150 ppm.
3. Silicon (dust/dirt) exceeds 25 ppm.
4. Calcium content 50 ppm above normal lubricant amount.
5. Viscosity changes more than 15%.

PETROLEUM LUBRICANTS — For normal operating conditions, change gear oils every six months or 2500 operating hours, whichever occurs first. If the drive is operated in an area where temperatures vary with the seasons, change the oil viscosity grade to suit the temperature, refer to Table 3. Lubricant suppliers can test oil from the drive periodically and recommend economical change schedules.

SYNTHETIC LUBRICANTS — Synthetic lube change intervals can be extended to 8000 hours depending upon operating temperatures and lubricant contamination. Laboratory analysis is recommended for optimum lubricant life and drive performance. Change lube with change in ambient temperature, if required. Refer to Table 4.

TABLE 1 — Approximate Oil Capacity ★

DRIVE SIZE	JR, JF & JSC Gallons (Liters)	JRV & JFV Gallons (Liters)
5407	4.3 (16,3)	6.3 (23,8)
5415	7.0 (26,5)	9.5 (36,0)
5507	10.3 (39,0)	13.3 (50,3)
5608	12.0 (45,4)	19.5 (73,9)

★ Quantities are approximate. Always fill drive to specified level.

Grease Lubricated Seals

All drives are furnished with grease purged seals which minimize the entry of contaminants and abrasive dusts into the drive. Drives are shipped with NLGI #2 grease in the seal housing cavities unless otherwise specified.

Whenever changing oil in the drive, purge the seals with one of the NLGI #2 greases listed in Table 2.

TABLE 2 — Greases For Grease Purged Seals

[0° to 200°F (-18° to 93° C)]

Manufacturer	Lubricant
Amoco Oil Co. BP Oil Co. Chevron U.S.A., Inc. Citgo Petroleum Corp.	Amolith Grease No. 2 Energrease LS-EP2 Industrial Grease Medium Premium Lithium Grease No. 2
Conoco Inc. Exxon Company, U.S.A. Houghton Int., Inc. Imperial Oil Ltd.	EP Conolith Grease No. 2 Unirex N2 Cosmolube 2 Unirex N2L
Kendall Refining Co. Keystone Lubricants Lyondell Petrochemical (ARCO) Mobil Oil Corp.	Multi-Purpose Lithium Grease L421 Zeniplex 2 Litholine H EP 2 Grease Mobilith 22
Mobil Oil Corp. Petra-Canada Products Phillips 66 Co. Shell Oil Co.	Mobilith SHC 460 † Multipurpose EP2 Philube Blue EP Alvania Grease 2
Shell Canada Limited Sun Oil Co. Texaco Lubricants	Alvania Grease 2 Ultra Prestige EP2 Premium RB Grease
Unocal 76 (East & West) Valvoline Oil Co.	Unoba EP2 Multilube Lithium EP Grease

† High performance synthetic alternate.

Some of these greases are of the EP type and may contain toxic substances not allowed in the food processing industry. If grease could contaminate the product, as in the food and drug industries, the grease should be removed. A grease that meets the USDA “H1” classification is suitable for food processing applications.

Periodically (at least every six months) depending upon the frequency and degree of contamination, purge contaminated grease from seals by slowly pumping fresh bearing grease thru the seal, **WITH HAND GREASE GUN**, until fresh grease flows out along the shaft. Wipe off purged grease.



Table 3 — Petroleum Based Gear Lubricants ★

Ambient Temperature Range		+30 to +90°F	+70 to +125°F
		-01 to +32°C	+21 to +52C
AGMA Viscosity Grade		5	6
ISO Viscosity Grade		220	320
Viscosity	cSt @ 40°C	198 - 242	288-352
	SSU @ 100°F	918 - 1122	1335-1632
Manufacturer		Lubricant	
Amoco Oil Co.		Amer. Ind. Oil 220 Permogear/Amogear EP 220 •	Amer. Ind. Oil 320 Permogear/Amogear EP 320 •
BP Oil Co.		Energol HLP-HD 220 Energear EP 220 • Energear EP 320
Chevron U.S.A., Inc.		Machine Oil AW 220 Gear Compounds EP 220 •	Machine Oil AW 320 Gear Compounds EP 320 •
Citgo Petroleum Corp.		Citgo Pacemaker 220 Citgo EP Compound 220 •	Citgo Pacemaker 320 Citgo EP Compound 320 •
Conoco Inc.		Dectol R&O Oil 220 Gear Oil 220 •	Dectol R&O Oil 320 Gear Oil 320 •
Exxon Company, U.S.A.		Teresstic 220 Spartan EP 220 •	Teresstic 320 Spartan EP 320 •
Houghton International, Inc.		Hydro - Drive HP 1000 MP Gear Oil 220 • MP Gear Oil 320 •
Imperial Oil Ltd.		Teresso 220 Spartan EP 220 •	Teresso 320 Spartan EP 320 •
Keystone Lubricants		KLC-50 Keygear 220 • Keygear 320 •
Lyondell Petrochemical (ARCO)		Duro 220 Pennant NL 220 •	Duro 320 Pennant NL 320 •
Mobil Oil Corp.		DTE Oil BB Mobilgear 220 •	DTE Oil AA Mobilgear 320 •
Petro-Canada Products		Harmony 220 Ultima EP 220 •	Harmony 320 Ultima EP 320 •
Phillips 66 Co.		Magnus Oil 220 Philgear 220 •	Magnus Oil 320 Philgear 320 •
Shell Oil Co.		Morlina 220 Omala Oil 220 •	Morlina 320 Omala Oil 320 •
Shell Canada Limited		Tellus 220 Omala Oil 220 •	Tellus 320 Omala Oil 320 •
Texaco Lubricants		Regal Oil R&O 220 Meropa 220 •	Regal Oil R&O 320 Meropa 320 •
Unocal 76 (East)		Unax RX 220 Extra Duty NG Gear Lube 220 •	Unax AW 320 Extra Duty NG Gear Lube 320 •
Unocal 76 (West)		Turbine Oil 220 Extra Duty NG Gear Lube 220 •	Turbine Oil 320 Extra Duty NG Gear Lube 320 •
Valvoline Oil Co.		Valvoline AW ISO 220 AGMA EP 220 •	Valvoline AW ISO 320 AGMA EP 320 •

★ Minimum viscosity index of 90. Maximum operating temperature of lubricants is 200°F (93°C)
 • Extreme Pressure Lubricant (contains sulfur-phosphorus). **DO NOT** use in drives equipped with internal backstop.

TABLE 4 — Synthetic Lubricants – Polyalphaolefin Type ‡

Ambient Temp. Range	-30 to +10°F (-34 to -12°C)	-15 to +50°F (-26 to +10°C)	0 to +80°F (-18 to +27°C)	+10 to +125°F (-12 to +52°C) ♦	+20 to +125°F (-7 to +52°C)
AGMA Viscosity Grade	05	25	45	55	65
ISO Viscosity Grade	32	68	150	220	320
Viscosity cSt @ 40°C	28.8-35.2	61.2-74.8	135-165	198-242	288-352
Viscosity SSU @ 100°F	134-164	284-347	626-765	918-1122	1335-1632
Manufacturer	Lubricant				
Chevron U.S.A., Inc.	Clarity Synthetic PM Oil 220 Syn. Gear Lube Tegra 220 ■	...
Conoco Inc.	Syncon R & O 32	Syncon R & O 68 Syncon EP 68 ■	Syncon EP 150 ●■	Syncon R & O 220 ● Syncon EP 220 ●■	Syncon EP 320 ●■
Dryden Oil Co.	Drydene SHL Lubricant 32	Drydene SHL Lubricant 68	Drydene SHL Lubricant 150	Drydene SHL Lubricant 220	Drydene SHL Lubricant 320
Exxon Company, U.S.A.	Teresstic SHP 32	Teresstic SHP 68	Teresstic SHP 150 Spartan Synthetic EP 150 ■	Teresstic SHP 220 Spartan Synthetic EP 220 ■	Teresstic SHP 320 Spartan Synthetic EP 320 ■
Mobil Oil Corp.	SHC 624	SHC 626	SHC 629 Mobilgear SHC 150 ■	SHC 630 Mobilgear SHC 220 ■	SHC 632 Mobilgear SHC 320 ■
Pennzoil Products Co.	Pennzgear SHD 32	Pennzgear SHD 68 Super Maxol "S" 68 ■	Pennzgear SHD 150 Super Maxol "S" 150 ■	Pennzgear SHD 220 Super Maxol "S" 220 ■	Pennzgear SHD 320 Super Maxol "S" 320 ■
Petro-Canada Products	Super Gear Fluid 150EP ■	Super Gear Fluid 220EP ■	Super Gear Fluid 320EP ■
Shell Oil Co.	Hyperia 220 Hyperia S 220 ■	Hyperia 320 Hyperia S 320 ■
Sun Co.	Sunoco Challenge 220 Sunoco challenge eP 220 ■	Sunoco Challenge 320 Sunoco Challenge EP 320 ■
Texaco Lubricants Co.	Pinnacle 32	Pinnacle 68	Pinnacle 150 Pinnacle EP 150 ■	Pinnacle 220 Pinnacle EP 220 ■	Pinnacle 320
Whitmore Manufacturing Co.	Decathlon 4EP ■	Decathlon 5EP ■	Decathlon 6EP ■

‡ Minimum viscosity index of 130. Consult lubricant supplier/manufacturer for maximum operating temperature.

● Minimum viscosity index of 120.

 ■ Extreme pressure EP lubricant (contains sulfur-phosphorus). **DO NOT** use in drives equipped with internal backstop.

 ♦ Drives **NOT** equipped with internal backstop may widen the ambient temperature range to -25 to +125°F (-32 to +52°C).

Backstop Installation — Sizes 5407 & 5415

Introduction

The following instructions apply to INSTALLATION ONLY of internal backstops in horizontal drives, Sizes 5407 thru 5415 double reduction.

WARNING: Axial float measurement of the high speed shaft must be within the following range: .001 inch preload to .001 inch float. Refer to Section III (Drive Reassembly) Item 6 (Bearing Adjustment) for proper instructions on bearing settings and measuring axial float. If backstop is to be replaced, the high speed shaft must also be replaced. Refer to instructions regarding high speed shaft replacement in Section III.

Remove all external loads from system before servicing drive or accessories, and lock out starting switch of prime mover.

Lubricant

PETROLEUM BASED LUBRICANTS — Use R & O type lubricants which do not contain anti-wear (AW) additives if the drive is equipped with an internal backstop.

CAUTION: Do not use EP lubricants or lubricants with anti-wear additives or lubricant formulations including sulfur, phosphorus, chlorine, lead derivatives, graphite or molybdenum disulfides in drives equipped with internal backstops. Refer to Appendix A for proper selection of petroleum based lubricants. Use of an improper lubricant will contribute to premature wear or malfunction of the backstop.

SYNTHETIC LUBRICANTS — Synthetic lubricants of the polyalphaolefin type may be used in drives with internal backstops.

Before installing backstop, check direction of free rotation (overrunning) indicated by the arrow etched on each side of the backstop.

Backstop Application

Backstops are designed to prevent reverse rotation or backlash in applications such as conveyors, bucket elevators, fans, rotary pumps and kilns. Backstops are not approved for use on systems that are designed for handling of people such as elevators, manlifts, ski tows and ski lifts. DO NOT use a backstop as a substitute for a brake.


Indexing

DO NOT use the backstop for indexing applications. The backstop is designed to prevent reverse rotation five times or less in eight hours, with one minute or more in overrunning direction between backstopping load applications. If backstopping operations are more frequent, or the time between operations is less than one minute, the backstop is classified as an indexing device and must be referred to the Factory.

Installation

1. Drain oil from the drive. If a backstop is being added to an existing drive, for Size 5415, remove and discard the original end cover, Ref. #18; fasteners, Ref. #37; and gasket, Figure 1. For Size 5407, remove and discard the original end cover, Ref. #18; gasket and four short studs. Install longer studs, Ref. #38, provided with the kit. The hex nuts removed from original shaft cover assembly will be required for reassembly.

Figure 1




2. If existing backstop is being replaced for Sizes 5407 & 5415J14, remove cover, Ref. #19; backstop, Ref. #5A1; spacer, Ref. #5A2; and gasket from backstop cage. For Size 5415J25, remove cover, Ref. #19; gasket and backstop cage, Ref. #20, from housing. Remove two (2) retaining rings from bore of backstop cage. Remove backstop, Ref #5A1, from cage. For all drive sizes, note direction of rotation of high speed shaft for proper reassembly. Refer to Section II for shaft and backstop inspection.
3. Remove backstop, Ref. #5A1, from the kit and wipe off excess lubricant.
4. **SIZE 5407 (FIGURE 2)** — Assemble backstop cage, Ref. #20, onto studs using one new .015" (.381 mm) shim-gasket, Ref. #30, against the housing. Slide the spacer, Ref. #5A2, into the backstop cage up against the bearing cup. Apply oil to the O.D. of the high speed shaft backstop journal and the sprags inside of the backstop. Insert key Ref #5A4 into backstop keyway. Align the key with the keyway in the backstop cage and carefully slide the backstop into the bore while slowly rotating the high speed shaft. The shaft will only rotate in one direction. DO NOT FORCE OR HAMMER; this may damage the shaft or misalign the sprags.

Check operation of backstop by turning high speed shaft in required direction of rotation by hand. If the shaft does not rotate in the required direction, remove backstop, reverse it and reinsert it into bore as instructed above. Proceed to Step 9.


Backstop Installation — Sizes 5407 & 5415

Figure 2




5. **SIZE 5415** — Install dowel into cage.
6. **SIZE 5415J14 (FIGURE 3)** — Apply oil to the O.D. of the high speed shaft backstop journal and the sprags inside of the backstop. Insert key, Ref #5A4, into backstop keyway. Align the key with the keyway in the backstop cage and carefully slide the backstop into cage, allowing the backstop to protrude 0.25" (6.4 mm). Coat spacer with grease to assist in holding the spacer against the backstop for assembly and slide into housing side of cage. This spacer will fit between bearing cup and backstop.

Figure 3



7. **SIZE 5415J25 (FIGURE 4)** — Install one (1) retaining ring in groove on backstop. Apply oil to the O.D. of the high speed shaft backstop journal and the sprags inside of the backstop. Insert key, Ref #5A4, into backstop keyway. Align the key with the keyway in the backstop cage and carefully slide the backstop into cage. Install second retaining ring on backstop to hold it in the cage.

Figure 4



8. **SIZE 5415 (ALL TYPES)** — Place one new .015" (.381 mm) shim-gasket, Ref. #30, against housing. **NOTE:** Position gaskets, Ref. #30 and spacer, Ref. #5A2, so that the drain back hole is open. Blocking the drain back hole will not allow oil to lubricate backstop sufficiently and could lead to premature wear, resulting in backstop or drive failure. Carefully install the backstop/cage assembly on the oiled shaft extension while slowly rotating the high speed shaft. The shaft will only rotate in one direction.

DO NOT FORCE OR HAMMER; this may damage the shaft or misalign the sprags.


Check operation of backstop by turning high speed shaft in required direction of rotation by hand. If the shaft does not rotate in the required direction, remove backstop, reverse it and reinstall as instructed in preceding steps.

9. Rotate high speed shaft in the required direction of rotation and then reverse the rotation to lock up the backstop. Observe the position of the sprags. All Sprags must be engaged and lay in the same relative position around the shaft. If the sprags are not uniformly positioned, lightly tap the backstop cage to centralize all the sprags around the shaft and cage. If sprags cannot be uniformly positioned in this manner, remove the backstop and run a finger around the sprags in the overrunning direction. Reinstall backstop as instructed in the preceding steps.

Check the position of the sprags several times by overrunning and locking the sprags. If all sprags move uniformly, hold the backstop in the locked position and proceed to the next assembly step.

10. Install backstop cover, shim-gasket and fasteners, Ref. #19, 29 & 38. **NOTE:** Position gaskets, Ref. #30, and spacer, Ref. #5A2, so that the drain back hole is open. Blocking the drain back hole will not allow oil to lubricate backstop sufficiently and could lead to premature wear, resulting in backstop or drive failure. Cross-tighten fasteners to 70 lb-ft (95 Nm) for Size 5407, and 28 lb-ft (38 Nm) for Size 5415.
11. Clean housing surface for rotation and warning labels. Affix the rotation indicator next to high speed shaft extension to indicate the free direction of rotation, Figure 5. Fill drive to oil level specified in Section I, with oil specified in Appendix A. Check motor for correct rotation before completing connection to drive.

Figure 5



Backstop Installation — Sizes 5507 & 5608

Introduction

The following instructions apply to INSTALLATION ONLY of externally mounted backstop on the high speed shaft of a horizontally mounted Sizes 5507 & 5608 double reduction drives. This backstop is sold only as an accessory for new or existing Falk drives. Do not use for any other application without written approval from Rexnord Industries.

Backstops must not be dismantled or repaired. Backstops are non-serviceable components. Replace damaged backstops with new backstops from .

Remove all external loads from system before servicing drive or accessories and lock out starting switch of prime mover.

Backstop Application

Backstops are designed to prevent reverse rotation or backrun without backlash in applications such as conveyors, bucket elevators, fans, rotary pumps and kilns. Backstops are not approved for use on systems that are designed for handling of people such as elevators, manlifts, ski tows and ski lifts. DO NOT use a backstop as a substitute for a brake.

Indexing

DO NOT use the backstop for indexing applications. The backstop is designed to prevent reverse rotation five times or less in eight hours, with one minute or more in overrunning direction between backstopping load applications. If backstopping operations are more frequent, or the time between operations is less than one minute, the backstop is classified as an indexing device and must be referred to the Factory.

WARNING: The backstop and normal associated equipment (shaft, pulleys, etc.) involve moving parts; therefore, consult local, state, OSHA and ANSI safety codes for proper guarding of rotating members and possible pinch points.

If backstop slippage occurs, DO NOT operate. Install a new backstop before resuming operation.

Lubricant (Grease) – Backstop P/N 2924040 and 2924041

NOTE: Unless specified otherwise, the backstop is furnished filled with grease oil suitable for operation in an ambient temperature range of -30°F to +125°F (-34°C to +52°C).

Consult Factory for lubrication recommendations when ambient temperatures are lower than -30°F (-34°C) or higher than 125°F (52°C), or when drives are operating in extremely humid, chemical, or dust laden atmospheres.

CAUTION: Do not use greases with molybdenum disulfide or other EP additives in external backstops. Use of an improper grease will contribute to premature wear or malfunction of the backstop.

Relubricate the backstop after the first week of operation and at one month intervals thereafter to purge any contaminants or burnishing material from the backstop. To relubricate, select and clean an upper grease fitting and pump grease into the backstop until fresh grease appears at both seals. Refer to manufacturer's service manual (supplied with drive) for detailed maintenance instructions and recommended lubricants.

Lubricant (Synthetic Oil – Backstop P/N 2921858 and 2921859

WARNING: Air vent must be installed before operating drive.

NOTE: Unless specified otherwise, the backstop is furnished filled with synthetic oil suitable for operation in an ambient temperature range of -55°F to +120°F (-48°C to +49°C).

Consult the Factory for lubrication recommendations when ambient temperatures are higher than 120°F (49°C), or when drives are operating in extremely humid, chemical, or dust laden atmospheres.

CAUTION: Do not use lubricant with molybdenum disulfide or other EP additives in external backstops. Use of an improper lubricant will contribute to premature wear or malfunction of the backstop.

Relubricate the backstop every 6 months. Refer to manufacturer's service manual (supplied with drive) for detailed maintenance instructions and recommended lubricants.


Installation

1. Clean the backstop bore and the shaft on which the backstop will be mounted. Remove and clean shaft key and set aside.

CAUTION: Refer to direction of rotation arrow on backstop. Before installation, make certain that the direction of rotation is correct. Check backstop size on nameplate and make certain it is correct.

2. Attach anchor bracket, Ref. #67, to housing using fasteners provided with kit, Figure 6. Tighten fasteners for Size 5507 to 68.8 lb-ft (94Nm) and Size 5608 to 245 lb-ft (332 Nm).
3. Secure backstop, Ref. #5A1, to torque arm, Ref. #68, using fasteners provided with kit, Figure 6. Tighten fasteners to 22 to 27 lb-ft (30 to 37 Nm). Note: Backstop will fit inside counterbore of torque arm. Oil filled backstops only.

Figure 6




When assembling torque arm to clutch, clutch should be position so that the fill/vent fitting can be located nearest to the top when backstop is mounted on the shaft. Customer to remove (1) drain plug and replace with fill/vent plug (wired to torque arm) at start up.


4. Install backstop key into keyway on backstop shaft extension.
5. Align key with keyway in bore of backstop and slide backstop/torque arm assembly onto shaft. Apply pressure to end face of the backstop inner race only. Pressure applied to the outer race could preload the backstop bearings, resulting in a premature failure.

The backstop must slip onto shaft. **DO NOT FORCE OR HAMMER** backstop on shaft. Allow for clearance between tab on anchor bracket and hole in torque arm so that the tab can pass through the hole, Figure 7.

6. Install retaining ring on backstop shaft extension to hold backstop assembly on shaft. **NOTE:** Clearance between backstop and retaining ring allows for backstop assembly to float axially on shaft.

Figure 7


7. Check free and locked rotation of backstop by turning the high speed shaft in required direction of rotation by hand. If the shaft does not rotate in the required direction, remove backstop assembly from shaft, disassemble backstop, Ref. #5A1, from torque arm, Ref. #68, and reverse backstop. Reassemble backstop assembly as instructed in preceding steps.
8. Clean housing surface for rotation and warning labels. Affix the rotation indicator next to high speed shaft extension to indicate the free direction of rotation, as in Figure 8. Check motor for correct rotation before completing connection to drive.

Figure 8


TA Removal Tool


Introduction

The TA removal tool (Patented) offers a positive method for removing a TA Taper equipped Quadrive from the driven shaft. This method uses the torque multiplying characteristic of the drive to separate the drive from the bushing and driven shaft.

The removal tool is available in kit form suitable for use with Sizes 5407 thru 5608. The kit can be ordered from your Rexnord-Falk Distributor by specifying "TA Removal Kit -Part 0769407." **NOTE:** Use of this tool requires a minimum axial clearance ("M" shown in Figure 1 and Table 1), from the seal cage stud.

CAUTION: DO NOT modify the tool in any way OR use it in another manner except to loosen the bushing nut as instructed herein.


Figure 1



WARNING: DO NOT disconnect the drive from its torque arm until the removal process is completed. In addition, the drive must be supported during removal process. Use a sling around the motor mount or as recommended in SECTION I, Step 6. Be sure to take up the slack in the sling before proceeding.

- Loosen the setscrew on the O.D. of the bushing nut. Remove the most convenient seal cage nut and lock washer from the stud. Figure 2.

Figure 2



- Select the proper adapter from the tool kit. (Adapters are marked with the Quadrive Size and part number.) Thread the appropriate adapter onto the stud and apply tightening torque from Table 2.

TABLE 1 — Minimum Tool Clearance

DRIVE SIZE	M Dimension — Inches (mm)
5407	5.12 (130)
5415	5.12 (130)
5507	5.38 (137)
5608	5.12 (130)

TABLE 2 — Adapter Tightening Torque

DRIVE SIZE	Part Number	Torque lb-ft (Nm)
5407	2111960	108 (146)
5415	2111960	108 (146)
5507	2111961	120 (163)
5608	2111960	108 (146)



Preparation For Removal

WARNING: Always "lock out" prime mover before working on the Quadrive.

- Quadrive shafts, high speed and hollow, must be free to rotate.
 - Remove any external load on the driven shaft.
 - Remove belts from high speed shaft sheave.
 - Remove the backstop (if so equipped) when. Refer to Section II — Step 10, for backstop removal instructions.

- Mount the removal tool as illustrated in Figure 3 or 4. It is generally preferable to install the tool in a position where it's weight will tend to keep it engaged into the nut. Rotate the high speed shaft until the tool hook engages one of the slots in the nut.

TA Removal Tool

Figure 3 SIZES 5407, 5415, & 5608

Figure 4 SIZE 5507


Removal Of Quadrive

- Use a spanner wrench to apply torque through the high speed shaft keyway (Type J05 clockwise; Types J14 or J25 counter-clockwise) to loosen the bushing nut.

WARNING: Never use the prime mover to produce the torque needed. This could result in severe personal injury or damage to the equipment.

CAUTION: To avoid damage to the drive or the removal tool, DO NOT exceed the H.S. shaft torque values listed in Table 3.

NOTE: The nut will rotate freely for approximately 180° as it moves from the locked to the removal position. Resistance will indicate that unseating is occurring. Turn until the nut and bushing are completely free. Now, prepare the drive for lifting by disconnecting the torque arm at the drive end.

- ALTERNATE METHOD** — Torque may be applied to the sheave or sprocket mounted on the high speed shaft.

TABLE 3 — Maximum Torque - High Speed Shaft lb-ft (Nm)

DRIVE SIZE	Drive Reduction		
	J05	J14	J25
5407	843 (1143)	302 (410)	167 (226)
5415	902 (1224)	337 (456)	183 (249)
5507	...	372 (504)	205 (278)
5608	...	422 (572)	230 (312)


Motor Mount Installation

Introduction

The Falk Equi-Poised Motor Mount is an all-steel weldment that bolts directly to the steel housing of Falk Shaft Mounted (Type JR), Flange Mounted (Type JF) and Screw Conveyor (Type JSC) Drives, as shown in Figure 1.

This modern design provides a simple means of tensioning V-belts or chains with adjusting screws. Motor base plates are available from the Factory predrilled for NEMA & IEC standard foot mounted motors within the rated capacity of the drive.

Figure 1



Assembly Instructions

From Figure 2, determine which assembly is required. Drives are shown assembled in the 3 o'clock position, high speed shaft relative to low speed shaft. They can also be mounted in the 6, 9 and 12 o'clock positions after the motor mounts are assembled.

WARNING: Remove all external loads from system before servicing drive or accessories.

Consult applicable local and national safety codes for proper guarding of rotating members.


Figure 2 STANDARD ASSEMBLIES



A3
(3 o'clock)




C3
(3 o'clock)



D3
(3 o'clock)

Letter = Motor Mount Position, Number = Drive H.S.S. Clock



OSHA type guard when specified. Dimensions to suit components.

Refer to Appendix L for installation of Falk V-belt guards.

1. ASSEMBLE MOTOR MOUNT BRACKET TO DRIVE.

Remove housing cover fasteners and attach motor mount bracket to housing using longer fasteners provided. Refer to Table 1 for fastener size and tightening torque.

2. ASSEMBLE REAR SUPPORT BRACKET TO DRIVE.

Refer to Table 1 for fastener size and tightening torque.

a. **SIZE 5407 ALL TYPES (FIGURE 3)** — Remove two hex nuts and lock washers from seal cage studs. Remove the two seal cage studs and replace them with the longer studs provided. Mounting position of drive and motor mount will determine which fasteners need to be removed. Using lock washers provided with motor mount and hex nuts previously removed, attach rear support bracket to drive, aligning holes in bracket with seal cage studs.

b. **SIZES 5415JR & 5507JR (FIGURE 3)** — Remove appropriate hex nuts and lock washers from seal cage studs. Mounting position of drive and motor mount will determine which fasteners need to be removed. Using hex nuts and lock washers previously removed, attach rear support bracket to drive, aligning holes in bracket with seal cage studs.

c. **SIZES 5415, 5507, & 5608JF (FIGURE 4)** — Attach rear support to flange using mounting fasteners furnished by user (furnished by Falk for Size 5608JF).

d. **SIZE 5608JR (FIGURE 3)** — Attach rear support bracket to seal cage pads using fasteners provided.

Figure 3 Sizes:
5407 thru 5507JR
5407JF & JSC
5608JR






Figure 4 Sizes:
5415 thru
5608JF



Motor Mount Installation

3. **ASSEMBLE SUPPORT BRACKET TO MOTOR MOUNT BRACKET** — Use the fasteners provided. Refer to Table 1 for fastener size and tightening torque.
4. **ASSEMBLE BASE PLATE TO MOTOR MOUNT BRACKET (FIGURE 1)** — Assemble adjusting screws to motor mount bracket and base plate with jam nuts above and below the base plate.
5. **MOUNT MOTOR** — Position motor on base plate so that all mounting holes are in alignment. Install and tighten motor fasteners.
6. **SPROCKET, PULLEY OR SHEAVE CONNECTION** — Mount power takeoffs as close to drive and motor housing as possible to avoid undue bearing load and shaft deflection. Align the high speed shaft of drive square and parallel with motor shaft by placing a straightedge across the face of the sprockets or sheaves as illustrated. Check horizontal shaft alignment by placing one leg of a square against the face of the sheave or sprocket with the spirit level on the horizontal leg of the square.



Adjustment of the belt or chain is accomplished by turning adjusting screws evenly. DO NOT over tighten belts or chains. Over tightening belts or chains reduces belt/chain and bearing life. When the required tension is reached, tighten adjusting screw jam nuts to torques listed in Table 1. Adjust chain tension to manufacturers' specifications. Adjust belts as follows:

The ideal belt tension is the lowest tension at which the belt will not slip under peak load conditions. Check belt tension frequently during the first 24 to 48 hours of run-in operation. Keep belts free from foreign material which may cause slippage. Inspect the V-belt drive periodically; retighten belts if they are slipping.

TABLE 1 — Fastener Size and Tightening Torque ★

DRIVE SIZE	Motor Mount to Housing		Support to Seal Cage		Support to Motor Mount		Support to Flange		Adjusting Screws	
	Size	Torque lb-ft (Nm)	Size	Torque lb-ft (Nm)	Size	Torque lb-ft (Nm)	Size	Torque lb-ft (Nm)	Size	Torque lb-ft (Nm)
5407	.500-13UNC x 2.25	69 (94)	.750-10UNC	330 (447)	.500-13UNC x 1.75	69 (94)	.750-10UNC	330 (447)	1.250-7UNC †	362 (491)
5415	.500-13UNC x 2.50	69 (94)	.750-10UNC	330 (447)	.500-13UNC x 1.75	69 (94)	1.250-7UNC ‡	1050 (1424)	1.250-7UNC †	362 (491)
5507	.500-13UNC x 2.50	69 (94)	.875-9UNC	533 (723)	.500-13UNC x 1.75 •	69 (94)	1.250-7UNC ‡	1050 (1424)	1.250-7UNC †	362 (491)
5608	.750-10UNC x 3.25	245 (332)	.750-10UNC	330 (447)	.750-10UNC x 1.75	245 (332)	.750-10UNC x 2.00	245 (332)	1.250-7UNC	362 (491)

★ All fasteners are Grade 5.

† Size .625-11UNC x 6.00 fasteners are furnished with motor mount for select motor frame sizes. Tighten these fasteners to 60 lb-ft (81 Nm).

‡ Fasteners furnished by customer.

• Size .750-10UNC x 2.25 fasteners are furnished with motor mount for select motor frame sizes. Tighten these fasteners to 245 lb-ft (332 Nm).

Vertical Standpipe Installation

Introduction

The following instructions apply to the installation of standpipe kits to standard drives mounted for vertical operation (high speed shaft up or down). Drawings are representative of this series of drives and may not agree in exact detail with all drive sizes.

NOTE: Vertical shaft drives, when filled to the proper oil level, are completely full of oil.


High Speed Shaft Down — Figure 1

- After installing the drive per the Owners Manual installation instructions, determine which of the upper side plug locations on the drive will provide the best location for the standpipe, observing clearance required to remove dipstick (Dimension D, Table 1). Discard the air vent. When the air vent location is not used for the standpipe, relocate the pipe plug from the selected standpipe location to the air vent location. Recoat pipe plug threads with Permatex #3 or equivalent sealant before reinstalling.
- Coat all pipe threads of kitted parts with Permatex #3 or equivalent sealant.

TABLE 1 — Dimensions

DRIVE SIZE	Inches (mm)			
	A	B	C	D
5407	0.75 (19)	1.25 (32)	1.75 (44)	24.3 (617)
5415	0.90 (23)	1.40 (36)	1.90 (48)	21.3 (541)
5507	0.92 (23)	1.42 (36)	1.92 (49)	21.3 (541)
5608	1.03 (26)	1.53 (39)	2.03 (52)	20.6 (523)

Figure 1




- Assemble kitted parts to the drive as illustrated in Figure 1 and then secure the standpipe with an external support to maintain its vertical position.
- Carefully measure Dimension X as illustrated in Figure 1.
- From Table 1:
 - $X + A$ equals oil level "Full" mark.
 - $X + B$ equals oil level "Low" mark.
 - $X + C$ equals dipstick length.

- Scribe Dimensions $X + A$ and $X + B$ on the dipstick as illustrated in Figure 1. Make measurements from the felt pad in the dipstick cap.
- Lightly chisel permanent oil level marks on the scribed lines and cut the dipstick to the length marked. File end of dipstick smooth.
- Install magnetic drain plug (furnished) in oil drain location.
- Remove the oil filler plug. Add oil until the oil level reaches the "Full" mark on the dipstick. Coat the filler plug (not vented) with Permatex #3 or equivalent sealant and replace it.
- Filler plug must always be removed to relieve entrapped air before checking oil level.

High Speed Shaft Up — Figure 2

- After installing the drive per the Owners Manual installation instructions, determine which of the lower four side plug locations on the drive will provide the best location for the standpipe, observing clearance required to remove dipstick (Dimension D, Table 1). Discard the air vent. When the air vent location is not used for the standpipe, relocate the pipe plug from the selected standpipe location to the air vent location. Recoat pipe plug threads with Permatex #3 or equivalent sealant before reinstalling.

Figure 2



Vertical Standpipe Installation

2. Coat all pipe threads of kitted parts with Permatex #3 or equivalent sealant.
3. Assemble kitted parts to drive as illustrated in Figure 2 and then secure the standpipe with an external support to maintain its vertical position.
4. Carefully measure Dimension X as illustrated in Figure 2.
5. From Table 1:
 - X + A equals oil level "Full" mark.
 - X + B equals oil level "Low" mark.
 - X + C equals dipstick length.
6. Scribe Dimensions X + A and X + B on the dipstick as illustrated in Figure 1. Make measurements from the felt pad in the dipstick cap.
7. Lightly chisel permanent oil level marks on the scribed lines and cut the dipstick to the length marked. File end of dipstick smooth.
8. Install magnetic drain plug (furnished) in oil drain location.
9. Remove the oil filler plug. Add oil until the oil level reaches the "Full" mark on the dipstick. Coat the filler plug (not vented) with Permatex #3 or equivalent sealant and replace it.
10. Filler plug must always be removed to relieve entrapped air before checking oil level.

Modifications For Non-Standard Mounting Positions

Instructions


For non-standard mountings, modify drives as illustrated below and on Page 37 to assure satisfactory lubrication. For applications that exceed the limits shown, drives that are both rotated AND tilted and for with backstops, consult Factory.

CAUTION: Inadequate lubrication will cause damage.

When replacing a pipe plug (P) with a street elbow (E), insert the plug in the elbow (E/P). When replacing a pipe plug (P) with a street elbow (E), pipe nipple (N) and a pipe cap (C), discard the pipe plug. Kits consist of parts for an oil expansion chamber. Pipe fittings and kits tabulated on Page 37 are available from Rexnord. Pipe fittings may also be purchased locally. Use galvanized pipe fittings.

Remove all pipe plugs and coat them and the added parts, with Permatex #3 or equivalent to prevent leakage. Install parts as illustrated to suit the mounting position. The air vent must be in the top of the drive or in the kit standpipe. Fill drives with oil to the level indicated by the letter "L" in the following drawings.

Standard Drive Mounting Limits




The 10° Max rotation illustrated at the left applies to standard 3, 6, 9 & 12 o'clock mountings. For higher limits, follow the instructions at the left and the drawings below. (6 o'clock illustrated)

- CODE
- | | |
|-------------------------------|------------------------|
| B — Reducing Bushing | L — Oil Level |
| C — Cap | N — Nipple |
| E — Street Elbow | P — Pipe Plug |
| K — Oil Expansion Chamber Kit | STD — No Modifications |

Horizontal Drive Modifications for 10 to 20° Drive Rotation


10 to 20° Clockwise Rotation

3 O'Clock — CW Rotation




5407 = KIT 0786777
5415 THRU 5608 = KIT 0786778

6 O'Clock — CW Rotation




5407 = .750 E/C & .750 x 1.375 N
5415 & 5507 = 1.250 E/C & 1.250 x 1.625 N
5608 = 1.25 E/P

9 O'Clock — CW Rotation



5407 = KIT 0786777
5415 THRU 5608 = KIT 0786778


12 O'Clock — CW Rotation



5407 = .750 E/C & .750 x 1.375 N
5415 & 5507 = 1.250 E/C & 1.250 x 1.625 N
5608 = 1.25 E/P


10 to 20° Counterclockwise

3 O'Clock — CCW Rotation




5407 = .750 E/C & .750 x 3.00 N
5415 = 1.250 E/C & 1.250 x 3.00 N
5507 = 1.250 E/C & 1.250 x 3.50 N
5608 = 1.250 E/C & 1.250 x 2.50 N

6 O'Clock — CCW Rotation



5407, 5415, 5507, & 5608 = STD


9 O'Clock — CCW Rotation



5407 = .750 E/C & .750 x 1.375 N
5415 & 5507 = 1.250 E/P
5608 = STD

* This oil level applies when only a street elbow with a pipe plug is used.

12 O'Clock — CCW Rotation




5608

5407, 5415 & 5507 = STD
5608 = KIT 0786778

Modifications For Non-Standard Mounting Positions

Standard Drive Mounting Limits



The limits illustrated at the left applies to standard 3, 6, 9 & 12 o'clock mountings. For higher incline limits, follow the instructions on Page 36 and the drawings below. (6 o'clock illustrated)

- 4407 & 4415 = 0° INCLINE DOWN ON DRIVES WITH BACKSTOPS IN 9 OR 12 O'CLOCK MOUNTING POSITION.
- ▲ 4507 & 4608 = 5° INCLINE ON DRIVES WITH BACKSTOPS IN ALL MOUNTING POSITIONS.

CODE

C — Cap
E — Street Elbow
K — Oil Expansion Chamber Kit

L — Oil Level
N — Nipple
P — Pipe Plug
STD — No Modifications

Standard Pipe Fittings ★ — Inches


.750-14 NPT	Falk No.	1.25-11.5 NPT	Falk No.
.750 Street Elbow	0915253	1.25 Street Elbow	0915255
.750 Cap	0914804	1.25 Cap	0914806
.750 x 1.375 Nipple	0915824	1.25 x 1.625 Nipple	0915882
.750 x 3 Nipple	0915836	1.25 x 2.5 Nipple	0915885
.750 x .500 Bushing	0914652	1.25 x 3 Nipple	0915886
		1.25 x 3.5 Nipple	0915897
		1.25 x .500 Bushing	0914656

★ Kits: Falk Nos. 738471 Oil expansion chamber parts. All pipe fittings are galvanized.


Horizontal Drive Modifications for Inclined H.S. Shaft

H.S. Shaft Inclined 20 to 30° Up


3 O'Clock H.S.S. Up




6 O'Clock H.S.S. Up



9 O'Clock H.S.S. Up




12 O'Clock H.S.S. Up




H.S. Shaft Inclined 5 to 30° Down


3 O'Clock H.S.S. Down




6 O'Clock H.S.S. Down



9 O'Clock H.S.S. Down



12 O'Clock H.S.S. Down



NOTE: FOR SIZES 5507 & 5608 WITH BACKSTOP, MAXIMUM INCLINE IS 5° (ALL CLOCK POSITIONS).



Retaining Rings For Bushing Nuts And Thrust Plates

JR — Retaining Rings For Bushing Nuts

DRIVE SIZE	Manufacturer Part Number
5407	Truarc N5000-650
5415	Truarc N5000-725
5507	Truarc N5000-775
5608	Truarc N5000-900

JF & JSC — Retaining Rings For Thrust Plate Kits

DRIVE SIZE	Manufacturer Part Number
5407	Truarc N5000-500
5415	Eaton IN550
5507	Truarc N5000-600
5608	Truarc N500-725

Seal Housing Lip Seal For Type JSC

Type JSC — Seal Housing Lip Seal

DRIVE SIZE	Falk Part No.	Manufacturer Part No.
		Chicago Rawhide
5407	2913658	39320

Tooth Combinations For Vibrations Analysis

Type J05 — Tooth Combinations

DRIVE SIZE	Exact Ratio	Pinion Ref. #3A3	Gear Ref. #4A4
5407	4.938	16	79
5415	5.077	13	66
5507	4.929	14	69
5608	5.000	13	65


Type J14 — Tooth Combinations

DRIVE SIZE	Exact Ratio	Input		Output	
		Pinion Ref. #1A3	Gear Ref. #1A4	Pinion Ref. #2A3	Gear Ref. #4A4
5407	13.89	16	45	16	79
5415	13.61	25	67	13	66
5507	13.46	26	71	14	69
5608	13.82	17	47	13	65

Type J25 — Tooth Combinations

DRIVE SIZE	Exact Ratio	Input		Output	
		Pinion Ref. #1A3	Gear Ref. #1A4	Pinion Ref. #2A3	Gear Ref. #4A4
5407	25.04	14	71	16	79
5415	26.11	14	72	13	66
5507	24.29	14	69	14	69
5608	25.33	15	76	13	65

Drive Shaft Recommendations for Tapered Drive Shafts



Dimensions – Inches (mm) ★

DRIVE SIZE	Keyway		D • +0.000, -0.005 (+0,00, -0,13)	DA	LA ±.030 (±.76)	LB +0.000, -0.010 (+0.000, -0.250)	LC +0.040, -0.000 (+1.02, -0.00)	LD	LE	MD =	S	T Min	Key		
	W ‡	L ±.010 (±0,25)											W	H	L
5407	1.000 (25,40)	7.000 (177,80)	4.925 (125,10)	5.175 (131,45)	0.500 (12,70)	4.374 (111,10)	9.250 (234,95)	5.25 (133,4)	2.25 (57,2)	2.45 (62,2)	1.000-8	2.75 (69,8)	1.000	0.750	6.00
5415	1.250 (31,75)	8.750 (222,25)	5.455 (138,56)	5.767 (146,48)	1.000 (25,40)	4.864 (123,54)	10.925 (277,50)	6.00 (152,4)	2.50 (63,5)	2.85 (72,4)	1.250-7	2.50 (63,5)	1.250	0.875	7.50
5507	1.250 (31,75)	9.000 (228,60)	6.003 (152,48)	6.327 (160,71)	1.000 (25,40)	5.368 (136,35)	12.020 (305,31)	7.00 (177,8)	2.50 (63,5)	3.10 (78,7)	1.250-7	2.50 (63,5)	1.250	0.875	7.75
5608	1.500 (38,10)	11.500 (292,10)	7.277 (184,84)	7.617 (193,47)	1.000 (25,40)	6.061 (153,95)	13.875 (352,42)	8.50 (215,9)	3.00 (76,2)	3.21 (81,5)	1.250-7	3.00 (76,2)	1.500	1.500	10.00

★ Dimensions are for reference only and are subject to change without notice unless certified.

‡ Inch keyway width tolerances are as follows: over .500" (12,70) to & including 1.000" (25,40) = +.0030" (+0,076), -0.0000" (-0,000), over 1.000" (25,40) to & including 1.500" (38,10) = +.0035" (+0,089), -0.0000" (-0,000). Inch keyway depth tolerance is +.010" (+0,25), -0.000" (-0,00).

● Straight diameter is used to aid in measurement and manufacture of the keyway.

■ Dimension "MD" will vary slightly depending on degree of axial compression during installation and manufacturing tolerances.

Drive Shaft Recommendations Using TA Taper Bushing

INTRODUCTION — These instructions are for use when a flange mounted 5407-5608JF drive is to be used and the manufacture of a tapered drive shaft is not feasible. For JF tapered drive shaft recommendations, see Appendix H. Use this appendix to retrofit existing applications or for outfitting new installations. Parts required are the drive, TA Taper bushing and a thrust plate kit.

This appendix will allow the use of a straight drive shaft with the tapered bushing (without spanner nut) on flange mounted applications. Provided are dimensions (Table 4) for shaft recommendations and instructions for the installation and removal of the assembly. All bushing bore sizes, which are available in the standard Quadrive, are possible with this setup.

FIGURE 2 — 5407-5608JF drives are furnished with a flange adapter installed. The hollow shaft of the drive has a tapered bore which accepts the tapered bushing. When the bushing is drawn into the taper, a clamping force is applied to the drive shaft. The drive shaft is drawn into the hollow shaft via a fastener in the thrust plate. The bushing seats against a shoulder on the driven shaft and is drawn into the drive with the shaft. Removal is accomplished by using a jackscrew in the thrust plate and forcing the drive shaft out of the drive. The retaining ring in the drive shaft assures that the bushing will be removed along with the shaft.

DRIVE SHAFT RECOMMENDATIONS — The recommendations for the drive shaft consist of two major features. The first is the shoulder which must be provided in the location shown in Figure 2. This shoulder provides the backing necessary to draw the bushing into the taper. A permanently fixed shoulder must be provided in order for this design to be effective. The shoulder may be a welded collar or an integral step. SET COLLARS ARE NOT ACCEPTABLE. A retaining ring may be used, in the driven shaft, to provide the shoulder, but stress concentrations occur at the groove and therefore shaft stresses must be checked. The second major feature on the shaft is the retaining ring groove in the shaft end. This feature is recommended to ensure positive removal of the bushing when the drive shaft is removed from the drive. The threaded hole in the end of the drive shaft accepts the thrust plate fastener.

WARNING: Lock out power source and remove all external loads from system before servicing drive or accessories.

INSTALLATION PROCEDURE — With the drive shaft manufactured per the recommendations shown, and the bushing selected for the proper shaft diameter, remove and discard the retaining ring and spanner nut from the bushing assembly.

5407JF — Use of the tapered bushing requires that the flange of the bushing be removed to clear the adapter, Figure 2. A flangeless bushing is available for the 3.4375" (87 mm) diameter shaft only.

ALL JF DRIVES — Slide the bushing (flange end first) onto the drive shaft until it contacts the shoulder on the shaft. Insert the key through the bushing and into the drive shaft keyway. Install the retaining ring into the groove in the drive shaft. Bring the drive into position, line up the hollow shaft keyway with the key and slide the bushing and drive shaft into the hollow shaft bore.

Attach the drive to the mounting surface with fasteners (not provided). Refer to Table 1 for fastener size and tightening torque. Assemble the thrust plate and retaining ring into the counterbore in the hollow shaft. Insert the thrust plate fastener

through the thrust plate and thread into the drive shaft end. Tighten to the torque given in Table 2. Install all covers and guards.

REMOVAL PROCEDURE — Remove hollow shaft cover. Remove the thrust plate fastener, retaining ring and thrust plate from the hollow shaft. Refer to Table 3 and select a backing bolt and flat washer and install them into the drive shaft as illustrated in Figure 1. The head of the backing bolt provides a working surface for the removal bolt. Reinsert the thrust plate and retaining ring into the hollow shaft and select a removal bolt from Table 3. Thread the removal bolt into the thrust plate until it contacts the backing bolt head. Tighten the removal bolt to the torque indicated in Table 3. (If the thrust plate rotates in the shaft, align the slot in the plate with the hollow shaft keyway and insert a screw driver or piece of key stock to prevent rotation of the plate). After torquing the bolt, as instructed, strike the bolt sharply with a hammer and retorque the bolt if separation of the drive from the shaft did not occur. Repeat this procedure, retorquing the bolt after each blow, until separation occurs.




TABLE 1 — JF Drive – Foundation Fastener & Tightening Torque (Non-Lubricated Fasteners)


DRIVE SIZE	Fastener Size & Grade	Max.Tightening Torque lb-ft (Nm)
5407	.750-10UNC, Grade 5	245 (332)
5415	1.250-7UNC, Grade 5	1050 (1424)
5507	1.250-7UNC, Grade 5	1050 (1424)
5608	1.500-6UNC, Grade 5	1842 (2497)

TABLE 2 — Thrust Plate Fastener Data (Non-Lubricated Fasteners)

DRIVE SIZE	Fastener Size & Grade	Max Tightening Torque lb-ft (Nm)	Min Thread Depth Inches (mm)
5407	1.000-8UNC x 5.50, Grade 8	792 (1073)	2.75 (69.8)
5415	1.250-7UNC x 6.00, Grade 8	1596 (2164)	3.00 (76.2)
5507	1.250-7UNC x 6.00, Grade 8	1596 (2164)	3.00 (76.2)
5608	1.250-7UNC x 8.00, Grade 8	1596 (2164)	3.50 (88.9)

Drive Shaft Recommendations Using TA Taper® Bushing

Figure 2


TABLE 3 — Removal & Backing Bolt Size and Tightening Torque

DRIVE SIZE	Removal Bolt Size & Min Length – Inches	Max Tightening Torque lb-ft (Nm)	Backing Bolt Size & Max Length – Inches
5407	1.125-7UNC x 3.00	742 (1006)	1.000-8UNC x 2.50
5415	1.500-6UNC x 3.75	1842 (2497)	1.250-7UNC x 2.75
5507	1.500-6UNC x 3.75	1842 (2497)	1.250-7UNC x 2.75
5608	1.500-6UNC x 3.75	1842 (2497)	1.250-7UNC x 2.75

TABLE 4 — Dimensions For Largest Bore Bushing – Inches (mm) ★

DRIVE SIZE	Thrust Plate Kit †	Thrust Plate Part No.	A ± 0.010 (±0,25)	B ± 0.030 (±0,75)	C ‡	D •	DA ■	DB Min	Retaining Ring ♦				Keyway *			S	T Min
									Groove		Spir O Lox		W	H	L Min		
									F	G	Mfg No.	Max O.D.					
5407	TP5407JF	0778780	8.160 (207,26)	8.500 (215,90)	1.384 (35,15) 1.037 (26,34)	5.250 (133,35)	4.4375	4.750 (120,65)	4.059 4.071	0.120 0.125	RSN-425	4.688	1.000	0.5000	7.750 (196,85)	1.000-8	2.75 (69,8)
5415	TP5415JF	0778781	10.100 (256,54)	10.375 (263,52)	0.867 (22,02) 0.520 (13,21)	...	4.9375	5.250 (133,35)	4.616 4.604	0.079 0.084	RS-475	5.125	1.250	0.6250	9.563 (242,90)	1.250-7	3.00 (76,2)
5507	TP5507JF	0778782	10.440 (265,18)	10.750 (273,05)	0.617 (15,67) 0.269 (6,83)	...	5.4375	5.750 (146,05)	5.114 5.100	0.079 0.084	RS-525	5.688	1.250	0.6250	9.875 (250,82)	1.250-7	3.00 (76,2)
5608	TP5608JF	0778783	12.530 (318,26)	13.000 (330,20)	2.639 (67,03) 2.292 (58,22)	...	6.5000	7.000 (177,80)	5.993 5.977	0.174 0.182	RSN-625	6.813	1.500	0.7500	12.625 (320,68)	1.250-7	3.50 (88,9)

★ For metric drive shafts or bushing bores smaller than the maximum, provide the retaining ring groove per manufacturers' recommendations, keyway appropriate for the shaft diameter, and DB minimum of 0.300" (7.62 mm) larger than the bushing bore to provide adequate backing.

† Kit consists of: thrust plate, thrust plate fastener, hollow shaft retaining ring and drive shaft retaining ring.

‡ The range for C dimensions is the variation which may occur due to axial compression and manufacturing tolerances.

• The D dimension is the recommended minimum bore which clears the TA Taper bushing flange.

■ Shaft diameter tolerances are per AGMA as follows: over 2.50" to & including 4.00" = +.000", -.006"; over 4.00" to & including 6.00" = +.000", -.007"; over 6.00" to & including 7.00" = +.000", -.008". Metric drive shafts are to be based on h10 tolerances.

♦ Smalley retaining rings may be used instead of Spir O Lox by substituting WS for RS, WST for RST or WSM for RSN.

* Inch keyway widths are as follows: .500" to & including 1.000" = +.0030", -.0000"; over 1.000" to & including 1.500" = +.0035", -.0000". Metric keyway widths are based on class N9 tolerances. Inch keyway depth tolerance is +.010", -.000". Refer to ISO 773 or DIN 6885 sheet 1 for metric keyway depth tolerances.

Drive Shaft Recommendations Using (TCB) Kit

INTRODUCTION — These instructions are for use when a screw conveyor 5407JSC drive is to be used and the following conditions exist: Falk standard or 316 stainless steel JSC tapered drive shafts can not be used due to special extension dimensions or materials; or manufacturing a special tapered drive shaft is not feasible. Use this appendix to retrofit existing applications or for outfitting new installations where the above conditions warrant. For tapered shaft recommendations, see Appendix H.

This appendix will allow the use of a straight (non tapered) drive shaft with a special bushing conversion kit on screw conveyor applications. The bushing conversion kit may also be used on flange mounted 5407JF applications where the Falk JSC seal housing is to be used as the mounting flange. This kit provides one bushing bore per drive size as shown in Table 4. Provided in this appendix are dimensions for drive shaft recommendations and instructions for the installation and removal of the assembly.

FIGURE 2 — The hollow shaft of the drive has a tapered bore which accepts the tapered bushing. When the bushing is drawn into the taper, a clamping force is applied to the drive shaft. The drive shaft is drawn into the hollow shaft via a fastener in the thrust plate. The bushing seats against a shoulder on the drive shaft and is drawn into the drive with the shaft. Removal is accomplished by using a jackscrew in the thrust plate and forcing the drive shaft out of the drive. The retaining ring in the drive shaft assures that the bushing will be removed along with the shaft.

DRIVE SHAFT RECOMMENDATIONS — The recommendations for the drive shaft consist of two major features. The first is the shoulder which must be provided in the location shown in Figure 2. This shoulder provides the backing necessary to draw the bushing into the taper. A permanently fixed shoulder must be provided in order for this design to be effective. The shoulder may be a welded collar or an integral step. SET COLLARS ARE NOT ACCEPTABLE. A retaining ring may be used in the drive shaft, to provide the shoulder, but stress concentrations can occur at the groove and therefore shaft stresses must be checked. The second major feature on the shaft is the retaining ring groove in the shaft end. This feature is recommended to ensure positive removal of the bushing when the drive shaft is removed from the drive. The threaded hole in the end of the drive shaft accepts the thrust plate fastener.

WARNING: Lock out power source and remove all external loads from system before servicing drive or accessories.

INSTALLATION PROCEDURE — With the shaft manufactured per the recommendations shown, proceed as follows:

The seal housing may be assembled to the drive before or after the drive shaft is installed into the drive, but if the seal housing is installed to the drive first, the lip type seal (if used) must be installed from the extension end.

Slide the bushing (large end first) onto the drive shaft until it contacts the shoulder on the shaft. Insert the key through the bushing and into the drive shaft keyway. Install the retaining ring into the groove in the drive shaft. Line up the keyway in the drive hollow shaft with the key in the drive shaft and slide shaft/bushing assembly into the hollow shaft. Attach the seal housing to the drive with the fasteners provided. Tighten fasteners to torque given in Table 1. Assemble the thrust plate and retaining ring into the counterbore in the hollow shaft.

Insert the thrust plate fastener through the thrust plate and thread into the drive shaft end. Tighten to the torque given in Table 2. Install all covers and guards.

REMOVAL PROCEDURE — Remove low speed shaft input end cover. Remove the thrust plate fastener, retaining ring and thrust plate from the hollow shaft. Refer to Table 3 and select a backing bolt and flat washer and install them into the drive shaft as illustrated in Figure 1. The head of the backing bolt provides a working surface for the removal bolt. Reinsert the thrust plate and retaining ring into the hollow shaft and select a removal bolt from Table 3. Thread the removal bolt into the thrust plate until it contacts the backing bolt head. Tighten the removal bolt to the torque indicated in Table 3. (If the thrust plate rotates in the shaft, align the slot in the plate with the hollow shaft keyway and insert a screwdriver or piece of key stock to prevent rotation of the plate). After torquing the bolt, as instructed, strike the bolt sharply with a hammer and retorque the bolt if separation of the drive from the shaft did not occur. Repeat this procedure, retorquing the bolt after each blow, until separation occurs.

Figure 1




TABLE 1 — Seal Housing Fastener Tightening Torque (Non-Lubricated Fasteners)


DRIVE SIZE	Fastener Size & Grade	Max Tightening Torque lb-ft(Nm)
5407	.750-10UNC	330 (447)

TABLE 2 — Thrust Plate Fastener Data (Non-Lubricated Fasteners)

DRIVE SIZE	Fastener Size & Grade	Max Tightening Torque lb-ft (Nm)	Min Thread Depth Inches (mm)
5407	1.000- 8UNC x 5.50, GR.8	792 (1074)	2.75 (69.8)

Drive Shaft Recommendations Using (TCB) Kit

Figure 2


TABLE 3 — Removal & Backing Bolt Size and Tightening Torque

DRIVE SIZE	Removal Bolt Size & Min Length – Inches	Max Tightening Torque lb-ft (Nm)	Backing Bolt Size & Max Length – Inches
5407	1.125- 7UNC x 3.00	742 (1006)	1.000- 8UNC x 2.50

TABLE 4 — Dimensions – Inches (mm)

Taper Conversion Bushing Kit †	(TCB) Kit Part No.	A ± 0.010 (± 0,25)	B ± 0.030 (± 0,75)	C ‡	DA •	DB ■ +0.000, - 0.003 (+0,00, - 0,08)	Retaining Ring ♦			Keyway *			S	T Min	Weld/Integral Flange		
							Groove		Mfg No.	Max O.D.	W	H			L Min	U	V
							F	G									
TCB5407J-3.438	0786823	7.655 (194,44)	9.500 (241,30)	1.879 (47,73) 1.552 (39,42)	3.4375	3.938 (100,03)	3.263 3.251	0.103 0.108	Spir O Lox RSN-343	...	0.875	0.4375	9.250 (234,95)	1.000-8	2.75 (69,9)	1.500 (38,10)	...

† Kit consists of: Bushing, thrust plate, fastener, key, retaining ring, and hardware.

‡ The range of C dimension is the variation which may occur due to axial compression and manufacturing tolerances.

• Shaft diameter tolerances are per AGMA as follows: over 2.50" to & including 4.00" = +.000", - .006".


■ If a lip type seal is used, a 32rms finish is recommended.

♦ Smalley retaining rings may be used instead of Spir O Lox by substituting WSM for RSN.


* Inch keyway width tolerances are as follows: over .500" to & including 1.000" = +.0030", -.0000"; 1.000". Inch keyway depth tolerance is +.010", -.000".

OSHA V-Belt Guard Installation For Drives Without Shaft Fan

1. ASSEMBLE MOTOR MOUNT AND MOTOR TO DRIVE AS INSTRUCTED IN APPENDIX D





4. ASSEMBLE THREADED RODS TO BACKPLATE & MOUNT SLOT COVER(S) AS REQUIRED




2. ASSEMBLE BELT GUARD BRACKETS TO MOTOR MOUNT

A9 MOTOR MOUNT POSITION




B9 MOTOR MOUNT POSITION




C9 MOTOR MOUNT POSITION


5. MOUNT BELT DRIVE AS INSTRUCTED IN APPENDIX D



3. ASSEMBLE BACKPLATE TO BRACKETS



6. MOUNT COVER AND APPLY WARNING LABEL




OSHA V-Belt Guard Installation For Drives With Shaft Fan


WARNING: Consult applicable local and national safety codes for proper guarding of rotating members.

WARNING: Lock out power source and remove all external loads from drive before servicing drive or accessories


1. ASSEMBLE MOTOR MOUNT AND MOTOR TO DRIVE AS INSTRUCTED IN APPENDIX D




4. ASSEMBLE THREADED RODS TO BACKPLATE & MOUNT SLOT COVER(S) AS REQUIRED




2. ASSEMBLE GUARD MOUNTING BRACKET & ADAPTER TO GUARD BACKPLATE




5. MOUNT BELT DRIVE AS INSTRUCTED IN APPENDIX D



3. ASSEMBLE BACKPLATE WITH ADAPTER TO SHROUD



6. MOUNT COVER




Electric Fan Installation

Introduction

The following instructions apply to the installation of the electric fan. The sump temperature switch is provided as a standard feature.

The sump temperature switch features dual settings for two independent single-pole, double-throw circuits. Only one circuit is used to control the fan. The remaining circuit may be used to control a warning light, an alarm, or a motor shutdown switch if the temperature setting is exceeded. The sump temperature switch wiring diagram is given in Figure 1.

Figure 1



Refer to Figure 2 for electric fan, temperature switch and bulb well standard mounting locations. The bulb well houses the sump temperature probe. These mounting locations are based on drive mounting position.

Figure 2

ELECTRIC FAN, TEMP. SWITCH & BULB-WELL STANDARD LOCATIONS (BASED ON DRIVE MOUNTING POSITION)

DRIVE WITH MOTOR MOUNT			DRIVE W/O MOTOR MOUNT
			3 O'CLOCK
			6 O'CLOCK
			9 O'CLOCK
			12 O'CLOCK


Assembly Instructions

WARNING: Consult applicable local and national safety codes for proper guarding of rotating members.

Lock out power source and remove all external loads from drive before servicing drive or accessories.

1. Drain oil from the drive.
2. **ELECTRIC FAN PANEL REWORK** — The holes in the electric fan panel must be enlarged to accommodate the fasteners used to mount the electric fan to the shroud. Align the fan panel to the shroud. Locate and drill four 0.4375" (12 mm) diameter clearance holes in line with the pre-drilled holes in the shroud.
3. Insert four 1.25" (32 mm) cap screws through the fan mounting holes in the shroud with the threaded portion of the cap screw away from the drive. Secure the cap screws to the shroud with flat washer (2 washers for 5407) and nut, see Figure 3.


Figure 3




4. Secure the sump temperature switch to the switch mounting bracket. Attach the switch and mounting bracket to the fan shroud, refer to Figure 2 for location.
5. Install the temperature probe bulb well in the designated drain hole as shown in Figure 4. Refer to Figure 2 for bulb well location.

CAUTION: Sump temperature probe must be located below oil level.

Figure 4



6. Mount the shroud on drive using spacers and hardware, see Figure 5.

Figure 5


7. Place the temperature probe in bulb well and secure capillary to the shroud by using one or two cable straps to remove extra slack, refer to Figure 4.

CAUTION: Do not crimp capillary.

8. Install split nut in the bulb well to retain the temperature probe.
9. Sump temperature switch settings:
 - a) Remove the two screws and cover from the top of switch to reveal the sump temperature switch setting wheels. Set the low circuit to turn the electric fan on at 140°F (60°C). Set the high circuit at 210°F (99°C) to engage alarm or main motor cutout.
 - b) Remove the four screws and cover from the front of the sump temperature switch to reveal the differential setting wheels. Rotate the wheels to the full clockwise position as viewed from the top of the switch. This is the maximum temperature differential setting of 15°F (9°C). Replace the cover and four screws.
10. Fill drive to oil level specified in Section I with oil specified in Appendix A.
11. Position the electric fan panel on the remaining threaded portion of the cap screws from Step 2 and secure it to the shroud with four locknuts, see Figure 3.
12. Remove the condensation plug from the bottom of the electric fan.
13. Place the button plug in the shroud, see Figure 5.
14. Connect the electric fan to the power source per local and national electrical codes.



REXNORD INDUSTRIES, LLC
P.O. Box 492
Milwaukee, WI 53201-0492 USA