


# Jupiter Owners' Manual



# TABLE OF CONTENTS

## Jupiter—Owners' Manual

<b>Section 1.0.</b>	<i>Introduction</i>	1
<b>Section 2.0.</b>	<i>Installation</i>	2-3
<b>Section 3.0.</b>	<i>Lubrication</i>	4
<b>Section 4.0.</b>	<i>Start-up</i>	5
<b>Section 5.0.</b>	<i>Maintenance</i>	6
<b>Section 6.0.</b>	<i>Disassembly and Assembly Instructions</i>	7-15
<b>Section 7.0.</b>	<i>Storage Procedures</i>	16
<b>Section 8.0.</b>	<i>Troubleshooting</i>	17
<b>Section 9.0.</b>	<i>Tables</i>	18
<b>Section 10.0.</b>	<i>Tables: Replacement Seals and Bearings</i>	19
<b>Section 11.0.</b>	<i>Maintenance Log</i>	20
<b>Section 12.0.</b>	<i>Accessories</i>	22

## Section 1.0

### Introduction

The following instructions apply to Jupiter **Planetgear™** Speed Reducers. To assure long life and performance of the **Planetgear** speed reducers, the following practices should be followed.

#### 1.1 BASIC OPERATION AND DESIGN

The **Planetgear** unit is a concentric shaft speed reducer that uses a simple planetary design, which utilizes a sun gear as the input, a ring gear as the fixed element, and a planetary carrier as the output. Power is transmitted from the reducer input shaft, through a splined connection to the input gear (sun gear) of the first reduction. The input gear drives the planet gears, which in turn drive the planetary carrier assembly. This carrier assembly is then connected to the next reduction sun gear or to the output shaft through a splined connection. Each carrier represents a single reduction. The reducer output shaft rotates in the same direction as the input shaft, regardless of the number of reductions. **Reference Figure 1.2** for a detailed representation.

All gearing has been made of a high grade alloy steel and case hardened for maximum life. Three to four points of contact, with a minimum of six to eight gear teeth engaged allow for a smooth transmission of power during normal operation and under extreme spike loads. Self contained input and output

shaft assemblies use a double row of tapered roller bearings mounted to a steel alloy shaft to provide high overhung and thrust load capacity. This feature also keeps all external shaft forces isolated from the gearing. Included in both shaft assemblies are two seals with a grease purgeable cavity between them. This design prevents contamination from entering the gear reducer under extreme conditions. The input shaft assembly also has the ability to add a backstop option to eliminate reducer counter rotation when the input driver is shut off.

#### 1.2 SECTIONAL VIEW AND COMPONENT IDENTIFICATION

**Reference Figure 1.2.**

#### 1.3 NAMEPLATE INFORMATION

Note location of serial number and model number on nameplate. When contacting the factory, have the **serial number** available, as this unique number fully describes the reducer and allows for the most efficient and accurate exchange of information. **Reference Figure 1.3** for nameplate illustration.

**Operation of the reducer shall not differ from the application data warranted on the nameplate. Any deviations from this data requires submittal of new application information along with all nameplate data to the factory or service center for approval. All data changes require a revised nameplate.**




Figure 1.2—Sectional View of a Planetgear Speed Reducer

Rexnord		PLANETGEAR SPEED REDUCER		WARNING	
Brook Hansen Drives Group MILWAUKEE, WISCONSIN USA				ROTATING POWER TRANSMISSION PRODUCTS ARE DANGEROUS AND MUST BE PROPERLY GUARDED. INSTALL AND MAINTAIN GUARDS BEFORE START UP.	
MODEL NO.		REDUCER ONLY		MOTORIZED REDUCER	
SERIAL NO.		MAX. TORQUE OUT		MOTOR HP	DATE
CUST. PO.		SERVICE HP		SERVICE CLASS	OIL CAP.
SIZE		SERVICE FACTOR			APPROX.
RPM IN				LUBRICATION	
RATIO				AGMA NO. ISO GRADE	
RPM OUT				VISCOSITY RANGE	
				cSt @ 40°C	
				90-110	
				150	
				135-165	
IMPORTANT: FILL TO THE LEVEL INDICATED WITH A PREMIUM QUALITY PETROLEUM BASED GEAR LUBRICANT CONTAINING OXIDATION RUST, AND FOM INHIBITORS. FOR DETAILED LUBRICATION INSTRUCTIONS, SEE LUBRICATION BULLETIN. UNDER NORMAL CONDITIONS, THE LUBRICANT SHOULD BE CHANGED EVERY 2500 HOURS OR EVERY SIX MONTHS WHICHEVER COMES FIRST. FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN PROPERTY DAMAGE OR PERSONAL INJURY.					

Figure 1.3—Reducer Nameplate

## Section 2.0

### Installation

#### 2.1 HANDLING OF REDUCER

Disconnect all mounting bolts from the reducer before lifting. Use lifting chains of ample strength, hooked to the eye bolts when lifting the speed reducer; reference Figure 2.1. Reference Table 1 (page 18) for reducer weight. Be sure the reducer is properly secured and balanced to prevent shifting during suspension.

#### ⚠ WARNING

To avoid personal injury or product damage, never attempt to lift the reducer with an eyebolt threaded into the top of the reducer maincase.




Figure 2.1—Reducer Handling

#### 2.2 REDUCER MOUNTING

It is essential that the speed reducer be securely bolted to a solid, level, and vibration free foundation.

Bolts should be of the correct size to fit mounting holes. They should be SAE Grade 5 or equivalent. Fasteners shall be torqued according to Table 2 (page 18). The use of a rigid structural steel baseplate is strongly recommended as a foundation. If a concrete foundation is used, grout structural steel mounting pads into the concrete rather than grouting the reducer directly into the concrete. Allow the concrete to cure before torquing the reducer mounting bolts down.

Align the reducer with driven equipment by placing broad flat shims underneath all mounting pads of the reducer. Start at the low speed end and level across the length and width of the reducer. **Check with a feeler gauge to make certain there is no clearance and that all pads are supported to prevent distortion of housing when reducer is bolted down.** After the reducer has been aligned with the driven equipment and bolted down, align prime mover to the reducer input shaft. **If the reducer is received coupled to a motor, it has been aligned properly at the factory. However, because alignment may have been disturbed during shipment, it is best to check alignment and then realign if necessary.** The reliability and long life of the reducer requires careful installation of accessories and accurate alignment of the connecting shafts. Check final alignment of motor shaft, coupling, and reducer shaft after reducer is in final working position.

#### 2.3 MOUNTING OF TRANSMISSION ACCESSORIES

#### ⚠ WARNING


When the Planetgear speed reducer is connected to a motor or driven equipment through the use of couplings, sprockets, gears or belt drives, all rotating parts must be properly guarded with guarding that conforms to OSHA requirements to prevent personal injury or property damage.

##### 2.3.1 MOTORS (STANDARD UNITS)

When direct coupling motors to the Planetgear reducer, follow the four step process shown below to achieve proper motor to reducer alignment. Refer to coupling manufacture specifications to determine required alignment accuracy. **Note: Steps 1 to 4 may have to be repeated several times to achieve manufacturers required accuracies.**


##### STEP #1 ( side view plane )

Correct for **angular** misalignment in the **side view plane**.




##### STEP #2 ( side view plane )

Correct for **parallel** misalignment in the **side view plane**.




##### STEP #3 ( top view plane )

Correct for **angular** misalignment in the **top view plane**.



##### STEP #4 ( top view plane )

Correct for **parallel** misalignment in the **top view plane**.



### 2.3.2 COUPLINGS

Mount the reducer coupling hub on the input shaft and the motor coupling hub on the motor shaft as instructed in the manual shipped with the coupling. If the coupling is not a **Rexnord® Omega™**, refer to the manufacturers literature for installation instructions. If Planetgear does not mount the motor, the couplings are mounted for shipment only. Coupling bolts and coupling instructions are packed inside the coupling elements. Note: Prior to the installation of the element, check both coupling hubs for the required parallel and angular alignment; **Reference Figure 2.3.2.**




Figure 2.3.2 Parallel and Angular Misalignment

### 2.3.3 SPROCKETS OR SHEAVES

Prior to installing sprockets or sheaves, review the manufacturers requirements for chain or belt tension and required alignment. When mounting the sprocket or sheave to the shaft, locate it as close as possible to the reducer. This will minimize the overhung load and prolong bearing life.

When using a **Planetgear** motor mount accessory, the belt tension can be changed by varying the height of the motor mount plate. This can be done by adjusting the four threaded support bolts. **Reference Figure 2.3.3.**

**NOTE: Mount sheaves and belts as close to the reducer as possible to avoid undue overhung loading on the bearings.**




Figure 2.3.3—Planetgear Top Motor Mount

## Section 3.0 Lubrication

### ✖ IMPORTANT

Read and carry out all instructions on nameplate and review all warning tags and caution tags.

## LUBRICATION CHANGES

### OIL

For normal conditions, **change oil every six months or 2,500 hours**, whichever comes first. If operating under abnormal conditions such as high temperature, severe duty, moisture or particle contamination, oil may need to be changed more frequently. **Reference Section 5.0** for maintenance.

**NOTE: Most lubricant suppliers can test oil from the unit periodically and recommend economical oil change schedules. Oil samples should be taken from the oil level hole, not the drain hole.**

### GREASE

All reducers are furnished with grease purgeable seals, thus minimizing entry of water or abrasive dust into the reducer. The reducers are shipped with the grease cavity filled with No.2 grease (equivalent to K2K grease). For normal conditions, change grease every six months or 2,500 hours, whichever comes first. Under extreme conditions, grease may need to be changed more frequently. **Reference Section 5.0** for maintenance.

## OPERATING TEMPERATURE

Determine the minimum and maximum ambient temperatures that the **Planetgear** reducer will be subject to during operation. If the speed reducer operates in an environment where the temperature fluctuations are predictable, choose an oil viscosity that is recommended for that given temperature. I.E. for cold weather operation, use an oil that will circulate freely at all times. The pour point of the oil should be 9°F (5°C) less than the minimum external temperature during reducer operation. During hot weather, use a higher viscosity oil that will not thin out and lose its lubricating qualities.

If the speed reducer operates under extreme conditions or is exposed to large temperature fluctuations, the use of a synthetic oil is recommended. Contact lubrication supplier for recommendations.

**NOTE: The synthetic lubricant should conform to the requirements of ANSI / AGMA 9005-D94.**

### ✖ CAUTION


Special measures should be taken to protect drives operating in direct sunlight at ambient temperatures over 100°F (38°C). This protection can consist of a canopy over the drive or reflective paint on the drive. If neither is possible, a heat exchanger or other cooling device may be required to prevent the reducer sump temperature from exceeding the allowable maximum oil temperature of 200°F (93°C). Temperatures in excess of 120°F (49°C) feel hot to the human hand. Planetgear reducers can be operated with reducer sump oil temperatures of up to 200°F (93°C).

## LUBRICATION GRADE SELECTION

After the determination of the ambient temperature is made, reference the nameplate or the **Ambient Temperature Table** (next column) to determine the proper AGMA or ISO grade lubricant for those temperature conditions, and select an appropriate oil. SAE oils apply to gear lubricants only. Automotive oils are not recommended. All reducers are splash lubricated by gear rotation with even distribution to all gear meshes and bearings.

Ambient Temp.	Viscosity @ 40°C Centistokes	AGMA Grade #	ISO Grade #
-10°C to 15°C 15°F to 60°F	90 - 110	3	100
10°C to 50°C 50°F to 125°F	135 - 165	4	150

## Comparative Viscosity Classifications



## Petroleum Based R&O Gear Oils

Maximum operating temperature of lubricants: 200°F (93°C)  
AGMA 3: 15°F - 60°F AGMA 4: 50°F - 125°F

Manufacturer	AGMA Viscosity Grade 3	AGMA Viscosity Grade 4
	Lubricant	Lubricant
Amco Oil Co.	American Ind. Oil #100	American Ind. Oil #150
Chevron U.S.A. Inc.	AW Machine Oil 100	AW Machine Oil 150
Cities Service Co.	Citgo Pacemaker 100	Citgo Pacemaker 150
Conoco Inc.	Dectol R&O Oil 100	Dectol R&O Oil 150
Exxon Company, U.S.A.	Teresstic 100	Teresstic 150
Gulf Oil Corp.	Harmony 100	Harmony 150 D
Gulf Canada Limited	Harmony 66	Harmony 77
Imperial Oil Ltd.	Teresso 100	Teresso 150
Mobil Oil Corp.	DTE Heavy	DTE Extra Heavy
Phillips Petroleum Co.	Magnus Oil 100	Magnus Oil 150
Shell Oil Co.	Morlina 100	Morlina 150
Shell Canada Limited	Tellus 100	Tellus 150
Standard Oil Co. (Ohio)	Industron 66	Industron 80
Texaco Inc.	Regal Oil R&O 100	Regal Oil R&O 150
Texas Canada Inc.	Regal R&O 100	Regal R&O 150
Union Oil Co. of Calif. (East)	Unax RX 100	Unax RX 150
Union Oil Co. of Calif. (West)	Turbine Oil 100	Turbine Oil 150

## LUBRICATION QUANTITY

From the nameplate or the oil capacity chart below, determine the quantity of oil in gallons, needed to operate the reducer.

Reducer Series	Reduction Type	
	D/T/Quad gallons	D/T/Quad liters
Jupiter	32	121.3

D=double

T= triple

Quad = quadruple

## Section 4.0

### Start-up

#### WARNING

Never operate the speed reducer at speeds and/or loads that exceed the limits specified on the nameplate. Exceeding these limits may result in personal injury or machinery damage. Check to insure that all rotating equipment is properly guarded according to OSHA standards.

#### CAUTION

All speed reducers are shipped without oil. Be sure to fill the unit to the proper level prior to start-up.

#### CAUTION

When starting up new equipment, proceed cautiously.

### 4.1 PRE START-UP CHECKLIST

- ③ Has the reducer been filled with the proper oil type and to the correct oil level?
- ≤ Are all mounting bolts high strength ANSI B18.2.1 Grade 5 or ISO 898/1 Grade 8.8 and tightened according to torque specifications in **Table 2, (page 18)?**
- ♣ Are all input and output shaft couplings, sprockets, pinions, etc. mounted with full engagement and keys in place?
- ➔ Have couplings and reducer seals been properly greased?
- Are coupling connections properly aligned and fastened?
- ± Have all pipe plugs (oil fill, oil level, and oil drain) been inserted and properly tightened?
- ➔ Have all electrical connections been made?
- ≈ Does the motor shaft rotate in the proper direction?
- ♠ Are all guards in place and properly secured?

### 4.2 INITIAL START-UP

It is recommended that all **Planetgear** speed reducers be run-in for a period of time before introduction to full service. This will allow the gearing to mate properly prior to being exposed to any high load conditions. The following procedure is recommended for initial start-up.

### 4.2.1 PRIME MOVER

The prime mover should be set up to maximize the amount of time necessary to get to the rated speed. This will avoid any instantaneous gear loads that could exceed the rating of the speed reducer or other components.

### 4.2.2 REDUCER ROTATION

If the reducer is equipped with an internal backstop, an arrow located on the top of the maincase will indicate the direction of rotation during operation. Make sure the motor shaft will rotate in that direction. If necessary, reverse the leads on the motor so that the proper motor direction is attained.

### 4.2.3 START-UP

Start the reducer under as light a load as possible. As the unit is brought up to normal operating speed, check for unusual noises, excessive vibration, or excessive heat and oil leakage. If any of these conditions exist, shut down the unit immediately and determine the cause of the problem. Refer to **Section 9.0 Troubleshooting (page 17)** for assistance.

### 4.3 POST START-UP CHECKLIST

- ③ After approximately forty hours of use, check all foundation and mounting bolts and tighten as required. **Note: Always recheck alignment after tightening.**
- ≤ The oil used in the initial start-up of a new reducer should be completely drained and replaced after 500 hours of use. A thorough cleaning of the gear case using a flushing oil should be performed to remove any foreign matter during the first oil change.

## Section 5.0 Maintenance

### WARNING

DO NOT PERFORM ANY MAINTENANCE PROCEDURES WHILE REDUCER IS IN OPERATION. DOING SO MAY RESULT IN PERSONAL INJURY OR PROPERTY DAMAGE. TO INSURE SAFETY DURING MAINTENANCE, ACTIVATE ALL ELECTRICAL AND/OR MECHANICAL LOCKOUTS.

### 5.1 FILLING OIL

1. Chose correct oil type; **reference Section 3.0.**
2. Determine correct oil quantity; **reference Nameplate or Section 3.0.**

**NOTE:** Special applications may have different oil quantity requirements. Refer to the nameplate for specific oil quantity.

3. Remove oil fill plug (vent plug) and one of the two oil level plugs; **reference Figure 5.1.**
4. Fill reducer at oil fill port.
5. Reducer oil capacity is reached when oil starts to pour out of the bottom of the level port. Allow several minutes for oil to settle, then recheck oil level. Add oil if necessary.

**NOTE:** Oil should be checked or added when reducer is at ambient temperature.

### CAUTION

Underfilling reducer may cause product damage. Overfilling reducer may cause excessive oil temperatures.

6. Replace oil level plug, sealing it in the process using thread sealant.
7. Replace oil fill plug (vent plug).
8. Start up reducer under a no load condition. Run reducer for a few minutes.
9. Stop reducer and recheck oil at the oil level port. If necessary, add oil.




Figure 5.1—Reducer Oil Ports, Vent Plug, and Grease Insert Locations

### 5.2 DRAINING OIL

1. Clean external surfaces to avoid contaminants from entering unit when plugs are removed.
2. Remove oil fill plug (vent plug) for ventilation; **reference Figure 5.1.**

### CAUTION

Care should be taken when removing the vent plug. If vent has been clogged, the possibility of pressurized air inside the reducer may exist. Once threads are free to hand rotate, place a heavy cloth over the vent plug and rotate counter-clockwise until removed.

3. With the proper size oil drain pan (reference oil quantity on nameplate) in place, remove one of the drain plugs.

### CAUTION

Oil may be hot. Do not drain until oil is at ambient or a safe temperature.

4. After oil is removed, replace oil drain plug, sealing it in the process using thread sealant.
5. **Reference Section 5.1** for filling reducer with oil.

### 5.3 ADDING GREASE TO REDUCER SEALS

1. Clean grease inserts, **reference Figure 5.1** for location.
2. Using a high temperature No. 2 grease. Attach grease gun to grease insert and pump grease into seal carrier.
3. Stop greasing when a sufficient amount of grease purges out of seal carrier next to shaft.

**NOTE:** Grease should purge from outboard seal onto shaft, if this does not occur, refer to Section 6.2 to check for proper seal installation.

4. Clean purged grease from reducer.

### 5.4 REPLACING SEALS IN SERVICE

Reference Section 6.2 for procedure.



## Section 6.0

### Disassembly and Assembly Instructions

The following instructions are for the Jupiter speed reducer. This is a guide for disassembly, parts replacement, and reassembly. Note, the drawings used are not to scale and therefore may not agree in every detail. To expedite service, when ordering parts or requesting information, supply the following information: **model number, reducer size, ratio, serial number, HP, motor RPM, and the build date** from the reducer nameplate. No ratio change should be made without first consulting a **Planetgear** representative. All bearings and seals used on standard **Planetgear** speed reducers are listed in **Table 3 and Table 4 (page 19)**.

#### REQUIRED EQUIPMENT

Standard mechanic's tools: arbor press or hydraulic press, torque wrench, dial indicator with magnetic base, and hoist.

#### ⊠ CAUTION

Always take the necessary safety precautions when working with an arbor press, hydraulic press or with any hand tools.

#### 6.1 TAKING REDUCER OUT OF SERVICE

**NOTE:** If only replacing seals, the reducer need not be pulled from service.

1. Disconnect all attached equipment.

#### ⊠ WARNING

DO NOT PERFORM ANY MAINTENANCE PROCEDURES WHILE REDUCER IS IN OPERATION. DOING SO MAY RESULT IN PERSONAL INJURY OR PROPERTY DAMAGE. TO INSURE SAFETY DURING MAINTENANCE, ACTIVATE ALL ELECTRICAL AND/OR MECHANICAL LOCKOUTS.

2. Remove all reducer mounting bolts.
3. Lift reducer as explained in **Section 2.1**.
4. Drain oil from reducer, **reference Section 5.2** for procedure.

**NOTE:** Care should be taken to protect the shafts from damage. Damaged shaft may cause problems when reinstalling couplings, sprockets, or sheaves.

#### 6.2 REPLACING SEALS

##### 6.2.1 REMOVING SEAL CARRIER

**NOTE:** If only replacing seals, the reducer need not be pulled from service. Seals are housed in a seal carrier which can be removed from the reducer at the installation location.

**NOTE:** If unit is equipped with a fan and shroud, remove fan and shroud.

1. Clean shaft extension.
2. Drain oil from reducer before removing seal carrier; **reference Section 5.2**.
3. Remove bolts attaching seal carrier to input or output housing (Note location of grease fitting for reinstallation).
4. Using a **flat blade** and a hammer, break the seal between the seal carrier assembly and the input or output housing; **reference Figure 6.2.1**.




Figure 6.2.1—Separation of Seal Carrier From Hub

5. Remove seal carrier.
6. After seal carrier is removed, protect the input or output bearings from contamination by wrapping a clean cloth (or equivalent) around the exposed area.

#### ⊠ CAUTION

When removing seal carrier, care should be taken not to damage or contaminate the bearings. Damaged bearings may reduce bearing life.

#### 6.2.2 REMOVING SEALS FROM SEAL CARRIER

1. Remove seal carrier from the input or output housing; **reference Section 6.2.1 Removing Seal Carrier**.
2. With a set of blocks or equivalent, support the seal carrier up so the seals can be pushed out; **reference Figure 6.2.2, next page**.
3. With an arbor press or a hydraulic press, carefully push seals out of seal carrier using a metal tube or a circular disc.

**NOTE:** Take care not to scratch or gouge the inside diameter of the seal carrier or the surface that mates to the input or output housing. Damage to these areas may result in oil leakage during operation.




Figure 6.2.2—Removal of Seals from Seal Carrier




Figure 6.2.3.1B—Installation of Inboard Seal

**NOTE:** Be sure to push seal in squarely. Any misalignment might damage seal and result in oil leakage.

6. Place seal carrier inboard side face down on a flat surface. Set the single lipped seal on the seal carrier so that the opening (garter spring side) faces the outboard side; reference Figure 6.2.3.2A.




Figure 6.2.3.2A—Placement of Outboard Seal for Installation

## 6.2.3 INSTALLING NEW SEALS

1. Remove seal carrier from the input or output housing; reference Section 6.2.1.
2. Remove seals from seal carrier; reference Section 6.2.2.
3. Clean all machined surfaces on the seal carrier and the machined surface that the seal carrier seats to on the input or output housing.
4. Place seal carrier outboard side face down on a flat surface. Set the double lipped seal on seal carrier so that the opening (garter spring side) faces the inboard side; reference Figure 6.2.3.1A.




Figure 6.2.3.1A—Placement of Inboard Seal for Installation

5. With an arbor press or a hydraulic press, carefully push seal into seal carrier flush with end of chamfer; reference Figure 6.2.3.1B, next column.




Figure 6.2.3.2B—Installation of Outboard Seal

**NOTE:** Be sure to push seal in squarely. Any misalignment might damage seal and result in oil leakage.

#### 6.2.4 INSTALLING SEAL CARRIER - INPUT/OUTPUT SHAFT ASSEMBLY

1. Clean the machined surfaces where the seal carrier and the input or output housing mate.

**NOTE:** Scraping of surfaces with a putty knife may be required.

2. Apply a bead of sealant around the inboard lip of the seal carrier and/or around the face of the input or output housing inside the bolt hole circle.

**NOTE:** Use Loctite 515 gasket eliminator, or equivalent as a sealant.

3. Slip the seal carrier over the shaft.

#### CAUTION

Extreme care must be taken to not roll the lip of the seal or cut the seal on the keyway.

4. When the seal carrier is piloted on the shaft pilot, seat the seal carrier by slowly pressing down on the flange; reference Figure 6.2.4.




Figure 6.2.4—Placement of Seal Carrier Assembly onto Shaft

**NOTE:** Orientate the seal carrier grease fitting to the position best suited to your application. Reducers built by Planetgear are assembled with the grease fitting oriented in-line with an oil port in the input or output shaft housings and are normally in the 12 o'clock position.


5. Bolt seal carrier to input or output housing, reference Table 2 (page 18) for bolt torques.
6. Add grease to seal carrier; reference Section 5.3.
7. Add oil to reducer; reference Section 5.1.

#### 6.3 REPLACING BEARINGS - INPUT/OUTPUT SHAFT ASSEMBLIES


##### 6.3.1 REMOVING INPUT OR OUTPUT SHAFT ASSEMBLIES TO REPLACE BEARINGS

1. Take reducer out of service; reference Section 6.1.
2. Clean all external surfaces to prevent contaminants from entering unit when disassembled.
3. Drain oil from unit; reference Section 5.2.
4. If unit is equipped with a fan and shroud, remove fan and shroud.


**NOTE:** For better results, mount reducer in the vertical position; reference Steps A, B, and C.



**Step A—** Carefully lift reducer by using the two eyebolts located on the input shaft end of reducer. Do not allow output shaft to be damaged.



**Step B—** Carefully lift reducer to vertical position by both the two eyebolts and the two foot mounting holes on the input shaft end.



**Step C—** Carefully place reducer in vertical position on support blocks.

**NOTE:** Special care should be taken when removing the output assembly. All gearing is stabilized at the output assembly. Removing output assembly first may result in difficulties during reducer reassembly. It is recommended that the input assembly be removed first, then the gear train, and finally the output assembly (reference Section 6.5 for additional information).

5. Remove the bolts that attach the assembly to the maincase.
6. With a 1/2" bolt, drive the bolt into one of the four 1/2-13 UNC threaded holes. This will break the seal between the housing and the maincase allowing the removal of the assembly.
7. Remove assembly by lifting it straight up away from the maincase. An eye bolt can be used in the threaded end of the shaft to lift the assembly; **reference Figure 6.3.1. DO NOT LIFT ENTIRE REDUCER BY THE THREADED HOLE ON EITHER SHAFT.**

**CAUTION**

Do not lift input or output shaft assembly by hand. The assemblies are heavy and lifting by hand can cause serious injury.




Figure 6.3.1—Proper Lifting of Input or Output Shaft Assemblies

**NOTE:** Place all removed parts on a clean dry surface to avoid contact with contaminants.

**NOTE:** Allow space between the shaft extension and the working surface.

4. **OUTPUT ONLY** - Remove external retaining ring. **Store in clean spot.**
5. Loosen socket head cap screw on clampnut.
6. Remove clampnut from shaft. **Store in clean spot.**

**NOTE:** A wedge can be used to spread the clampnut in order to ease removal.

7. Remove tongued washer from shaft. **Store in clean spot.**
8. **INPUT ONLY** - Remove backstop or backstop spacer from shaft. **Store in clean spot.**
9. With an arbor press or a hydraulic press, press on the inboard end of the shaft to break free the inboard bearing cone.
10. At this time, the shaft will be free and can be separated from the housing. The inboard bearing cone will be free to remove and discard.

**CAUTION**

The input and output shafts are heavy.

11. To remove the outboard bearing from the shaft, one of two procedures can be used. 1.) Support the shaft by the bearing cone with the inboard end of the shaft facing up. With an arbor press or hydraulic press, press down on the inboard end of the shaft; **reference Figure 6.3.2.2.** 2.) With a hammer and punch, carefully strike the bearing cone towards the inboard end of the shaft; **reference Figure 6.3.2.3, next column.**




Figure 6.3.2.2—Removal of Outboard Bearing Cone (Option #1)

**6.3.2 DISASSEMBLING INPUT OR OUTPUT SHAFT ASSEMBLIES TO REPLACE BEARINGS**

1. Remove endbell from reducer; **reference Section 6.3.1.**
2. Remove seal carrier from endbell; **reference Section 6.2.1.**
3. Support hub to expose the inboard side of the endbell; **reference Figure 6.3.2.1.**




Figure 6.3.2.1A—Positioning of Hub




Figure 6.3.2.3—Removal of Outboard Bearing Cone (Option #2)

**NOTE:** Take care not to damage the shaft bearing surface or seal surface.

12. With a hammer and punch, tap out the inboard and outboard bearing cups from the housing.

**NOTE:** Take care not to damage the bearing surface of the housing.

### 6.3.3 INSTALLING BEARING CUPS INTO INPUT OR OUTPUT HOUSINGS

1. Clean machined surfaces on housing where bearing cups are located.

**NOTE:** If high spots or burrs occurs after disassembly, use discretion to remove them. Bearing cup has to be seated perfectly to insure proper bearing alignment.

2. Place bearing cup squarely on the bearing bore. With an arbor press or a hydraulic press and flat disc push bearing cup into housing until seated.

**NOTE:** This procedure applies to both inboard and outboard bearing cup. Be sure to push cups in evenly. Any misalignment may result in a damaged housing or bearing cup.

**NOTE:** Take care not to scratch or gauge bearing surface. Any damage done may result in premature damage of the bearings.

3. With a 0.001" or 0.040 mm feeler gage, make sure that there is no gap between the housing and the bearing cups to insure proper cup seating; reference Figure 6.3.3.




Figure 6.3.3—Installation of Inboard and Outboard Bearing Cups

**NOTE:** Any gap between hub and bearing cups can result in excessive axial bearing clearance or bearing misalignment and ultimately result in premature bearing damage.

### 6.3.4 ASSEMBLING INPUT OR OUTPUT SHAFT ASSEMBLIES

1. Clean bearing surface on shaft.

#### CAUTION

Assembly may become top heavy. Pilot assembly so that it will not fall over.

2. Make sure bearing cups are clean and installed properly in housing; reference Section 6.3.3.
3. Set shaft on end with the spline end of the shaft facing up.
4. Place the outboard bearing cone squarely on the inboard end of the shaft with the smaller diameter of the bearing facing inboard; reference Figure 6.3.4.1.




Figure 6.3.4.1—Placement of Outboard Bearing Cone on Shaft

**NOTE:** For output assembly, the use of Neverseize around the shaft is allowed to ease assembly. DO NOT put Nerverseize on threaded part of shaft.

5. With an arbor press or a hydraulic press carefully push bearing cone until it bottoms on shaft shoulder.

**NOTE:** DO NOT push on bearing rollers or bearing cage; reference Figure 6.3.4.2 for location.




Figure 6.3.4.2—Location of Bearing Cage and Roller Bearing

6. With a 0.001" or 0.040 mm feeler gage, make sure that there is no gap between the shaft shoulder and the bearing cone to insure proper cone seating; reference Figure 6.3.4.3.




Figure 6.3.4.3—Checking for Zero Clearance with Feeler Gauge

**NOTE:** Any gap between shaft and bearing cone can result excessive axial bearing clearance or bearing misalignment and ultimately result in premature bearing damage.

7. Carefully set the housing, outboard side face down, onto the outboard bearings.

**NOTE:** It is helpful to use a crane to lift hub onto shaft; reference Figure 6.3.4.4.




Figure 6.3.4.4—Placing Housing onto Shaft Assembly

8. While rotating the housing on bearings, apply clean oil to the bearings.
9. Place the inboard bearing cone squarely on the inboard end of the shaft with the smaller diameter of the bearing facing the outboard; reference Figure 6.3.4.5.




Figure 6.3.4.5—Placing Inboard Bearing Cone onto Shaft

10. With an arbor press or a hydraulic press carefully push bearing cone. When bearings begin to approach the bearing cup, apply clean oil to inboard bearings.

**NOTE:** DO NOT push on bearing rollers or bearing cage; reference Figure 6.3.4.2.

11. Press inboard bearing until it touches the surface of the bearing cup.

**NOTE:** Do not over push bearings into cup. This might cause the bearings to Brinell the cup.

**NOTE:** An indication when the inboard bearing is fully seated is when the hub will not rotate on the shaft freely.

12. **INPUT ONLY** - Clean and place the backstop or backstop spacer onto the shaft.

**NOTE:** The desired rotation of the reducer is determined by viewing thru the output shaft side. Reference Figure 6.3.4.6 for orientation of the backstop after being assembled onto the input shaft.




Figure 6.3.4.6—Backstop on Input Assembly

13. Clean and place the tongued washer onto the shaft.
14. Clean clampnut. Place it with the grooved side down (or groove towards bearings) and thread on clampnut until it is unable to rotate.
15. Mark the location of the clampnut.
16. Loosen clampnut approximately 3/4" (19 mm) from original mark.
17. Tighten socket head cap screw on clampnut; reference Table 2.
18. **OUTPUT ONLY** - Install external retaining ring.
19. Support hub and affix to work table with the shaft not touching the table; reference Figure 6.4.1.
20. With an arbor press or a hydraulic press, push on the inboard end of the shaft to relieve the bearings.

**NOTE:** A popping noise will sound when bearings are relieved. If the noise does not occur, an alternative way to determine if the bearings have been relieved is if the housing rotates freely on the bearings.

21. Reference Axial Bearing Clearance, Section 6.4 for proper bearing endplay.

## 6.4 SETTING PROPER AXIAL BEARING CLEARANCES ON INPUT OR OUTPUT SHAFT ASSEMBLIES

### 6.4.1 MEASURING AXIAL CLEARANCE ON INPUT AND OUTPUT ASSEMBLIES

1. Support housing to allow the shaft to rotate freely; **reference Figure 6.4.1.**




Figure 6.4.1—Setting Axial Bearing Clearance

**NOTE:** If necessary, the axial bearing clearance can be measured by orientating the larger assemblies outboard side down. The dial indicator should then be placed on the inboard end of the shaft while prying upwards on the outboard end of the shaft.

**NOTE:** Axial clearance should be checked while seal carrier is removed.

2. Affix the hub to the support table with C-Clamps or bolting to table; **reference Figure 6.4.1.**
3. While exerting downward force by hand on the end of the shaft, rotate shaft 6 to 10 times to align the bearing rollers.
4. Use a dial indicator with a magnetic base to take measurements.

**NOTE:** Use a dial indicator that has a balanced dial with 0.0001" or 0.010 mm graduations.

5. Affix the magnetic base of the dial indicator to a flat area of the housing; **reference Figure 6.4.1.**
6. Place the stem of the dial indicator perpendicular to the end of the shaft.

**NOTE:** Place stem of dial indicator as close to the center of the shaft as possible.

7. Record the reading of the dial indicator when the indicator has engaged the shaft.
8. With a pry bar, push the inboard end of the shaft up; **reference Figure 6.4.1.**

**NOTE:** Use a constant swift force when pushing on the pry bar. Excessive force not required. **DO NOT** rotate shaft while pushing on shaft. The object is to lift the shaft only.

9. Record reading of the dial indicator. Take the difference between the two readings. The difference is the axial bearing clearance.

**NOTE:** 0.001" to 0.004" (0.025 to 0.102 mm) axial bearing clearance is recommended. Do steps 3 thru 9 several times to insure an accurate measurement has been made.

10. See Sections 6.4.2 and 6.4.3 for adjusting for too much or too little axial bearing clearance.

### 6.4.2 ADJUSTING FOR TOO MUCH AXIAL BEARING CLEARANCE

**NOTE:** If axial bearing clearance is too excessive, it might be necessary to remove the clampnut and other hardware, and press the bearing again. **Reference Section 6.3.5 - steps 11 to 20, or Section 6.3.6 - steps 12 to 21.**

1. Loosen socket head cap screw on clampnut.
2. Mark the position of the clampnut.
3. Rotate clampnut 1/16" to 1/8" (1.5 to 3.1 mm) in the clockwise direction from mark to tighten clampnut.

**NOTE:** The measurement given is an estimate.

4. Tighten socket head cap screw on clampnut.
5. Follow procedures in **Section 6.4.1** to determine new axial bearing clearance.
6. Repeat first 5 steps if axial bearing clearance is found to be still too much.

### 6.4.3 ADJUSTING FOR TOO LITTLE AXIAL BEARING CLEARANCE

1. Loosen socket head cap screw on clampnut.
2. Mark the position of the clampnut.
3. Rotate clampnut 1/16" to 1/8" (1.5 to 3.1 mm) in the counter clockwise direction from mark to loosen clampnut.

**NOTE:** The measurement given is an estimate.


4. Tighten socket head cap screw on clampnut.
5. With a hydraulic press, push on the clampnut end of shaft to increase the bearing axial clearance.
6. Follow procedures in **Section 6.4.1** to determine new axial bearing clearance.
7. Repeat first 6 steps if axial bearing clearance is found to be still too little.

## 6.5 GEAR TRAIN DISASSEMBLY


Place gears in a clean dry place in the order of disassembly. Exploded view drawings of a specific gear train may be requested from the factory by specifying the reducer serial number, model number, size, ratio, and rating. To order replacement components, please give the previously stated information about the reducer and the items needed. Reference the following sketches for general exploded view drawings.

**NOTE:** All the gearing is stabilized at the output assembly. Removing output assembly first may result in a difficult time reassembling reducer. **It is recommended that the input assembly be removed first, then the gear train, and finally the output assembly.**


**Double Reduction disassembly**—Remove input assembly (1), input gear (2), maincase (3), ring gear (4), first stage carrier (5), last stage sun gear (6), ring gear (7), last stage carrier (8), and output assembly (9).



**Triple Reduction disassembly**—Remove input assembly (1), input gear (2), maincase (3), first stage carrier (4), ring gear (5), sun gear (6), second stage carrier (7), last stage sun gear (8), ring gear (9), last stage carrier (10), and output assembly (11).



**Quadruple Reduction disassembly**—Remove input assembly (1), input gear (2), maincase (3), first stage carrier (4), ring gear (5), sun gear (6), second stage carrier (7), ring gear (8), sun gear (9), third stage carrier (10), last stage sun gear (11), ring gear (12), last stage carrier (13), and output assembly (14).



### 6.6 GEAR TRAIN ASSEMBLY

The gear train can be assembled in the reverse order of disassembly. **Reference Section 6.5.**

**NOTE:** It is recommended that the output sub-assembly be installed first, then the gear train and finally the input sub-assembly. Unit should be assembled in the vertical position, with input shaft up.

### 6.7 FAN AND SHROUD INSTALLATION

#### 6.7.1 SHROUD CLIP INSTALLATION

Remove mounting bolts from input sub-assembly / maincase in the following locations and install shroud clips; **reference Figure 6.7.1A.**




Figure 6.7.1A—Location of Shroud Clips

Align shroud clip with center of reducer; **reference Figure 6.7.1B,** and tighten bolts to torque requirements of **Table 2, (page 18).**




Figure 6.7.1B—Location of Shroud Clips

#### 6.7.2 FAN INSTALLATION

From **Figure 6.7.2,** determine the distance from the end of the input shaft to the front edge of the fan.

REDUCER SIZE	NA Inch Shaft	NA Metric Shaft
JUPITER	4.69"	119mm




Figure 6.7.2—Location of Fan


With key in place, position the fan on the input shaft to the determined "NA" distance.

Locate the set screw which is 90° from the keyway to the spotting hole on the shaft.

Tighten set screws (2). **Reference Table 2, (page 18)** for torque requirements.



### 6.7.3 REMOTE GREASE LINE INSTALLATION



I-T-E-M	DESCRIPTION
1	1/8" NPT x 1/4" O.D. TUBE STRAIGHT QD. BRASS FTG.
2	1/4"-28 MALE x 1/8" NPT FEMALE ADAPTER
3	3/8" STEEL WASHER
4	1/8" NPT GREASE FITTING
5	1/4" O.D. TUBE x 12" LG. (300 mm)

Per preceding drawing, install grease fitting hardware (items 1 & 2) at seal carrier (if not already installed) and fill grease tube (item 5). Note, fill grease tube prior to installation.

Assemble grease fitting hardware (items 1, 3, & 4) into predrilled 7/16 (11 mm) diameter hole in fan shroud (if not already installed).

The grease line (item 5) will be inserted into the grease fitting hardware in the fan shroud when the shroud is assembled to the speed reducer.

### 6.7.4 FAN SHROUD INSTALLATION

Position the fan shroud so that it fits tight over the shroud clips. Check to insure that when the input shaft is rotated, the fan does not interfere with the shroud. Gently bend the shroud clips to position the shroud.

**NOTE: The fan shroud should be predrilled for the shroud clips and the remote grease line (RGL).**

Insert RGL grease tube into shroud grease fitting hardware.

Using bolts and washers that were removed originally during disassembly, fasten the shroud to the shroud clips. Once fastened rotate input shaft to insure no interference with fan.

## Section 7.0

### Storage Procedures

#### 7.1 SPARE PARTS STORAGE

1. On receipt of spare parts, unpack and spray or dip the parts in a rust preventative such as **Mobilarma 524**, or equivalent.
2. Place parts on a wood pallet in a dry place. Cover loosely with plastic, DO NOT wrap or store parts in news print as it is corrosive.
3. Re-spray parts every six months. Spray parts every three months if high humidity exists.
4. If rust develops, remove rust with a medium grit emery cloth and re-spray with rust preventative.
5. When ready to install parts, make sure all parts rotate freely. Clean all grime from the parts before installation.

#### 7.2 STORED AND INACTIVE REDUCERS

##### 1. Preparation For Storage

- A. If a reducer is to be stored or is inactive after installation, fill the reducer with the correct type and amount of lubricant. Add a rust inhibitor such as **Mobil Vaprotec Concentrate** to the lubricant. Seal the reducer completely; replace the vent plug with a solid pipe plug to keep rust inhibiting atmosphere sealed inside.
- B. After approximately three months, rotate the input shaft such that the output shaft rotates a full 360°(degrees). This will insure that all internal parts will remain coated and will also keep the bearings from becoming lacquered. Noncompliance with this procedure may cause bearing damage during start-up.
- C. Every six months inspect the stored or inactive reducer and add rust inhibitor if necessary. Dry, indoor storage is recommended.

##### 2. Preparation For Start-up

Rotate shafts until the bearings move freely. This is to assure that the bearings have not become lacquered. Reducer may be operated without draining the lubricant described in **Section 7.2-A**.

#### 7.3 LONG TERM STORAGE

Reducer can be ordered from the factory for long term storage. Field preparation for long-term storage is described **Section 7.2**.

## Section 8.0

### Troubleshooting

This troubleshooting guide will handle questions encountered in regards to **Planetgear** speed reducers.

EXCESSIVE TEMPERATURE [more than 200°F (93°C)]	
POSSIBLE CAUSES:	POSSIBLE SOLUTIONS:
OVERLOAD	<ul style="list-style-type: none"> <li>Compare actual reducer load with rated load on the nameplate. If the HP or torque is greater, or the speed is slower than stated on the nameplate, the reducer is probably overloaded. Contact a Rex Planetgear Representative; may require a speed change or a larger unit.</li> </ul>
TIGHT OR DEFECTIVE BEARINGS	<ul style="list-style-type: none"> <li>Inspect bearings for excessive wear or discoloration due to heat. If either is present, replace the bearings. Refer to Section 6.0 for replacing bearings.</li> </ul>
EXCESSIVE AMBIENT TEMPERATURE	<ul style="list-style-type: none"> <li>Provide ventilation for the reducer.</li> <li>Paint white if reducer is in direct sun light.</li> <li>If conditions are extreme, contact a Rex Planetgear Representative for assistance.</li> </ul>
IMPROPER OIL, OIL LEVEL, OLD OR CONTAMINATED OIL	<ul style="list-style-type: none"> <li>Make sure lubricant is correct for reducer. A mistake frequently made is to use automotive oil. This is incorrect and will frequently cause the reducer to overheat.</li> <li>Check the oil level in the reducer. Too much as well as too little oil can cause the reducer to overheat.</li> <li>Check to see that oil has not lost its' lubricating property. If oil viscosity is too low, this will result in high oil temperatures.</li> </ul>
PLUGGED SHROUD	<ul style="list-style-type: none"> <li>Make sure area immediately in front of fan shroud is clear.</li> </ul>
OVERSPEED	<ul style="list-style-type: none"> <li>Reduce input speed to reduce oil temperature. If reducer input speed is above the stated value on the nameplate, this would raise oil temperature due to increase in internal windage.</li> </ul>
RESTRICTED VENT PLUG	<ul style="list-style-type: none"> <li>Remove and clean vent plug.</li> <li>Replace vent plug.</li> </ul>

BEARING DAMAGE	
POSSIBLE CAUSES:	POSSIBLE SOLUTIONS:
IMPROPER ADJUSTMENT	<ul style="list-style-type: none"> <li>Adjust bearing to proper axial bearing clearance as instructed in Section 6.0.</li> </ul>
LACK OF LUBRICATION, IMPROPER LUBRICATION, OLD OR CONTAMINATED OIL	<ul style="list-style-type: none"> <li>Replace damaged bearings as instructed in Section 6.0. Note: Check hub and shaft for potential damage or heat distress.</li> </ul>
EXCESSIVE OVERHUNG LOAD	<ul style="list-style-type: none"> <li>Reduce overhung load. Move the sprocket or sheave closer to the bearings or increase the diameter of both the driven and the driver.</li> </ul>

BEARING NOISE	
POSSIBLE CAUSES:	POSSIBLE SOLUTIONS:
DEFECTIVE BEARING	<ul style="list-style-type: none"> <li>Inspect and replace bearings if necessary. Reference Section 6.0.</li> </ul>
IMPROPER BEARING ADJUSTMENT	<ul style="list-style-type: none"> <li>Adjust bearing endplay. Reference Section 6.0.</li> </ul>
WRONG OR INSUFFICIENT LUBRICATION	<ul style="list-style-type: none"> <li>Make sure that enough oil of the correct grade is used. Reference Section 3.0.</li> </ul>

LEAKAGE	
POSSIBLE CAUSES:	POSSIBLE SOLUTIONS:
DAMAGED OR WORN SEALS	<ul style="list-style-type: none"> <li>Replace seals. Reference Section 6.0.</li> </ul>
BEARINGS OUT OF ADJUSTMENT	<ul style="list-style-type: none"> <li>Reset bearings. Reference Section 6.0.</li> </ul>
EXCESSIVE TEMPERATURE, CAUSING BRITTLE SEALS	<ul style="list-style-type: none"> <li>Isolate reducer from source of extreme temperature.</li> <li>Install high temperature seals.</li> </ul>
ABRASIVE OR CORROSIVE ATMOSPHERE	<ul style="list-style-type: none"> <li>Isolate reducer seal area from environment.</li> <li>Re-grease frequently.</li> </ul>
RESTRICTED VENT PLUG	<ul style="list-style-type: none"> <li>Remove and clean vent plug.</li> <li>Replace vent plug.</li> </ul>
SPLIT-LINE LEAKAGE	<ul style="list-style-type: none"> <li>Make sure fasteners are torqued correctly. Reference Table 2.</li> <li>Remove suspect hub. Visually inspect mating surfaces for rises or dings. File smooth (do not allow file shavings to enter gearing or bearings) apply gasket eliminator and replace hub.</li> </ul>

DAMAGE OF FASTENERS	
POSSIBLE CAUSES:	POSSIBLE SOLUTIONS:
FAILURE OF FASTENERS	<ul style="list-style-type: none"> <li>Make sure fasteners are torqued correctly. Reference Table 2.</li> <li>Make sure the correct grade of fastener is used. All reducer fasteners should be ANSI B18.2.1 Grade 5 or ISO 898/1 Grade 8.8 or greater.</li> <li>Check length of fastener.</li> </ul>
FASTENER LOOSENING	<ul style="list-style-type: none"> <li>Make sure fasteners are torqued correctly. Reference Table 2.</li> <li>For highly vibratory environments, lockite fasteners and torque, or use studs and double nut.</li> </ul>

## Section 9.0

### Tables

TABLE 3 BEARINGS FOR STANDARD SPEED REDUCERS ( ALL BEARINGS ARE "TIMKEN" UNLESS NOTED OTHERWISE )				
REDUCER SERIES	INPUT BEARINGS		OUTPUT BEARINGS	
	INBOARD CUP / CONE	OUTBOARD CUP / CONE	INBOARD CUP / CONE	OUTBOARD CUP / CONE
Jupiter (s,d,t,q)	42584 / 42375	42584 / 42375	93125 / 93708	93125 / 93750
Jupiter (quint)	34478 / 34300	42620 / 42687	93125 / 93708	93125 / 93750

<sup>1</sup>Does not include motor weights

TABLE 2 TORQUE REQUIREMENTS FOR DRY FASTENERS (INCH)															
SAE	DIA	1/4	5/16	3/8	7/16	1/2	9/16	5/8	3/4	7/8	1	1 1/8	1 1/4	1 3/8	1 1/2
GENERAL PURPOSE GRADE 2	TORQUE ( ft. lbs. )	6	12	21	34	52	75	10- 4	17- 8	18- 4	26- 5	38- 0	53- 0	70- 0	93- 0
HIGH STRENGTH GRADE 5	TORQUE ( ft. lbs. )	9	18	33	53	80	11- 6	16- 0	28- 5	46- 0	69- 0	85- 0	12- 00	15- 70	20- 80
ALLOY STEEL GRADE 8	TORQUE ( ft. lbs. )	13	26	47	74	11- 4	16- 4	22- 5	40- 0	65- 0	97- 0	13- 70	19- 40	25- 40	33- 70
TORQUE REQUIREMENTS FOR DRY FASTENERS (METRIC)															
GRADE	NOMINAL DIA. STANDARD PITCH	M5	M6	M7	M8	M- 10	M- 12	M- 14	M- 16	M- 18	M- 20	M- 22	M- 24	M- 27	M- 30
8.8	TORQUE (Nm)	6- 15	10- .5	17- .5	26	51	89	14- 1	21- 5	29- 5	42- 0	57- 0	72- 5	10- 70	14- 50
10.9	TORQUE (Nm)	8- 65	15	25	36	72	12- 5	19- 8	30- 5	42- 0	59- 0	80- 0	10- 20	15- 10	20- 50
12.9	TORQUE (Nm)	10- .4	18	29	43	87	15- 0	24- 0	36- 5	50- 0	71- 0	96- 0	12- 20	18- 10	24- 50

- The torques shown produce a clamp load of 80% of proof load. They assume clean, dry threads with a torque coefficient of 0.2, and a coefficient of friction of 0.14.
- Plated threads. need only 3/4 torque shown.
- Well lubricated threads need only 1/2 torque shown.
- Source: Rexnord Engineering Specification: GES8-19, 04/10/79

## Section 10.0

### Tables: Replacement Seals and Bearings

<b>TABLE 3</b> <b>BEARINGS FOR STANDARD SPEED REDUCERS</b> <b>( ALL BEARINGS ARE "TIMKEN" UNLESS NOTED OTHERWISE )</b>				
REDUCER SERIES	INPUT BEARINGS		OUTPUT BEARINGS	
	INBOARD CUP / CONE	OUTBOARD CUP / CONE	INBOARD CUP / CONE	OUTBOARD CUP / CONE
Jupiter (s,d,t,q)	42584 / 42375	42584 / 42375	93125 / 93708	93125 / 93750
Jupiter (quint)	34478 / 34300	42620 / 42687	93125 / 93708	93125 / 93750

<b>TABLE 4</b> <b>SEALS FOR STANDARD SPEED REDUCERS</b>								
REDUCER SERIES	INPUT SEALS				OUTPUT SEALS			
	NITRILE		VITON		NITRILE		VITON	
	INBOARD	OUTBOARD	INBOARD	OUTBOARD	INBOARD	OUTBOARD	INBOARD	OUTBOARD
Jupiter (s,d,t,q)	Ñ-	Ñ-	(N) 416556V	(N) 455195V	(N) 415489	(N) 455489	(N) 415489V	(N) 455489H
Jupiter (quint)	(CR) 26220	(CR) 26209	(CR) 26204	(CR) 26208	(N) 415489	(N) 455489	(N) 415489V	(N) 455489H

N = National Seal  
CR = Chicago Rawhide

Section 11.0  
Maintenance Log

REDUCER SERIAL NUMBER \_\_\_\_\_


DATE INSTALLED \_\_\_\_\_

DATE	MAINTENANCE PERFORMED



# NOTES

**Contact a Planetgear sales representative or refer to Planetgear catalog for detailed information on accessories.**


Reducer with  
Baseplate



Reducer with  
Scoop Motor Mount



Reducer with  
Slidebase



Reducer with  
Top Motor Mount